

LF Cross-Trainer
General Assembly

X35-0000-01

120V Dom. Eng/Eng

ACCESSORY TRAY: REX2AYG
HARDWARE BAG: REX2AZ8
TOUCH UP PAINT: 7967401
RECEIVER: REX21PV
HEART RATE STRAP: REX2B95
TRANSMITTER: REX2B95
OPER. MANUAL: 7953801

CONSOLE ASSEMBLY
REX2AXW
GERMAN CONSOLE ASSEMBLY
REX2CTA

CONSOLE DECAL
REX2AV7

OVERLAY
REX2AXR


ENDCAP
REX21MV
ENDCAP SCREWS
REX0KC6

MODEL BADGE
REX2AVQ

WATER BOTTLE
REX2B96
WATER BOTTLE HOLDER
REX21CV
SCREWS
REX0K4R

CLEVIS COVERS
FRONT
REX2AQU
REAR
REX2AQT


LF LOGO LABEL
REX2ARH



**LF Cross-Trainer
Movement Arms and Hardware**

X35-0000-01


120V Dom. Eng/Eng



LF Cross-Trainer
Pedal Arms and Hardware

X35-0000-01


120V Dom. Eng/Eng




LF Cross-Trainer
Rear Components

X35-0000-01

120V Dom. Eng/Eng





RIGHT CONSOLE
MAST COVER (NOT SHOWN)
REX2AQ1
LEFT CONSOLE
MAST COVER (NOT SHOWN)
REX2AQ6
MAST COVER SCREWS (3)
REX0K4S

