Owner's Guide for the

CRATE MB10 Bass Amplifier



Congratulations!

You are now the proud owner of the compact but powerful Crate MXB10 Bass Amplifier. Small in size vet big in performance: the 8" Crate Custom speaker makes the most of the amplifier's 10 watts of musical output power. A 3-band rotary EQ gives you complete control over a wide variety of sounds. In addition, the front panel headphone and external speaker jacks make this amplifier equally suited for practicing as well as performing in intimate surroundings.

Like all Crate products, your MXB10 is designed by musicians and built using only the best components. Extensive testing confirms that this amplifier is the absolute best it can be.

In order to get the most out of your new amplifier, we strongly urge you to read the information contained in this manual before you begin playing.


And thank you for choosing



TABLE OF CONTENTS:

Important Safeguards and Precautions
The Front Panel
Suggested Settings6
System Block Diagram7
Technical Specifications









IMPORTANT SAFETY INSTRUCTIONS

- READ, FOLLOW, HEED, AND KEEP ALL INSTRUCTIONS AND WARNINGS.
- DO NOT OPERATE NEAR ANY HEAT SOURCE AND DO NOT BLOCK ANY VENTILATION OPENINGS ON THIS APPARATUS.
- DO NOT USE THIS APPARATUS NEAR SPLASHING, FALLING, SPRAYING, OR STANDING LIQUIDS.
- CLEAN ONLY WITH LINT-FREE DAMP CLOTH AND DO NOT USE CLEANING AGENTS.
- ONLY CONNECT POWER CORD TO A POLARIZED, SAFETY GROUNDED OUTLET WIRED TO CURRENT ELECTRICAL CODES AND COMPATIBLE WITH VOLTAGE, POWER, AND FREQUENCY REQUIREMENTS STATED ON THE REAR PANEL OF THE APPARATUS.
- PROTECT THE POWER CORD FROM DAMAGE DUE TO BEING WALKED ON, PINCHED, OR STRAINED.
- UNPLUG THE APPARATUS DURING LIGHTNING STORMS OR WHEN UNUSED FOR LONG PERIODS OF TIME.
- ONLY USE ATTACHMENTS, ACCESSORIES, STANDS, OR BRACKETS SPECIFIED BY THE MANUFACTURER FOR SAFE OPERA-TION AND TO AVOID INJURY
- THIS APPARATUS DOES NOT OPERATE NORMALLY AND REQUIRES SERVICE WITH ANY PHYSICAL DAMAGE FROM IMPACT OR ANY EXPOSURE TO MOISTURE.
- SERVICE MUST BE PERFORMED BY QUALIFIED PERSONNEL.
- OUR AMPLIFIERS ARE CAPABLE OF PRODUCING HIGH SOUND PRESSURE LEVELS. CONTINUED EXPOSURE TO HIGH SOUND PRESSURE LEVELS CAN CAUSE PERMANENT HEARING IMPAIRMENT OR LOSS. USER CAUTION IS ADVISED AND EAR PRO-TECTION IS RECOMMENDED IF UNIT IS OPERATED AT HIGH VOLUME.

EXPLANATION OF GRAPHICAL SYMBOLS: EXPLICACION DE SIMBOLOS GRAFICOS EXPLICATION DES SYMBÔLES GRAPHIQUES:



"DANGEROUS VOLTAGE "VOLTAJE PELIGROSO" "DANGER HALITE TENSION"




Important Safeguards and Precautions:

All Crate products are designed for continuous safe operation. Abiding by the following rules can help prevent damage to your amplifier, yourself and others.


- The amplifier is equipped with a three-pronged AC power cord. To reduce the risk of electrical shock, NEVER remove or otherwise attempt to defeat the ground pin of the power cord.
- Connect the amplifier ONLY to a properly grounded AC outlet of the proper voltage for your amp.
- Avoid sudden temperature extremes, rain and moisture. Also, avoid sudden and intense impact. (If the unit has been subjected to any of the preceding abuses, have it looked at by an authorized service center.)
- Do not expose the unit to splashing or dripping liquid. Do not place liquid filled objects on the unit.
- **NEVER** set the amplifier on a support that will not bear its weight.
- Always keep the total speaker impedance at or above the rated load.
- Unplug the amplifier before cleaning it. NEVER spray liquid cleaners onto the amplifier. Wipe it with a slightly dampened, lint-free cloth to remove dirt and film.
- DO NOT use the amplifier if it has sustained damage to the chassis, controls, or power cord. Refer the unit to an authorized service center for inspection.
- Prolonged exposure to high volume levels may cause permanent hearing loss or damage. Such damage is progressive and irreversible!

The Front Panel:



- **1: INPUT:** Use this 1/4" jack to connect your guitar to the amplifier by means of a shielded instrument cable.
- 2: LEVEL: Use this control to adjust the overall output of the amplifier.
- **3: LOW:** Use this control to adjust the bass response of the amplifier. Rotating the control counterclockwise reduces the low frequency output. Rotating the control clockwise increases the low frequency output. It may be necessary to reduce the Low control at higher volume levels.
- **4: MID:** Use this control to adjust the midrange response of the amplifier. Rotating the control counterclockwise reduces the midrange frequency output. Rotating the control clockwise increases the midrange frequency output.
- **5: HIGH:** Use this control to adjust the high frequency response of the amplifier. Rotating the control counterclockwise reduces the high frequency output. Rotating the control clockwise increases the high frequency output.
- **6: SPEAKER:** Use this jack to connect the amplifier to an external speaker. The internal speaker is disconnected when this jack is used. The impedance of the external speaker must be 4 ohms or greater.

WARNING: Do not attempt to use headphones in the Speaker jack! Permanent hearing damage could result!



7: HEADPHONES: Use this jack to connect headphones to the amplifier. The internal speaker is disconnected when headphones are used.

CAUTION: To avoid possible damage to your hearing, do not use headphones for extended periods of time at extremely loud levels.


8: ON LED: This LED illuminates when the amplifier is turned on.

9: POWER: Use this switch to turn the amplifier on (top of the switch depressed) and off (bottom of the switch depressed).


10: POWER CORD (rear panel, not shown): The grounded power cord should only be plugged into a grounded power outlet that meets all applicable electrical codes and is compatible with the voltage, power, and frequency requirements stated on the rear panel. Do not attempt to defeat the safety ground connection.

Suggested Settings:


Clean:




Blues:




Rhythm:



Lead:



System Block Diagram:



MXB10 TECHNICAL SPECIFICATIONS:

10 watts @ 15% THD		
14 watts @ 10% THD		
8"		
500k ohms		
1mV		
10mV		
0.9%		
120 VAC, 60Hz, 20VA		
100/115VAC, 50/60Hz, 20VA		
230VAC, 50Hz, 20VA	1	
16" H x 12.5" W x 6.5" D, 12.5 lbs.		
	14 watts @ 10% THD 8" 500k ohms 1mV 10mV 0.9% 120 VAC, 60Hz, 20VA 100/115VAC, 50/60Hz, 20VA 230VAC, 50Hz, 20VA	14 watts @ 10% THD 8" 500k ohms 1mV 10mV 0.9% 120 VAC, 60Hz, 20VA 100/115VAC, 50/60Hz, 20VA 230VAC, 50Hz, 20VA

The MXB10 is covered with a durable black Tolex material: wipe it clean with a lint-free cloth.

Never spray cleaning agents onto the cabinet. Avoid abrasive cleansers which would damage the finish.

Crate continually develops new products, as well as improves existing ones. For this reason, the specifications and information in this manual are subject to change without notice.

