



Mini Multimedia Keyboard User's Manual



Model No.: MCK-91

Copyright

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

Trademarks

All trademarks and registered trademarks are the property of their respective owners.

Federal Communications Commission Statement

This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Table of Contents

1. Introduction.....	3
2. System Requirements.....	3
3. Installation.....	4
4. Hot Key Buttons.....	4-5
5. Product Registration.....	6
6. Technical Support.....	6
7. Warranty.....	6-7

1. Introduction

Congratulations on purchasing the Mini Multimedia Keyboard. The Mini Multimedia Keyboard combines a standard mini keyboard layout with eleven (11) convenient multimedia buttons and 3 additional power management hot keys.

Key Features:

- Volume Control Buttons
- WWW and E-mail Access Buttons
- Media Control Keys

Contents:

The following items are included in the package. Please make sure all items are included as you open the package. If there is any item missing or damaged, please contact the reseller who sold you this product, or our support center.

- One Keyboard
- User's Manual

2. System Requirements

- IBM Compatible PC System
- Microsoft Windows 98SE/Me/2000/XP
- Microsoft Internet Explorer 5.0 or later.
- 64MB of RAM is recommended.

3. Installation




For Windows ME/2000/XP Users:









- Turn off your computer
- Connect the keyboard to the computer's PS/2 port or USB port, depending on what connection the keyboard comes with.
- Turn on your computer.
- For Windows Me/2000/XP users, the hot keys will work automatically so there is no need to install drivers.

For Windows 98SE Users:

- Turn off your computer
- Connect the keyboard to the computer's PS/2 port or USB port, depending on what connection the keyboard comes with.
- Turn on your computer.
- Download our multimedia software to enable the hot keys on this keyboard; it can be downloaded here: <http://www. adesso.com/drivers.asp>

4. Hot Key Buttons

Function Name	Function Description
 Back	Allows users to return to the most recently viewed web page.
 Forward	Advances to a previously accessed web page.
 WWW	Launches the default Internet browser in your system.

 E-Mail	Allows the user to compose e-mails for subsequent sending over the Internet.
 Volume Down	Decreases the volume of the current audio output by one level.
 Volume Up	Increases the volume of the current audio output by one level (every time the button is pressed). The maximum audio output is 32 scales.
 Mute	Cuts off the audio output of the file being played. Press again to restore the sound.
 Pre Track	Fast backtrack through the current track/file.
 CD Stop	Stops the audio/video file currently being played.
 Play	Plays a CD, VCD or DVD. If the CD drive is empty, you are asked to select a saved audio/video file. Play starts after you select the file and click on "Open". Press the play button again to pause the file being played.
 Next Track	Skips forward to the next track/file.
Wake	Wakes up your system from Sleep Mode.
Sleep	Puts the system into Sleep Mode if the PC supports Power Management and it is enabled.
Power	Turns your computer off.

5. Product Registration

To activate this products warranty and to provide more efficient customer service, Adesso recommends that you register your Adesso product shortly after purchasing it.

To register your Adesso product, go to:

http://www.adesso.com/product_registration.asp

6. Technical Support

For technical questions, please visit our (FAQs) Frequently Asked Questions: <http://www.adesso.com/faqs.asp>

Or contact support at Adesso Inc.

Monday - Friday, 9:00 a.m. to 6:00 p.m. PST

Email: support@adesso.com

Phone: (800) 467-1195

7. Warranty

Adesso's warranty obligations are limited to the terms set forth below. Adesso warrants this hardware product against defects in materials and workmanship for a period of ONE (1) year from the date of original retail purchase.

If you discover a defect, Adesso will, at its option, repair or replace the product at no charge to you, provided you return it during the warranty period with freight charges pre-paid to Adesso. You must contact Adesso for a Return Merchandise Authorization number (RMA) prior to returning any product. For each product returned for warranty service, please include your name, shipping address (no P.O. Box), telephone number, copy of the receipt or invoice as proof of purchase and clearly mark the package with your RMA number. For warranty service outside of the United States or Canada, customer must bear the cost of shipping in both directions. Please contact support@adesso.com for instructions.

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, WHETHER WRITTEN, ORAL, EXPRESS OR IMPLIED. ADESSO SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING AND WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO ADESSO DEALER, AGENT, OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION, EXTENTION OR ADDITION TO THIS WARRANTY.

ADESSO IS NOT RESPONSIBLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY, OR UNDER ANY LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPLACEMENT OF EQUIPMENT OR PROPERTY AND ANY COST OF RECOVERING, REPROGRAMMING OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH ADESSO PRODUCTS. ADESSO'S MAXIMUM LIABILITY FOR ANY AND ALL DAMAGES ARISING OUT OF USE OF THE PRODUCT SHALL BE LIMITED TO THE AMOUNTS PAID BY PURCHASER FOR SUCH PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages or exclusion of implied warranties, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

Adesso is a trademark of Adesso Inc. All other trademarks and trade names are property of their respective holders. Specifications and information in this publication are subject to change.