



BookEndz®

Owner's Manual

**DOCKING STATION
FOR THE APPLE®
MACBOOK AIR®**



© OlympicControls Corp.

THANK YOU

Thank you for purchasing the **BookEndz**[®] Dock for your MacBook[®] Air Computer. The purpose of the **BookEndz**[®] Dock is to eliminate the hassles, headaches, wear & tear, and delays that arise from having to plug in all of your peripheral cables each time you want to use them. Once the cables are plugged into the dock, all you need to do is slide in your **BookEndz**[®] Dock and you are connected to everything at once.

Prior to using your new **BookEndz**[®] Dock, take a few minutes to read through this manual. It contains important information regarding the use of your new **BookEndz**[®] Dock.

TABLE OF CONTENTS

| | |
|---|-----|
| Installing Your New BookEndz ® Dock | 3 |
| MacBook® Air - Features & Ports | 4 |
| BookEndz ® Dock - Features & Connectors <i>Right Side</i> | 5-6 |
| BookEndz ® Dock - Features & Connectors <i>Left Side</i> | 7 |
| Docking and Undocking Your BookEndz ® Dock | 8 |
| Audio Hookup | 9 |
| Limited Warranty | 10 |
| Product Registration | 11 |

INSTALLING YOUR NEW **BookEndz**® DOCK

1. Place the **BookEndz** Dock on the flat surface on which it will be used and plug all of your external devices into the **BookEndz** Docking Station (video monitor, network, etc.).
2. Shut down the MacBook Air and close the LCD screen.
3. Place the MacBook Air on to the BookEndz Dock. Make sure that the ports of the MacBook Air align with the connectors of the BookEndz Dock. Once these ports are lined up push both sides simultaneous into the MacBook Air.
4. Restart your MacBook Air and allow your peripheral devices to bootup.
5. To travel with your MacBook Air, shut down your MacBook Air and all external devices and close the LCD screen. It is not necessary to unplug them from the dock. Move the release handle to the vertical position. The **BookEndz** Dock will gently undock from your MacBook Air.
6. Refer to page 8 for more details on docking and undocking.
7. This Docking station comes with an AC/DC power adapter to power the USB hub included in the BookEndz Dock. This power supply does not power the laptop. * Please see page 6 to locate where the power supply is plugged in. The MagSafe power supply that comes with the Apple laptop will have to be plugged in directly to your laptop to charge it.

The **MacBook Air** **FEATURES & PORTS**

Your MacBook Air has several side panel ports and features as shown:



MAGSAFE POWER

USB

AUDIO

MICROPHONE

MACBOOK AIR Left Side



SD

USB

MINIDISPLAY PORT

MACBOOK AIR Right Side

*Picture shown is 13" MacBook Air Laptop.

The 11" MacBook Air has same side ports with the exception of SD Slot.


DOCK FEATURES & CONNECTORS Left side

Top View


The connectors shown below mate with those on your MacBook Air and allow you to easily dock and undock with your external devices.

Top View

1. *Audio Out
2. USB 2.0



Back View



1. T100 Ethernet**
2. Stacked USB 2.0
3. Stacked USB 2.0
4. Audio Out

*Please see page 10 for Audio Hookup

**Please visit www.bookendzdock.com for instructions for downloading the Ethernet driver

DOCK FEATURES & CONNECTORS Left side

Plug all of your peripherals into the ports shown below on the rear of your **BookEndz** Dock. Be sure all peripherals are turned off prior to connecting them to your **BookEndz** Dock.


Front View



Headphone Out

Bottom View

USB Power Port



DOCK FEATURES & CONNECTORS Right side

Plug all of your peripherals into the ports shown below on the rear of your **BookEndz** Dock. Be sure all peripherals are turned off prior to connecting them to your **BookEndz** Dock.

Top View

1. Mini Display Port
2. USB 2.0



Back View



MiniDisplay Port




Front View
USB 2.0
(Charging)

DOCKING AND UNDOCKING YOUR BookEndz® DOCK

Docking your **BookEndz** Dock into the MacBook Air is simple, quick, and easy. With your MacBook Air shutdown (not asleep), position the dock on the flat surface you intend to use it on. Align the connectors on the **BookEndz** Dock, with the ports on the MacBook Air, and gently push the **BookEndz** Dock until docking is complete.

To undock, shutdown the MacBook Air and move the release handle to the vertical position. The **BookEndz** Dock will gently undock from your MacBook Air.




Please visit www.bookendzdocks.com and go to Media page to watch a video for proper Docking and Undocking.


AUDIO HOOKUP

The Headphone Out Connector on your **BookEndz** Dock was designed to allow use of either external speakers or the internal speakers of your MacBook Air.

To use external speakers, move the Headphone Out Connector to engage into the MacBook Air:



To use internal speakers, move the Headphone Out Connector to disengage from the MacBook Air:



LIMITED WARRANTY

OlympicControls Corp. (“Manufacturer”) warrants this **BookEndz**® product to be free from defects caused by faulty materials or poor workmanship for a period of one year from the date of shipment to the initial user of the product. This liability of manufacturer under this warranty is limited to replacement or repair at its option.

The foregoing warranty is subject to the following conditions that must be met:

- a) Manufacturer is promptly notified in writing within ten (10) days after the discovery of such defect, and
- b) The defective unit is returned to Manufacturer, freight prepaid, within ten (10) days of the discovery of such defect, and
- c) Manufacturer’s examination of such units shall disclose to its reasonable satisfaction that such defects exist and have not been caused by misuse, neglect, improper installation, repair, alteration or accident caused by parties other than manufacturer.

Manufacturer’s products are not authorized for use as critical components in life support devices or systems which are intended for surgical implant into the body to sustain life. A critical component is any component of a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system or to affect its safety and effectiveness.

This warranty is the only warranty made to any person by OlympicControls Corp. and is in lieu of all other express warranties. IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. The remedies set forth in this warranty shall be the exclusive remedies available to any person for breach of this warranty. Under no circumstances shall Manufacturer be liable to any person for incidental or consequential damages, whether arising out of breach of warranty or other contract, negligence, strict liability or other tort, or otherwise.

No waiver or modification of the Warranty or any of its terms shall bind OlympicControls Corp. unless in writing and signed by an officer of OlympicControls Corp.

Apple and MacBook Air are registered trademarks of Apple Computer Inc. **BookEndz**® is a registered trademark of OlympicControls Corp. All other product names are trademarks or registered trademarks of their respective holders.

Features and specifications are subject to change without notice.

BookEndz Product Registration

Mr. Ms. Mrs.

First Name _____

Last Name _____

Company _____

Address _____

City _____ State _____ Zip Code _____

Telephone Number _____

Fax Number _____

Email Address _____


Where Purchased _____

Purchase Date _____

Model Number _____

Serial Number _____

Please Fax to 1-847-742-5686
Or email sales@bookendzdocks.com



Docking Stations for Apple Computers



BookEndz[®]

**1250 Crispin Drive
Elgin, Illinois 60123 USA**

Toll Free: 888-622-1199

Phone: 847-742-3566

Fax: 847-742-5686

E-mail: Sales@BookEndzdocks.com

www.BookEndzdocks.com

Pub. No. BE-10386

BookEndz is protected by US Patent #5,186,646
and produced by OlympicControls Corporation