

Duet Set Microphone Kit

For SingStar® & Rock Band™

Model: BH4008

PS2™ and PS3™ are registered trademarks of Sony Computer Entertainment, Inc. This product is not sponsored or approved by Sony.

Microsoft® and XBOX™ 360 are either registered trademarks or trademarks of Microsoft Corporation in the U.S. and/or other countries. This product is not sponsored, endorsed or approved by Microsoft®.

Nintendo® and Wii™ are either registered trademarks or trademarks of Nintendo® of America, Inc. This product is not sponsored, endorsed or approved by Nintendo®.

Thank you for purchasing this Blockhead Duet Set Microphone Kit for Rock Band™ on PS2™, PS3™, Wii™ and Xbox™ 360 and SingStar® on PS3™. We hope you enjoy it. For your personal safety and for the safety of others, please carefully read this instruction manual as well as the instruction manuals that came with your game consoles and games.

PRECAUTIONS


- Make sure to read the Instruction Manual of the Grinder Guitar Controller before using the product.
- If you have any health concerns, please consult with your physician prior to using the Grinder Guitar Controller.
- If at any time during game play you feel achy, numb, tingling or anything else abnormal, please take a break from playing. Blockhead recommends taking frequent breaks to prevent any of the above from happening.
- Keep all liquids away from this product. Getting this product wet will void your warranty.
- Do not insert objects of any kind into the product as this may cause damage or a fire hazard and void your warranty.
- Make sure small children are supervised while playing.
- Grinder Guitar Controller out of environments of extreme heat and extreme cold.
- If you have any technical or functional problems with the Grinder Guitar Controller, please contact Customer Service and do not try to modify the product or fix the problem yourself as this would void your warranty.
- When the Grinder Guitar Controller is not in use, make sure to store it properly for both safety and preservation of the product.

CONTENTS


- 2 Microphones
- 1 Harmonizer Splitter
- 1 Instruction Manual

Set-Up Guide

- 1 Slide the toggle switch according to which game you are going to play. Left, Rock Band™ on PS2™, PS3™, Wii™ and Xbox™ 360; Right, SingStar® on PS3™.




- 2 Turn on your microphone.




Set-Up Guide

- 3 Insert the microphones' plugs into the adapter.



- 4 Connect the USB cable to the console's USB port.



WARRANTY AND TECHNICAL SUPPORT

Every Blockhead branded product comes with a 90 day warranty (U.S. Only). Blockhead will replace, repair or refund any defective products or components at no charge to you within 90 days of the purchase date. This warranty does not apply if the Blockhead branded product has been damaged by misuse, neglect, or reasons unrelated to defective materials or assembly. Blockhead is not responsible or liable for loss of data or loss of equipment use. You must retain a copy of your original receipt for warranty support.

For support on Blockhead products, contact us by visiting www.blockheadgaming.com or call us at 727-431-0650.

For general questions, comments, information and grammar tips, email us at info@blockheadgaming.com.