

You can read the recommendations in the user guide, the technical guide or the installation guide for BOSCH SHE46C06UC. You'll find the answers to all your questions on the BOSCH SHE46C06UC in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

> **User manual BOSCH SHE46C06UC** User guide BOSCH SHE46C06UC **Operating instructions BOSCH SHE46C06UC Instructions for use BOSCH SHE46C06UC Instruction manual BOSCH SHE46C06UC**

DISHWASHER USE AND CARE MANUAL MODEL: SHE44C / SHE46C / SHE47C / SHE56C / SHU43C / SHX46A / SHX46L / SHX43E / SHV46C / SHE53L


GUIDE D'ENTRETIEN ET D'UTILISATION DU LAVE-VAISSELLE

MODÈLE : SHE44C / SHE46C / SHE47C / SHE56C / SHU43C / SHX46A / SHX46L / SHX43E / SHV46C / SHE53L

MANUAL DE USO Y CUIDADO PARA LAVADORA DE PLATOS

MODÈLOS: SHE44C / SHE46C / SHE47C / SHE56C / SHU43C / SHX46A / SHX46L / SHX43E / SHV46C / SHE53L





Manual abstract:

Use only detergents or wetting agents recommended for use in a dishwasher, and keep them out of the reach of children. When loading items to be washed: Locate sharp items so that they are not likely to damage the door seal. - Load knives and other sharp utensils with their HANDLES UP to reduce the risk of cut-type injuries. Do not wash plastic items unless they are marked "dishwasher safe" or the equivalent. For plastic items not so marked, check the manufacturer's recommendations. Do not operate your dishwasher unless all enclosure panels are in place. WARNING Electrical shock or fire could result if the electrical supply for the dishwasher covered in this manual is incorrectly installed or if the dishwasher has been improperly grounded. Do not use the dishwasher covered in this manual if you are not certain the electrical supply has been correctly installed or the dishwasher has been properly grounded.
GROUNDING INSTRUCTIONS This appliance must be grounded to a metal, permanent wiring system, or an equipment grounding conductor must be run with the circuit conductors and connected to the equipment grounding terminal or lead on the dishwasher. See the Installation Instructions included with this dishwasher for more information on electrical requirements.

·· SAVE THESE INSTRUCTIONS! 2 Dishwasher Components Vent Door Gasket Top Rack Top Rack Spray Arm Bottom Rack Spray Arm Bottom Rack Filter System (in dishwasher floor) Silverware Basket Detergent/ Rinse Agent Dispenser CAUTION It is highly recommended for the end use consumer to become familiar with the procedure to shut off the incoming water supply and the procedure to shut off the incoming power supply. See the Installation Instructions or speak with your installer for more information. Model/Serial Number Label 3 Dishwasher Features and Options Noise Reduction System: A two-pump motor system, the Suspension MotorTM, and triple insulation make this dishwasher one of the quietest in North America. Stainless Steel TALLTUBTM: A rust-free, hygienic interior surface with a lifetime warranty. See warranty statement for details.

Nylon Coated Racks: Eliminate cuts and nicks, and have a five-year warranty. Flow-Through HeaterTM: Heats water to a temperature of up to 161°F. Condensation Drying: A high temperature final rinse, a low temperature stainless steel tub, and the sheeting action of a rinse agent result in drying that is hygienic, energy efficient, and economical. SENSOTRONICTM Water Condition Monitor: Checks water condition and decides whether a second fresh water fill is necessary. Filter System: Three filters ensure distribution of clean water and protect the main pump and the drain pump from foreign material. Water Shut-Off: A safety feature that stops the flow of incoming water, if water is detected in the base of the dishwasher. Fully Integrated Unit (Model SHV46C13): A fully integrated unit that requires a custom front door..

