

SOLAR LIGHT SET Model 97294

SET UP AND OPERATING INSTRUCTIONS



Diagrams within this manual may not be drawn proportionally.

Due to continuing improvements, actual product may differ slightly from the product described herein.

Distributed exclusively by Harbor Freight Tools[®].

3491 Mission Oaks Blvd., Camarillo, CA 93011

Visit our website at: http://www.harborfreight.com

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Copyright[©] 2007 by Harbor Freight Tools[®]. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

For technical questions or replacement parts, please call 1-800-444-3353.

SAVE THIS MANUAL

Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

General Safety Rules

WARNING! Read all instructions Failure to follow all instructions listed below may result in injury.

SAVE THESE INSTRUCTIONS

- 1. Work area safety
 - a. Keep work area clean and well lit. *Cluttered or dark areas invite accidents.*
 - b. Keep children and bystanders away while installing or servicing the Lights. *Distractions can cause you to lose control.*

2. Personal safety

- a. Stay alert, watch what you are doing and use common sense when installing the Lights. Do not install while you are tired or under the influence of drugs, alcohol or medication.
- b. Use safety equipment. Always wear eye protection. Safety equipment such as dust mask or work gloves used for appropriate conditions will reduce injuries.
- 3. Light use and care
 - a. Do not use the Light if the switch does not turn it on and off. *Any*

product that cannot be controlled with the switch must be repaired.

- b. Disconnect the battery before making any adjustments, changing accessories, or storing the Lights.
- c. Maintain the Lights. Check for misalignment or breakage of parts and any other condition that may affect operation. If damaged, have the Light repaired before use.

5. Service

a. Have your Lights serviced by a qualified repair person using only identical replacement parts.

Specific Safety Rules

- Maintain labels and nameplates on the tool. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.
- 2. This product is not a toy. Keep it out of reach of children.
- Dispose of batteries in a manner appropriate for their type according to State, Local and Federal laws and regulations.
- 4. The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.



For technical questions, please call 1-800-444-3353.

SPECIFICATIONS

Battery	One Ni-Cd, AA 1.2V, 600mAh
Башегу	per Light (included)

UNPACKING

When unpacking, check to make sure that the item is intact and undamaged. If any parts are missing or broken, please call Harbor Freight Tools at the number shown on the cover of this manual as soon as possible.


INITIAL SET UP



Read all warning sections at the beginning of this manual including all text under subheadings therein before set up or use of this product.

- **Note:** For additional information regarding the parts listed in the following pages, refer to the Assembly Diagram near the end of this manual.
- 1. Open the battery cover on the bottom of the unit to verify that battery polarity is correct. Be careful not to pull on the wires connected to the cover, damaging the wires will render the unit dysfunctional. If necessary, remove tabs between the battery and the post. The battery must make contact with the post to operate.
- 2. Take an Inner Cover (2), place it over the light bulb and rotate it clockwise until the tabs on the Inner Cover are underneath the lip on the Cap.
- 3. Turn the Solar Light on.

- 4. Place an Outer Cover (3) over the Inner Cover and rotate it clockwise until the Tabs on the Outer Cover are underneath the lip on the Cap.
- 5. Examine the area where the Solar Light is to be placed. Make sure there are no utility lines beneath the surface that might be damaged. For best results, the Lights should be placed in an area that receives at least eight hours of direct sunlight per day.



- secures for Outer Cover (3)
- 6. Place a Spike (6) onto a Shaft (4) and push the unit firmly into the ground.
- The Solar Light can either be placed on the Shaft now, or a Connector (5) can be used to connect another Shaft and raise the height of the Light.
- 8. Repeat these steps to assemble all the lights.

OPERATING INSTRUCTIONS

- Before first use, ensure that each Solar Light receives a full day's exposure to direct sunlight. This will charge the batteries.
- 2. The Solar Light will turn on automatically when it gets dark.
- Do not install the Solar Light near a nighttime light source. A bright light source will prevent the Light from turning on at night.

MAINTENANCE AND SERVICING



Procedures not specifically explained in this manual must be performed only by a qualified technician. Turn the Power Switch of the light to its "OFF" position before performing any inspection, maintenance, or cleaning procedures.

Cleaning, Maintenance, and Lubrication

- 1. **BEFORE EACH USE,** inspect the general condition of the tool. Check for loose screws, cracked or broken parts, damaged electrical wiring, and any other condition that may affect its safe operation.
- 2. **PERIODICALLY,** clean external surfaces of the tool with clean, moist cloth. For best operation, clean the Solar Panel on the top of the Cap, so that the battery will charge efficiently.
- 3. Change the battery every year.


 Dispose of the battery in a manner consistent with State, Local and Federal laws and regulations. Check with your local hazardous waste disposal facility for instructions.

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LISTAND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT. THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THATALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Part	Description	Qty
1	Сар	10
2	Inner Cover	10
3	Outer Cover	10
4	Shaft	20
5	Connector	10
6	Spike	10

PARTS LIST & DIAGRAM



Record Product's Serial Number Here:_

Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.

SKU 97294 For technical questions, please call 1-800-444-3353. Page 5