Wireless Infrared Keyboard WK350BK

Philips Magnavox Wireless Keyboard

The wireless keyboard is designed for use with the Philips Magnavox Internet Terminals and Receivers. Together, the wireless keyboard and the Internet Terminal or Receiver allow you to access and browse the Internet from your TV viewing area.

The wireless keyboard is battery operated and uses an IR (infrared) signal to send information to the Internet Terminal or Receiver.

Keyboard features include:

· Non-skid rubber feet

• Effective operating range: 32.8 feet (10 meters)

Effective operating angle: 90 degrees









SmartConnect



For use with all Philips Magnavox Internet Terminals and Receivers

Wireless Infrared Keyboard WWK350BK

Keyboard Functions

A brief explanation of the keyboard buttons is given below.

Power (Web)

Press to turn the Internet Terminal on and off.

Power (TV)

Press to turn the TV on and off.

Code set

Press before entering the code that enables the keyboard to operate your TV.

TV/WebTV Switch

When this switch is set to TV, press the channel +/- buttons to change the TV Channels. When this switch is set to WebTV, press the channel +/- buttons to change the TV channel in the PIP (Picture in picture) window.

View

Press to display the PIP (picture in picture) window while WebTV is on-screen. Press again to enlarge the PIP window (full-screen TV viewing). Press again to remove the PIP window and return to a full-screen WebTV.

Mute

Press to turn the volume on or off.

Volume +/-

Press to turn the volume up or down.

Channel +

When the TV/WebTV switch is set to TV, press the Channel +/-buttons to change TV channels. When the TV/WebTV switch is set to WebTV, press the channel +/- buttons to change the TV channel in the PIP window.

F1-F6

Press to go to a Favorites page. First, you must assign a favorite page to each button.

Favs

Press to display your favorites folder.

Home

Press to display your Web page, or press to display the TV home page. (available in select models only)

SmartConnect™

Press to access additional Internet features and services.

Search

Press to access the search tool and look for a topic on the Internet.

Mail

Press to go to your mailbox, where you can send and receive email.

Find

Press to search for a word or phrase on a Web page or in an email.

Info

Press to display information about the displayed Web page.

Go to

Press to enter an Internet address. Then, press the return key to go to that address.

Save

Press to save the displayed Web page to your Favorites folder.

Send

Press to send someone the email address of the displayed Web page.

Edit

When an area on-screen required you to enter information, the area will be surrounded by a yellow highlight box. Press the edit button to activate the cursor, then enter the text.

Rack

Press to return to the previously viewed screen

Scroll up, scroll down

Press to move a Web page up or down on your screen.

Arrows

Press to move the yellow highlight box to different links.

Options


Press to display the options panel.

Recent

Press to display the most recent pages viewed.

Operating area

When using the wireless keyboard, remember that an IR signal is in use. The IR lens on the wireless keyboard should be pointing in the direction of the Internet Terminal and Receiver to maintain a properly aligned signal. Remember, point the keyboard toward the Internet Terminal, not your TV. The wireless keyboard will work properly when it is within 10 meters (32.8 ft.) and a ninety-degree angle of the Internet Terminal.



Carton Contents

- MWK350BK
- 2-AA batteries
- Owner's manual

UPC-Single Pack: 0 37849 88864 3 Product Dimensions: 12.7"L x 7.5"W x 1.4"H Product Weight: 1.4 lbs Carton Dimensions: 13.6"L x 8.5"W x 1.73"H Carton Weight: 1.75 lbs UPC-Master Pack: 1 37849 88864 0 Master Pack: 3

INTERNET ADDRESS: http://www.philipsusa.com

Printed in U.S.A. ©1999 Philips Consumer Electronics Co. A Division of Philips Electronics North America Corp. KID Design GR99213, Philips Consumer Electronics Co.

Subject to modification without notice

