

Philips
Wall mount

Antenna

SDW1410

Mount outdoor antenna

to side of house

Securely situate your antenna outdoors.

Includes all hardware

- Two 3" wall mounts
- Two U bolts
- · Wood screws, lock washers and hex-nuts



Wall mount Antenna

Specifications

Outer Carton

- Gross weight: 2.04 kg
 Outer carton (L x W x H): 30.5 x 25.4 x 15.5 cm
 Nett weight: 1.632 kg
 Tare weight: .408 kg

Packaging dimensions

- Packaging dimensions (W x H x D): 18.3 x 24.1 x 2.8 cm
- · Gross weight: .295 kg
- Nett weight: .272 kg
- Tare weight: .023 kg

Product highlights

Two 3" wall mounts

These two mounting brackets bolt to the house, keeping the antenna in place.

Two U bolts

These two bolts screw into the mounting brackets to secure $% \left\{ 1\right\} =\left\{ 1\right\}$ the antenna.

Wood screws, washers, hex-nuts

This hardware secures the mounting brackets and \boldsymbol{U} bolts.



Issue date 2008-08-19

© 2008 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 1.3.3

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 35216 UPC: 6 09585 14546 7

www.philips.com