



## PT260A OPERATING MANUAL



**200 Watts Digital AM/FM Stereo Receiver**

[www.pyleaudio.com](http://www.pyleaudio.com)

# PT260A Foreword - Features

## Foreword

---

Thank you for purchasing this fine PYLE PRO amplifier.  
Please read this operating instruction carefully before using. It will acquaint you fully with all its features and help you enjoy your time .  
The product adopts the most advanced digital technique in the world. It is 4 channels with high power output, so to speak, the real acoustic centre of your family movie theatre.

## Features

---

- ◆ Stereo Amplifier With A/B Speaker Output
- ◆ AM/FM Radio With Digital Display Screen
- ◆ Auto Scan, Memory, Radio Station PREVIOUS/NEXT control
- ◆ Remote Control Included
- ◆ 50 Radio Station Pre-Set Memory
- ◆ Volume/Balance/TREBLE/BASS Gain Control For Main Channel
- ◆ VOLUME/BASS/TREBLE/ECHO Control For Microphone
- ◆ Two Microphone Input Jacks
- ◆ Three RCA Input Source
- ◆ 110/220V power switch
- ◆ AM/FM Antenna Included

### **Precautions**

---

1. Power source-The unit should be connected to a power supply AC~110/60Hz or AC~220V/50Hz.
2. Ventilation-The unit should be situated so that its location or position does not interfere with its proper ventilation. Place the unit at least 10cm away from the walls.
3. Water and moisture-The unit should not be used near water-for example, near a swimming pool in a wet basement, etc.
4. Electric shock-if a metal object, such as hair pin or needle comes into contact inside this unit, a dangerous electric shock may result. For families with children, never permit children to put anything, especially metal, inside this unit.
5. Enclosure removal-Never remove the enclosure. If the internal parts are touched accidentally, a serious electric shock might occur.
6. Abnormal smell-if an abnormal smell or smoke is detected, immediately turn the power OFF and pull out the power cord. Contact your dealer or nearest service station.


# PT260A Technical Specifications

## Technical Specifications

<b>Technical</b>	PT260A	
<b>Main Channel Power Output</b> PMPO, 4 Ohms, 1KHz test THD(1KHz)	100WX2 <1%	
<b>Normal Load Impedance</b>	8 Ohm	
<b>Input Sensitivity Impedance</b>	CD/DVD AUX	300mV/33k Ohm
	Microphone	6mV/600 Ohm
<b>Signal to Noise Ratio</b>	Pure Amplifier	>76dB
	KARAOKE	>71dB
<b>Frequency Range</b> Frequency Response(40Hz-15KHz)	$\pm 2$ dB	
<b>Tone Characteristic(100Hz-10KHz)</b>	$\pm 14$ dB	
<b>Power Requirements</b>	AC~110V/60Hz AC~220V50Hz	
<b>Dimension</b>	19" (W) x11.4"(D)x 4.7" (H) inch	
<b>Weight</b>	9.9 lbs	


※ Specifications subject to change without prior notice

## PT260A Front panel




1. POWER SWITCH  
Press to switch the power unit ON or OFF.
2. MIC BASS  
Adjusts the bass of MIC.
3. MIC TREBLE  
Adjusts the treble of MIC.
4. ECHO CONTROL  
Turn the knob to adjust the MIC echo level.
5. MIC INPUT JACK 1  
KARAOKE MIC connect to this jack.
6. INPUT  
This is used to select the input sources:  
DVD/CD, TUNER, IPOD/MP3, AUX
7. AM/FM SELECTOR
8. MEMORY
9. AUTO  
Automatically search the signal of tuner.
10. CH-  
This knob is used to select the preview station which has been kept in system.
11. CH+  
This knob is used to select the next station which has been kept in system.
12. MENU CONTROL  
This is used to increment and decrement level for the selected function of STEREO/MONO, Sharp tuning when in TUNER status and VFD style by adjusting master volume knob.
13. MIC INPUT JACK 2  
KARAOKE MIC connect to this jack.
14. MIC VOLUME  
Adjusts the volume level. Turn the knob clockwise to increase the MIC volume.
15. BALANCE CONTROL  
Turn the knob to adjust the master balance level.
16. TREBLE CONTROL  
Turn the knob to adjust the master treble level.
17. BASS CONTROL  
Turn the knob to adjust the master bass level.
18. MASTER VOLUME CONTROL  
Adjusts the volume level. Turn the knob clockwise to increase the volume.

## PT260A Rear panel



- (1) TUNER ANT  
Connect for AM and FM antennas.
- (2) AUDIO INPUT JACKS  
Connect the audio output jacks of IPOD/MP3 \AUX \ CD/DVD to these jacks.
- (3) A SPEAKER OUTPUT TERMINALS  
Connect your speaker system to these terminals.
- (4) B SPEAKER OUTPUT TERMINALS  
Connect your the other speaker system(s) to these terminals.
- (5) 110V/220V SWITCH  
According to power voltage , push this button to the station of the 110V or 220V.
- (6) POWER CORD  
Connect to AC 110V/60Hz & 220V/50Hz outlet.

# PT260A Remote




1. Signal input selector  
CD/DVD,AUX,IPOD/MP3,TUNER selector
2. Number buttons  
Using for st SELECT & STORE
3. MEMORY  
After a station has been found, you can store the station by pressing the MEMORY button.
4. AUTO SCAN  
AM/FM auto scan selector, scan and store stations automatically. Can store 50 stations.
5. ST/MONO  
Stereo and mono selector.
6. AM/FM  
AM/FM selector.
- 7/10. DISP- / DISP+  
Display Down And Up
- 8/11. VOL- / VOL+  
Master Volume Down And Up
9. MUTE  
Mute Selector
12. TUNING ▲ TUNING ▼  
The two keys are used to adjust to the best signal of the stations.

## Remote Control Operation

1. Remote control should be operated within 6 meters and the scope of 30° in front of receiver.
2. Make sure that there is no big obstacle between remote control and machine.
3. Remote sensor should be far away from the light, high amounts of light can affect its performance.

# PT260A Rear Panel Connecting

## Connecting to amplifier







PyleAudio.com

718.535.1800 718.236.2400 (fax)  
1600 63rd Street, Brooklyn NY 11204