



**Conserving Internal Memory**  
It is strongly recommended to purchase and install a Micro SD card before transferring or downloading media files.

**Transferring and managing files**  
This tablet supports Micro SD cards up to 32GB (not included). To install a Micro SD card into the tablet: 1. Insert the card as shown below, into the card slot until it clicks and locks into place. 2. Once the card is mounted, the card icon appears on the Status Bar. 3. To access the Micro SD card, select "File Manager" from the Apps screen.

**Connecting the tablet to a PC or Mac**  
1. Connect the included USB cable to the "USB" port of the tablet and USB port of the computer. 2. The "USB connected" screen appears, select "Turn on USB storage" screen, then select "OK".

**Bluetooth**  
You can use the Bluetooth in your tablet to connect to various Bluetooth devices such as speakers and headphones. 1. Turn Bluetooth on or off. 2. Select Bluetooth. 3. Select "Turn off USB storage" on the tablet to disconnect it from the computer.

### Home screen

On the Home screen, you can place app shortcuts and widgets. There are three Home screens (left, center, right).  
**Access apps & widgets screen:** Press **Home** to access the Apps & widgets screens. Press **Home** again to return to the Home screen.  
**Placing apps & widgets on the Home screen:** Press & hold an app or widget to place it on one of the Home screens. **Remove shortcuts or widgets:** Press and hold the app or widget and slide it as shown below. You can always bring the widgets back from the Widgets screen.

### Connecting to Wi-Fi

**Status Bar:** The Status Bar is available on all screens and apps of the tablet.  
**Connecting to Wi-Fi:** 1. Swipe the Home screen to the left to access the Polario Settings widget. 2. Select "Wi-Fi Setup". 3. Select a network. 4. If required, enter the correct password and select "Connect". 5. When the tablet is connected to a network, the Wi-Fi icon will appear on the Status Bar and "Connected" will appear under the selected network. To set up Wi-Fi, use the "Polario Settings" widget on the Home screen.

### Downloading apps

**Downloading an App Store:** 1. After successfully connecting the tablet to Wi-Fi, select "Download App Store" on the Polario Settings widget. 2. Select an app store, and follow the instructions to download and install it on the tablet. 3. Click here. 4. Select the downloaded app store (apk file) from the Pop-up window. 5. Select "Install" to install the app. 6. The app store appears on the Apps screen.

**Downloading and installing apps:** After downloading the selected app store, it is possible to download and install apps directly to the tablet - these apps will appear on the Apps screen. Note: Apps compatibility / games: There are many apps available on the various app stores, but unfortunately not all will be compatible with the tablet. This is because some of the apps are designed for mobile phones and require functions or specifications that are not supported by the tablet. Avoid apps that require rear cameras or GPS as these apps will not be supported by the tablet. The tablet supports many games apps - however we recommend always testing the free version (if available) before purchasing. Note: Polario and the manufacturer of this tablet are not affiliated with, connected to or sponsored by Amazon or the Amazon app store.

### Camera and video chat

**Front & rear camera:** Select **Camera** on the apps screen to go to camera mode. It is possible to take pictures or videos with the built-in, front or rear facing camera. **Share pictures with Bluetooth, Facebook or Twitter:** To utilize the feature you must have a Facebook or Twitter account and be logged in.

**Video chat:** Use the built-in, front-facing camera to video chat with friends and family. There are many different services that offer video chat, which are available on the app stores.

**Browsing files:** File Manager: To view, open, copy or delete files on the internal memory of the tablet or inserted Micro SD card, select "File Manager" on the Apps screen. To conserve Internal Memory! Transfer media files to "Removable Disk" (Micro SD card).

**Settings:** Select and customize the options in "Settings" to increase battery performance, manage applications, manage Wi-Fi, change display options, set passwords and more.

**Online help:** Select "Online Help" on the Apps screen to access:  
- App stores  
- Firmware updates  
- Technical support  
- Product registration

**Restore:** If the problem persists it may be necessary to restore the tablet to the factory default settings:  
1) Select "Settings" from the Apps screen.  
2) Select "Backup & reset".  
3) Select "Factory data reset".  
Note: This will erase data stored on the device so make sure to make up your data prior to using this option.

**Specifications:**  
- Operating System: Android 4.2 (Jelly Bean)  
- Processor: Dual Core Cortex A7\*2  
- Processor Speed: 1.5GHz  
- RAM: 1GB DDR3  
- Graphics: Dual-core Mali400MP2 GPU  
- Memory:  
- External Memory: Micro SD card slot  
- Display Resolution: 1024x600  
- Display: 10.1" capacitive multi-touch screen  
- 4 way auto rotation  
- Dual Cameras  
- Bluetooth  
- Network: Wi-Fi (802.11 b/g/n)  
\*Actual internal memory may vary depending on the operating system of the device and the pre-installed apps.

**Legal information:** FCC Part 15: This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Re-orient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.  
Do not attempt to repair or modify this equipment. Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
Shielded USB cables must be used with this unit to ensure compliance with the Class B FCC limits.  
Android is a trademark of Google or modified. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License.

**TV Out:** You can connect the tablet to an HD display with a Mini HDMI to HDMI cable (not included). To connect an HDMI cable: 1. Connect the Mini end of the HDMI cable to the "TV Out" port of the tablet. 2. Connect the other end of the HDMI cable to the "HDMI port" of the TV or Display. 3. The tablet display is now shown on your TV or Display.  
Note: Polario and the manufacturer of this tablet are not affiliated with, connected to or sponsored by Amazon or the Amazon app store.

**Some countries, states or provinces do not allow the restriction or limitation of incidental or consequential damages or allow limitations on warranties, so some limitations may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.**

**Polario, Polario & Pixel, Polario Color Spectrum and Polario Classic Border Logos are trademarks of PLR IP Holdings, LLC, used under license. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product. PLR IP Holdings, LLC does not manufacture this product or provide any Manufacturer's Warranty or support. © 2012 All Rights Reserved.**

