

2011 **ARMADA**

QUICK REFERENCE GUIDE





- 01** HEADLIGHT AND TURN SIGNAL CONTROL
- 02** INSTRUMENT BRIGHTNESS CONTROL*
- 03** VEHICLE INFORMATION DISPLAY*
- 04** LOW TIRE PRESSURE WARNING LIGHT
- 05** WINDSHIELD WIPER / WASHER SWITCH

- 06** STEERING WHEEL SWITCHES FOR AUDIO / BLUETOOTH*
- 07** CRUISE CONTROL
- 08** POWER LIFTGATE SWITCH
- 09** POWER VENT WINDOWS*
- 10** PEDAL POSITION ADJUSTMENT SWITCH*

- 11** REAR SONAR SYSTEM OFF SWITCH*
- 12** STEERING WHEEL TILT ADJUSTMENT*
- 13** HOOD RELEASE*
- 14** CONTROL PANEL DISPLAY*
- 15** AUDIO SYSTEM
- 16** AUTOMATIC CLIMATE CONTROLS

- 17** FRONT PASSENGER AIR BAG STATUS LIGHT*
- 18** AUXILIARY JACK*
- 19** TOW MODE SWITCH*
- 20** VEHICLE DYNAMIC CONTROL (VDC) OFF SWITCH*
- 21** HEATED SEAT SWITCH*

*See your Owner's Manual for more information.

ESSENTIAL INFORMATION

Loose Fuel Cap	2
Tire Pressure Monitoring System (TPMS)	2

FIRST DRIVE FEATURES

NISSAN Intelligent Key™ (if so equipped)	3
Power Seat Adjustments (if so equipped)	3
Outside Mirror Control Switch	3
Starting/Stopping the Engine (NISSAN Intelligent Key™ models only) . . .	4
Headlight Control Switch	4
Windshield Wiper Switch	4
Automatic Climate Controls	5
FM/AM/XM® Radio with CD Player (if so equipped)	6
Parking Brake	6
Power Liftgate Release (if so equipped)	7
Fuel-Filler Door	7

SYSTEM GUIDE

Cruise Control	8
Bluetooth® Hands-free Phone System (if so equipped)	8
Navigation System (if so equipped)	8
NISSAN Mobile Entertainment System (MES) (if so equipped)	9
HomeLink® Universal Transceiver (if so equipped)	9



- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.

For more information, refer to the **“Safety -- Seats, seat belts and supplemental restraint system (section 1)”** of your Owner’s Manual.



Additional information about your vehicle is also available in your Owner’s Manual, Navigation System Owner’s Manual, Electronic Quick Reference Guide (EQRG) and at www.nissanusa.com.



This easy-to-use Quick Reference Guide is intended to help you more fully appreciate some of the unique features and functions of your new vehicle. However, it is not intended to replace your Owner’s Manual. The Owner’s Manual contains more detailed information to help you better understand the important safety warnings, features, operation and maintenance of your vehicle. All information, specifications, photographs and illustrations in this publication are those in effect at the time of printing. NISSAN reserves the right to change specifications or design without notice and without obligation.

LOOSE FUEL CAP


- A LOOSE FUEL CAP warning message will display in the vehicle information display **01** when the fuel-filler cap is not tightened correctly.
- The warning message will disappear when the vehicle detects the fuel-filler cap is properly tightened and the reset button **02** is pressed.
- If the cap is not properly tightened the Malfunction Indicator Light SERVICE ENGINE SOON may illuminate.



For more information, refer to the “**Instruments and controls (section 2)**” and the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.

TIRE PRESSURE MONITORING SYSTEM (TPMS)

- A CHECK TIRE PRESSURE warning message will display in the vehicle information display **01** and the TPMS light will illuminate when one or more tires are low on pressure and air is needed.
- After tire pressures are adjusted, drive the vehicle at speeds above 16 MPH (25km/h) and the warning and indicator light will disappear.
- When the low tire pressure warning light flashes for approximately 1 minute and then remains on, the TPMS is not functioning properly. Have the system checked by a NISSAN dealer.
- Tire pressure rises and falls depending on the heat caused by the vehicle’s operation and the outside temperature. Low outside temperature can lower the temperature of the air inside the tire, which can cause a lower tire inflation pressure. This may cause the low tire pressure warning light to illuminate. If the warning light illuminates in low ambient temperature, check the tire pressure in all four tires.



For more information, refer to the “**Instruments and controls (section 2)**” and the “**Starting and driving (section 5)**” of your Owner’s Manual.


NISSAN INTELLIGENT KEY™ (if so equipped)

The NISSAN Intelligent Key™ System allows you to lock or unlock your vehicle, open your liftgate and start the engine.

- To lock or unlock a door, push any door handle request switch **01** once.
- Push any door handle request switch **01** within 30 seconds of unlocking the door and all other doors will unlock.

NOTE: It is important to make sure the Intelligent Key is with you (that is, in your pocket or purse).

For more information, refer to the “Pre-driving checks and adjustments (section 3)” of your Owner’s Manual.




POWER SEAT ADJUSTMENTS (if so equipped)

- Push the control switch **01** forward or backward to slide the seat forward or backward.
- Push the switch **02** forward or backward to adjust the angle of the seatback.

SEAT LIFTER (driver’s seat only)

- To adjust the angle and height of the seat cushion, push the front or rear end of the switch **01** up or down.

For more information, refer to the “Safety — Seats, seat belts and supplemental restraint system (section 1)” of your Owner’s Manual.




OUTSIDE MIRROR CONTROL SWITCH

- Turn the control switch **01** right or left to select the right or left side mirror.
- Move the control switch **01** up, down, right or left to adjust the mirror angle.

POWER FOLDING OUTSIDE MIRRORS (if so equipped)

- Push the switch **02** to open or close the mirrors.

For more information, refer to the “Pre-driving checks and adjustments (section 3)” of your Owner’s Manual.



first drive features

STARTING/STOPPING THE ENGINE (NISSAN Intelligent Key™ models only)

- Depress the brake pedal.
- Push the ignition switch in.
- Turn the ignition switch to the **START** position.

TURNING THE ENGINE OFF

- Move the shift lever to the P (PARK) position, apply the parking brake and turn the ignition switch to the **LOCK** position.


For more information, refer to the “**Starting and driving (section 5)**” of your Owner’s Manual.



HEADLIGHT CONTROL SWITCH

- Turn the headlight control switch **01** to the position to turn on the front parking, tail, license plate and instrument panel lights.
- Turn the switch **01** to the position to turn on the headlights.


For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.




WINDSHIELD WIPER SWITCH

- Move the lever to the following positions to operate the windshield wipers:

- 01** Intermittent (**INT**) – Operates the speed-sensitive front wiper system intermittently.
- 02** Low (**LO**) – Front wipers operate at a continuous low-speed.
- 03** High (**HI**) – Front wipers operate at a continuous high-speed.
- 04** Rear Wiper (**REAR**) – Twist the end of the lever to operate the first (**INT**) or second (**ON**) speed settings for the rear wiper.



For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.




AUTOMATIC CLIMATE CONTROLS


01 AUTO BUTTON/TEMPERATURE CONTROL KNOB

- Press the **AUTO** button to turn the system on and the fan speed, air flow distribution and temperature will be automatically maintained. Turn the driver's side temperature control knob left for cooler air or right for warmer air.


02 FAN SPEED CONTROL BUTTONS

- Press the fan speed control buttons to manually adjust the fan speed up  or down .

03 DEFROSTING/DEFOGGING FRONT AND SIDE WINDOWS

- Press the front window defroster button  to turn the system on or off.

04 REAR WINDOW AND OUTSIDE MIRROR (if so equipped) DEFROSTER SWITCH

- Push the rear window and outside mirror defroster switch  to turn the system on or off.

For more information, refer to the “**Instruments and controls (section 2)**” and the “**Monitor, climate, audio, phone and voice recognition systems (section 4)**” of your Owner's Manual.

first drive features



FM/AM/XM[®]* RADIO WITH CD PLAYER (if so equipped)

01 VOL/ON-OFF CONTROL KNOB

- Press the **VOL/ON-OFF** control knob to turn the system on or off.
- Turn the **VOL/ON-OFF** control knob to the right or left to increase or decrease the volume.

02 TUNE/FLDR/AUDIO KNOB

- To manually tune the radio, turn the **TUNE/FLDR/AUDIO** knob left or right.

*XM[®] Satellite Radio is only available on vehicles equipped with optional XM[®] satellite subscription service.

For more information, refer to the “**Monitor, climate, audio, phone and voice recognition systems (section 4)**” of your Owner’s Manual.


PARKING BRAKE

- To apply, firmly depress the parking brake pedal **01**.



- To release, firmly press the foot brake **02**, then press the parking brake pedal **01** and the parking brake will release.

For more information, refer to the “**Starting and driving (section 5)**” of your Owner’s Manual.



POWER LIFTGATE RELEASE (if so equipped)

When the liftgate is closed, the liftgate will fully open automatically by:

- Pushing the power liftgate switch **01** on the instrument panel.
- Pulling the power liftgate handle **02**, once the vehicle is unlocked.
- Pressing the rear liftgate release button **03** on the keyfob for more than 0.5 seconds.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



FUEL-FILLER DOOR

- The fuel-filler door is located on the left, rear side of the vehicle.
- To open the fuel-filler door, pull the lid open.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



CRUISE CONTROL

- The cruise control system enables you to set a constant cruising speed.
- The system will automatically maintain the set speed until you tap the brake pedal, accelerate, cancel or turn the system off.

For more information, refer to the **“Starting and driving (section 5)”** of your Owner’s Manual.



BLUETOOTH® HANDS-FREE PHONE SYSTEM (if so equipped)

- With an overhead microphone and sound transmitted through the audio system speakers, the Bluetooth® Hands-free Phone System utilizes Bluetooth wireless technology and voice recognition to provide hands-free cellular phone communication.

For more information, refer to the **“Monitor, climate, audio, phone and voice recognition systems (section 4)”** of your Owner’s Manual or please visit www.nissanusa.com/bluetooth.



NAVIGATION SYSTEM (if so equipped)

- Your Navigation System can calculate a route from the current location to a preferred destination. The real-time map display and turn-by-turn voice guidance will lead you along the route.
- The Navigation System will continually update your vehicle’s position. If you have deviated from the original route, it will recalculate the route from your current location.
- The Navigation System can also provide you with important data, such as; distance to empty, your tire pressure and maintenance interval reminders.

For more information, refer to your Navigation System Owner’s Manual.

NISSAN MOBILE ENTERTAINMENT SYSTEM (MES) (if so equipped)

- With this Entertainment System, you can play video files via a DVD or CD, providing images and sound from the front and rear display screens.
- You can also operate auxiliary devices such as video games, camcorders or portable video players through the auxiliary jacks.
- Use the remote controller provided with the system, to operate the rear display screen.
- Use the headphones, also provided with the system, to listen to audio wirelessly.



For more information, refer to the “**Monitor, climate, audio, phone and voice recognition systems (section 4)**” of your Owner’s Manual.



HOMELINK® UNIVERSAL TRANSCEIVER (if so equipped)

- The HomeLink® system can learn and consolidate the functions of up to three different hand-held transmitters, operating items such as; garage doors, property gates, outdoor and indoor lights or alarm systems.

For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual, the HomeLink® website www.homelink.com or call 1-800-355-3515.



Nissan, the Nissan Brand Symbol, "SHIFT_" tagline,
Z and Nissan model names are Nissan trademarks.
© 2010 Nissan North America, Inc.
QR1E TA60U0
Printing: July 2010 (19)

