

**Talking Picture Frame**  
motion-activated

Package Contents

**Picture Frame**

**User's Guide**

**Quick Start**

63-234  
Quick Start


See the User's Guide for complete instructions.

home


① Install 4 AAA batteries



② Frame a picture



③ Insert Bolts



④ Record a message

1. Slide **REC/LOCK** to **REC**. Hold the **MIC** about two inches from your mouth.
2. Hold down **REC**. The red indicator lights. Record for up to 10 seconds, then release **REC**.
3. Slide **REC/LOCK** back to **LOCK**.



⑤ Play message

