


## AGES 3+

07703/07I45 Asst.

Thank you for choosing this unique **Star Wars** Jedi Force™ brand product.



PLAYSKO

Includes 2 x 1.5V "A76" or LR44 size alkaline batteries (non-replaceable).


## **PLAY FEATURES**



There are all kinds of ways to have fun with the *Star Wars* Jedi Force™, the strongest and bravest group of galaxy guardians ever known! Here are a few play features and suggestions:


Yoda™ can hold lightsaber. Press the button on the bottom of Yoda's lightsaber to light it up!


## TO USE SWAMP STOMPER:



Press the button on top of the Swamp Stomper platform to make the legs move.

Place Yoda on top of Swamp Stomper. Turn Yoda's hands so that his thumbs are pointed downward. Yoda can then grip the handlebars to help keep him in place.





Gripper claw can hold Yoda's lightsaber while he's on the Swamp Stomper.



© 2004 Lucasfilm Ltd. & ® or TM where indicated. All rights reserved. Used under authorization. ®\* and/or TM\* & © 2004 Hasbro. All Rights Reserved. ® denotes Reg. U.S. Pat. & TM Office.



P/N 6463040000