




Outline Description




Fitting the battery


1. Slide the battery cover.










2. Insert the battery




3. Replace the battery cover and slide it up gently until hearing a click.



Accessory


RCA cable		VGA cable	
AC adaptor		Battery	
Carry pouch		Tripod	
Remote controller (Option)			

Key Pad



Function	Description
▲	Up/Luminance selection
▼	Down, CVBS mode/PC mode selection
◀	Left / Volume down
▶	Right / Volume up
MENU	Menu/Exit (Resume)


Remote Controller



Function	Description
Ⓜ	Suspend / Resume
🔇	Mute
▲	Normal mode : Luminance selection OSD mode : Up
▼	Normal mode : CVBS/PC input selection OSD mode : Down
◀	Left
▶	Right
MENU	Menu/Exit
📺	CVBS/PC input selection
AUTO	Using mode selection
+ VOL	Volume up
- VOL	Volume down

OSD (On Screen Display)


No source



Basic Functions


Function	Description
Input	Composite/PC
Luminance	0, 25, 50, 75, 100

PC - HV mode




Basic Functions

Function	Description
Input	Composite/PC
Luminance	0, 25, 50, 75, 100
Mode	User, Movie, P.P.T, Photo



Picture Setup


Function	Description
Brightness	0 - 100
Contrast	0 - 100
H Position	0 - 100
V Position	0 - 100



Color Turner

Function	Description
GAMMA	Mode 0 – Mode 15
R. Ratio	Total 250*
G. Ratio	
B. Ratio	


* The RGB parameter can be adjusted for personal preferred (the sum of RGB parameter is 250)



Utility


Function	Description
Sleep Timer	OFF, 30, 60, 90, 120, 150Min
Key LED Time	ON, 5, 10, 15, 20, 25, 30sec
Auto Adjust	Auto adjust display
Auto Color	Auto adjust color
Language	English/Traditional Chinese
Reset	Factory default
FW Version	Show the Firmware version

CVBS mode




Basic Functions

Function	Description
Input	Composite/PC
Luminance	0, 25, 50, 75, 100
Volume	0 - 100
Mode	User, Movie, P.P.T, Photo



Picture Setup


Function	Description
Contrast	0 - 100
Brightness	0 - 100
Saturation	0 - 100
Hue	0 - 100
Sharpness	0 - 100



Color Turner

Function	Description
GAMMA	Mode 0 – Mode 15
R. Ratio	Total 250*
G. Ratio	
B. Ratio	

* The RGB parameter can be adjusted for personal preferred (the sum of RGB parameter is 250)



Utility

Function	Description
Sleep Timer	OFF, 30, 60, 90, 120, 150Min
Key LED Time	ON, 5, 10, 15, 20, 25, 30sec
Language	English/Traditional Chinese
Reset	Factory reset
FW Version	Show the Firmware version