



Illustrated Parts List

Portable Generator
Model 030372




BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC
JEFFERSON, WISCONSIN, U.S.A.

Manual No. 204883A Revision - (01/11/2008)

Exploded Views and Parts Lists


EXPLODED VIEW - MAIN UNIT



Copyright © 2008 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.

Exploded Views and Parts Lists

CONTROL PANEL EXPLODED VIEW & PARTS LIST



Item	Part #	Description
1	203692GS	CONTROL PANEL (Includes decal)
2	*	NUT, Nylon
3	*	WASHER, M4 x 08
4	*	SCREW, M6 x 16
5	68759GS	OUTLET, 120/125V, 15/20a, Duplex
6	*	SCREW, Pan Head, M4x10
7	203527GS	CIRCUIT BREAKER, 15A
8	68867GS	OUTLET, 120/240V, 20a, Locking
9	*	SCREW, M3 x 06
10	*	LOCK WASHER


Parts Not Illustrated

205615GS DECAL, Control Panel

* - Items without part numbers are common fasteners and are available at your local hardware store.

Exploded Views and Parts Lists

WHEEL KIT EXPLODED VIEW & PARTS LIST



Item	Part #	Description
1	204780GS	KIT, Handle
2	204778GS	KIT, Pad Vibration Mount
3	204779GS	KIT, Wheel
4	204548GS	Axle