




**Quick Start** 

# CREATIVE

Copyright © 1998-2004 Creative Technology Ltd. All rights reserved. All other brand and product names listed are trademarks or registered trademarks of their respective holders and are hereby recognized as such.

## **FM Wired Remote - Special Features**



#### Turning the player on or off

- 1. Press and hold ►II/□N to turn the player on.
- 2. Press and hold ( DFF ) to turn the player off.


Press to enable or disable FM mode.

#### Presetting radio stations automatically in FM mode

- 1. Press **FM preset** + ( ►II /□N ) or **FM preset** ( □FF ) to choose a channel for saving a radio station in.
- 2. Press and hold ▶▶I to scan up or I◀◀ to scan down for radio stations. Scanning stops when a station is detected. Press ▶▶I or I◄◄ to fine tune at
- 3. Press BAVE to save the radio station as a preset channel.

#### Searching forwards / backwards for a preset channel in FM mode

- 1. Press **FM preset** + ( ▶II/□ N ) to go to the next preset channel.
- 2. Press **FM Preset** ( □ FF ) to go to the previous preset channel.





Next FM Preset

Turn On player

Previous Track


• Turn Off player

Scan Down

Fine Tune Down

• Previous FM Preset

- Fine Tune Up
- Scan Up



#### **Product Registration**

Enjoy a host of benefits by registering your product during installation, or at www.creative.com/register. Benefits include:

- Service and Product Support from Creative
- Exclusive updates on promotions and events

### **Creative Knowledge Base**

Resolve and troubleshoot technical queries at Creative's 24-hour self-help Knowledge Base.

Go to www.creative.com and select your region.

#### **Warranty & Customer Support Services**

For terms and conditions, warranty and other service details, visit our website and online store at www.creative.com.

Keep this document for future reference.

### **Proper Handling**











**WARNING:** Handling the cord(s) on this product may expose you to lead, a chemical known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.



- Creative Product
- Produit Creative
- Prodotto Creative Creative-Produkt
- Producto Creative
- Creative Product
- Creative Produkt
- Creative tuote
- Creative Produkt
- Creative produkt
- Creative produkt
- Vyrobek firmy Creative Produto Creative
- Creative продукт
- Dealer Stamp
- · Cachet revendeur
- Timbro del rivenditore
- Händlerstempel
- · Sello distribuidor Dealer stempel
- Forhandler stempel
- Jälleenmyyjä leima
- Återförsäljare stämpel
- Forhandler stempel Pieczátka dilera
- · Razitko prodejce
- · Carimbo do Agente • Печать дилера
- Purchase Date
- Date d'achat · Data di acquisto
- Kaufdatum
- Fecha de compra
- Aankoopdatum
- Kiøbsdato
- Ostopäivä Inköpsdatum
- Købsdato Data zakupu
- Datum koupy
- Data de compra • Покупное число
- · Name and Address of Customer • Nom et adresse du client
- · Nome e indirizzo del cliente
- · Name & Anschrift des Käufers
- · Nombre & dirección del cliente
- Naam & adres van de klant
- Kundens navn & adress
- · Asiakkaan nimi & osoite Kundens namm & adress
- Kundens navn & adresse
- Imië, nazwisko klienta
- Meno a adresa zakaznika
- · Nome e morada do comprado
- Фамилия и адрес покупателя