# Maintenance Quick Reference

You must perform certain maintenance procedures for your printer to function properly:

- Clean the printhead
- Clean the peel bar

## **Cleaning the Printhead**

Follow these instructions to clean the printhead.

Clean the printhead every time you load a new roll of paper labels into the printer.

- 1. Turn the printer off (O).
- 2. Press the cover release buttons (on both sides of the printer) towards the front of the printer. Lift open the cover.
- 3. Gently rub the cleaning pen (#114226) across the printhead.

- Clean the platen roller
- Clean the outside of the printer.



## **Cleaning the Peel Bar**



Follow these instructions to clean the peel bar.

Clean the peel bar every time you load a new roll of paper supply into the printer.

- 1. Turn the printer off (O).
- 2. Press the cover release buttons (on both sides of the printer) towards the front of the printer. Lift open the cover.
- 3. Gently rub the cleaning pen (#114226) across the peel bar.

#### IF YOU NEED HELP OR MORE PAPER LABELS, PLEASE CALL 1-888-666-9414.

## **Cleaning the Platen Roller**



Follow these instructions to clean the platen roller

Clean the platen roller every time you load a new roll of paper labels into the printer.

- 1. Turn the printer off (O).
- 2. Press the cover release buttons (on both sides of the printer) towards the front of the printer. Lift open the cover.
- 3. Gently rub the cleaning pen (#114226) across the platen roller.

## **Cleaning the Outside of the Printer**

Follow these instructions to clean the outside of the printer.

Clean the **outside** of the printer when you see grease build up.

- 1. Turn the printer off (O).
- 2. Dampen a soft cloth with water and gently clean the **outside** of the printer.



#### Caution

Do not clean the inside of the printer with a damp cloth.

Do not clean while the printer is on.



## Setting the Date/Time/Hot Hold Time

Scan the following barcodes to set the Date, Time, or Hot Hold Time.



Time

Hot Hold Time

Dry Hot Time













If you need to change the date or time use the top row buttons on the bump pad.

	Cheese	Supreme	Pepperoni	Meat Lovers®
Date	month	day	adds a year	subtracts a year
Time	hours	minutes	am/pm	