

Classic Dollhouse

Instructions




B2089



B2090


Please keep this instruction sheet for future reference, as it contains important information. Adult assembly is required. Discover what's possible"...www.fisher-price.com No tools needed for assembly.

Let's Decorate!




- Make sure the areas where the labels will be applied are clean and dry.
- Apply the labels as indicated in the illustration.
- For best adhesion, avoid repositioning a label once it has been applied.

Open House!




- Rotate the side walls out to open.
- · Pull down the main floor.
- Lower the staircase.

Swing Attachment



- · Locate the columns inside the house.
- · Rest the bar on the swing behind the tabs between the columns.

Playtime's Over



- Place the family and their accessories inside the house or on the third floor.
- · Lift the staircase.
- · Lift the main floor.
- · Rotate the side walls in to close.

Consumer Information

Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-5437**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

For countries outside the United States:

CANADA

Questions? 1-800-567-7724. Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2. GREAT BRITAIN

Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500302.

ALICTRALIA

Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

NEW ZEALAND

16-18 William Pickering Drive, Albany 1331, Auckland.

ASIA

Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.