

[HTTP://WWW.PYLEAUDIO.COM](http://www.pyleaudio.com)

PYLE[®]
view


TV TUNER SYSTEM

PLTK120

OWNER'S MANUAL

Changing the battery in the remote

1. The remote's battery is held in a small drawer on one edge of the remote. To open this drawer, press and hold the small button on the edge of this drawer (as show below) and slide the drawer out.
2. Insert a new battery and push the drawer back into the remote.



Specifications

Signal System	NTSC
Audio/Video Outputs	Audio R/L×1, Video×1
TV Channel	Channels 2-81
Tuner Box, Overall Dimensions	(L)5.6×(W)3.6×(H)1.2 inch
Tuner Box, Weight	0.31Kg

CONTENTS

Thank you for your purchase.

Please read this User Manual in detail and use the set properly.

Precautions	3
System features and controls	4
Installation and electrical connections	5
Remote Function	7
Selecting the input mode	7
Programming channels for TV	7
Selecting channels and adjusting the sound	8
Providing A/V audio to your car radio	8
Changing the remote battery	9
Specifications	9


Precautions

Please read this manual completely and carefully before installing the equipment.

1. Do not operate this equipment while driving, safe driving should always be your highest priority.
2. Do not install these components in an area exposed to rain, moisture, direct sunlight, extreme heat or cold, excessive dust, dirt or humidity.
3. Immediately unplug the power cord and send the TV Tuner to your local dealer or service center as soon as possible:
 - a) If there is smoke or any peculiar odor present during use.
 - b) If there is damage to any of the component casings.
4. To avoid damage and risk of electronic shock, protect this equipment from getting humid or wet, If this does occur, unplug the power cord immediately and send the unit to your local dealer or service center as soon as possible.
5. Do not attempt to repair, open or disassemble any of the components. Dangerous high voltage is present and may cause an electric shock.
6. Use only a power source with 12 Volts DC (negative ground).
7. Do not place objects on or suspend objects from the power cord, as this may damage the cord.
8. Do not twist or place the power cord near any source of heat in the vehicle.
9. Do not attempt to repair a damaged, broken or defective power cord. Replace it with a new one immediately.

Selecting channels and adjusting the sound

Use the CH+ and CH- buttons to select channels.
Use the VOL+ and VOL- buttons to increase or decrease audio volume.
You will see a Volume Bar on screen indicating relative volume level.
To disable the audio output, press the MUTE button. To cancel the muting function, press MUTE button again.




Please note: VOL+, VOL- and MUTE buttons are disabled in AV mode.

Providing A/V audio to your car radio

If your radio has AUX line-level inputs, you can attach the A/V audio output connectors to these inputs with RCA-RCA interconnect cables.

Remote function

1. POWER: Power on/off
2. MENU: In AV mode push the MENU button to access on screen menu. Use CH- or CH+ button to move on screen point to next or previous command item. And use VOL+ or VOL- button to increase or decrease current option value. In TV mode MENU is invalidated.




Selecting the input mode

Tuner can switch between three different video sources using the remote control. These modes are:

TV Mode: for receiving TV Channels.


AV1: external audio and video inputs for DVD, VCD or video game.

AV2: external audio and video inputs for DVD, VCD or video game.



Programming channels for TV


The tuner system can memorize channels in both TV modes. Press the AUTO button on the remote, the tuner will begin scanning all of the available channels and put them into memory.




7

SYSTEM FEATURES AND CONTROLS

TUNER BOX



REMOTE CONTROL



4

Installation and Electrical Connections

1. Find a suitable location for the tuner unit and mount it securely in place. Be sure to place it in an area away from moisture and dirt, and where incoming cables will not be walked on or pulled accidentally.
2. Make all required audio, video and power connections to the appropriate connectors on the tuner as indicated in the drawing below to suit your system installation. Install the infrared remote eye in a location you know will be available in line-of-sight with the remote control use location.

Please note that the following drawing describes connections for all system possibilities and your particular system may vary from this.

Connection

