





PC2011 ELECTRIC AIR COMPRESSOR


Parts Reference Guide



PDAC015-121297-DUBS

PC2011 ELECTRIC AIR COMPRESSOR Parts Reference Guide





SENCO PC2011 ELECTRIC AIR COMPRESSOR

REPLACEMENT PARTS LIST

Part No.	Description
020089	MOTOR
030172	PUMP
070151	GRIPS
090045	CORD RELIEF
100083	FLYWHEEL
100089	PULLEY
100090	FLYWHEEL
110039	BELT
140068	WHEEL
140069	ISOLATOR
150175	HOSE
190078	FILTER
190080	FILTER
200314	SPACER
200420	AXLE
200421	BRACKET
200425	PLATE
200436	BRACKET
220228	VALVE
220231	REGULATOR
220232	SWITCH
220257	GAUGE
220258	VALVE
220263	PLATE
230069	HOSE BARB
230123	HOSE BARB
230309	TEE
230312	VALVE
230341	ADAPTER
240010	NIPPLE
260204	GASKET
260205	SEAL
270015	BOLT
270067	BOLT
270068	BOLT
270121	BOLT
270576	BOLT
278002	BOLT
278032	BOLT
278033	BOLT
278803	BOLT
278909	BOLT
278910	BOLT
278910	BOLT
278917	SCREW
278918	BOLT
279524	BOLT
280002	WASHER
280003	WASHER
280022	WASHER
280023	WASHER
280210	WASHER
281032	WASHER
300155	LOCKNUT
300157	LOCKNUT
300159	LOCKNUT
303023	HEX NUT
320003	TERMINAL
320444	CORD PLUG SET
320445	CORD
330264	WIRE CLIPS
340575	LABEL
340815	LABEL
340817	LABEL
340819	LABEL
340822	LABEL
340823	LABEL
340842	LABEL
390101	PLUG
420004	CLAMP
430073	KEY
430092	PIN
460780	HEAD
460781	CYLINDER
460782	DIPSTICK
460783	CAP
460784	CAP
480060	BEARING
620109	AIR CONVEYOR
700220	RING SET
854011	BELTGUARD BACK
854013	TUBE
854014	TUBE
854015	AIR TANK
854016	BELTGUARD