




# COOKTOP PARTS

For Models: RS696PXGB12, RS696PXGQ12  
(Black) (Designer White)

30" ELECTRIC  
DROP-IN RANGE  
SELF CLEANING  
OVEN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP PARTS

For Models:RS696PXGB12, RS696PXGQ12  
(Black) (Designer White)


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		Literature Parts
	LIT8300770	Installation Instructions
	LIT8300666	Use & Care Guide
	LIT8302073	Tech Sheet
	LIT3191638	Safe Cooking Tips
2		Cooktop, Glass
	3191843	Black
	3191189	White
3	3191310	Bracket, Switch Mounting
4		Element, Surface
	8523698	1200W RF-LR
	8523696	1800W RR
	8523692	2500W LF
5	3191791	Spring, Locator
	246119	Screw (8)
7		Switch, Infinite
	3191049	1200W RR-LR (Silver Shaft)
	3191050	1800W RR (Yellow Shaft)
	4454541	2500W LF (Red Shaft)
	311865	Screw
8	3183956	Seal, Switch Cover
10		Knob, Control (4)
	3196231	Black
	3196232	White
14	8285469	Seal, Switch
15	3191515	Bracket, Support Element
16		Trim Ring, Cooktop
	3193228	Black
	3193227	White
	3196537	Screw
17	3192452	Frame, Cooktop
21	3191952	Lamp, Indicator
	3191953	Bumper, Rubber
	9750835	Bumper, Door

# OVEN PARTS

For Models: RS696PXGB12, RS696PXGQ12  
(Black) (Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# OVEN PARTS

For Models: RS696PXGB12, RS696PXGQ12  
(Black) (Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			10	4452165	Lens, Light	29	4455636	Sensor
			11	4452368	Oven Light Assy		4449154	Screw
			12	4452166	Bulb, Light	37	4451442	Thermostat (TOD) (Temp.) SPST
1		Trim, Side (Right Hand)	14	4455612	Frame, Front	43	4455530	Base, Chassis
	4450844	Black Model		4449040	Screw	49	4448933	Retainer, Gasket
	4450845	White Model (Left Hand)	15	4455382	Gasket, Door		4449154	Screw
	4450847	Black Model	19	4451478	Support, Insulation	50	4451747	Cover, Back
	8281236	Screw		4449809	Screw		4449809	Screw
	4450848	White Model Screw	21		Rail, Side	53	4449845	Support, Bracket
3		Hinge Receiver		4450579	Right Side		4449809	Screw
	4455605	Left Hand		4450580	Left Side	55		Trim, Bottom
	4455606	Right Hand		4448444	Grommet		4448477	Black Model
4	4448520	Bumper, Door		4449154	Screw		4448478	White Model
7	4455865	Top Chassis	22	8302157	Latch, Motorized	<b>FOLLOWING PARTS NOT ILLUSTRATED</b>		
	4449809	Screw	25	4455641	Side, Chassis (R.H. & L.H.)	<b>INSULATION</b>		
9	4452158	Tube, Vent		4449809	Screw		4449316	Insulation, Wrap
	3196176	Screw	26	4452234	Back, Chassis		4450365	Insulation, Back
				4449809	Screw			
			27		Liner, Oven (Not serviceable)			

# CONTROL PANEL PARTS

For Models: RS696PXGB12, RS696PXGQ12  
(Black) (Designer White)



<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
-------------------	-----------------	--------------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		Control Panel Assy. W/Membrane Switch
	4456312	Black Model
	4456311	White Model
	4449745	Screw
	3400832	Screw
2	4451034	Gasket, Control Panel
3	8301919	Assy, Control
	4449745	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN DOOR PARTS

For Models: RS696PXGB12, RS696PXGQ12  
(Black) (Designer White)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			4	4451722	Insulation, Door	19	4450362	Shield, Heat
1	4455618	Door Liner	7	4449263	Glass, Inner	4449809		Screw
2	8300571	R.Side Hinge, Door	9	4450470	Retainer, Glass	20	8300778	Retainer, Glass
	8300572	L.Side		4449809	Screw	4449809		Screw
	4449743	Screw	13	4448854	Door Handle	21	8300820	Seal, Door Top
3	4449259	Glass, Inner		4448855	Black Model	23		Retainer, Clip
			14	4450813	Bracket, Handle		4450863	Black Model
				4451040	Screw		4450864	White Model
			15		Assy, Door Glass	24	3400832	Screw
				8300903	Black Model		8300974	Glass, Inner
				8300899	White Model			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models: RS696PXGB12, RS696PXGQ12  
(Black) (Designer White)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw
2	4455178	Elbow, Vent-Top
3	4455334	Blower
	4455352	Bracket

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

4	4451758	Block, Foam
5	4455177	Elbow, Vent-Bottom
11	4449868	Block, Terminal
	3400080	Screw
13	4448549	Vent, (Control Panel)
	4450038	Screw


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

14		Side, Control Compt.
	4451535	Right
	4451536	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
19	4451985	Suppressor
20	3191842	Cover, Rear
21	4451407	Plate, Support
	4452260	Spacer, Foam

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Models: RS696PXGB12, RS696PXGQ12  
(Black) (Designer White)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

2	4456103	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# OPTIONAL PARTS

For Models:RS696PXGB12, RS696PXGQ12  
(Black) (Designer White)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**PAINT, TOUCH-UP (1/2oz.)**

	72017	White
	261869	Cord Brown
	72032	Black

**PAINT, SPRAY**

	350930	White
	261900	Citrine White
	830864	Black

**ADHESIVE**

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**SPLICING WIRES--25FT.**

**LENGTH**

	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**WIRING HARNESS PARTS**

	8301876	Harness, Wire (Main)
	3191956	Harness, Wire (Infinite Switch)
	4455280	Harness, Wire (Burners)
	4451163	Conduit
	4448664	Clamp
	4449809	Screw 112432 Nut
	4450800	Screw, Ground
	4451761	Support, Wiring
	4454842	Tie, Cable
	4452222	Spacer, Harness

**Miscellaneous**

	814381	Pin Hinge Kit
	4448950	Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST