# INSTALLATION & OPERATING INSTRUCTIONS

for

# PIZZA DISPENSING CABINET PDC-2418, PDC-4818, PDC-4826



PDC-2418 shown



THIS MANUAL CONTAINS IMPORTANT SAFETY AND INSTALLATION-OPERATION INSTRUCTIONS. REQUIRE ALL OPERATORS TO READ THIS MANUAL BEFORE USING THE UNIT. FAILURE TO FOLLOW THE INSTRUCTIONS CONTAINED IN THIS MANUAL MAY CAUSE INJURY AND/OR DAMAGE TO THE UNIT AND WILL VOID THE WARRANTY.

THIS MANUAL SHOULD BE RETAINED FOR FUTURE USE





PDCopsmanual P/N: 001210 REV: 1/17/07


#### PRODUCT DESCRIPTION


Merco Pizza Dispensing Cabinets are the perfect choice for self-service situations. They are manufactured from heavy-duty aluminum alloys specifically selected for even heat transfer and easy cleaning. All models feature a spacious 3-level configuration and are available in three different sizes to meet any capacity requirement. A forward-slanted design keeps pizza boxes to the front where a stop bar allows easy access to lift the pizza box out. Insulated heat cable base heating with factory-set thermostatic control on each level is ideal for holding boxed pizza at peak flavor without continued cooking. Each level has bright incandescent illumination to enhance product display. Glass panels on each end contain warmth where you want it. A 6-foot cordset is provided for easy installation.

#### **DIMENSIONS**

(inches/cm)

	PDC-2418	PDC-4818	PDC-4826
Α	24/61	48/122	48/122
В	18/45.7	18/45.7	26/66
С	30/76.2	41.6/105.7	30/76.2





#### **SPECIFICATIONS**

(Standard Models)

MODEL	120	VOLTAGE/AMPS 120/208	120/240	WATTS	NET WT.* lbs/kg	SHIP WT.* lbs/kg	SHIP VOL.* cu ft/cu m
PDC-2418	8.8	-	-	1060	60/27.2	115/52.2	7.5/0.21
PDC-4818	14.9	-	-	1785	120/54.5	190/86.3	15/0.42
PDC-4826	14.8	-	=	1780	135/61.3	205/93.1	21.7/0.61

#### **INSTALLATION**

- 1. Check the specification data plate located on the bottom or right hand corner for the model number, voltage, and wattage.
- 2. Insure the electrical circuit used to supply electricity to the unit has the same voltage rating as indicated on the data plate and sufficient amperage rating.
- 3. Be sure to match the receptacle to the plug on the unit.
- 4. Plug cordset into outlet.

#### **OPERATION**

- 1. Make sure the unit is plugged into appropriate outlet.
- 2. Flip the On/Off Toggle Switch to the "ON" position. The terminal cables will be activated and the lights will illuminate indicating the heat is on.

#### **CLEANING**

1. Aluminum and Stainless Steel – Perform daily cleaning using only a mild non-abrasive cleanser, applied with a soft cloth or sponge.



DISCONNECT POWER WHEN REPLACING OR SERVICING THERMAL CABLES AND LAMPS!

PDC Operations Manual 3

### Merco Savory, LLC Limited Warranty

Merco equipment is guaranteed to be free from quality problems in material and workmanship for a period of ninety (90) days on labor and one (1) year on parts (excluding appliance lamps and heat tubes) from installation or purchase date.

Savory equipment is guaranteed to be free from quality problems in material and workmanship for a period of one (1) year parts and labor from date of purchase, or eighteen (18) months from date of shipment from factory, whichever comes first.

#### Warranty beyond standard as follows:

Heat Tubes: One (1) year against burnout (not breakage) from date of purchase of equipment. Hot Food Server: One (1) year labor, two (2) year parts.

## **Travel and Mileage**

Savory equipment: Travel expenses limited to fifty (50) miles total.

Merco equipment: Labor warranty includes travel time not to exceed two (2) hours and/or mileage not to exceed one hundred (100) miles. Portable equipment – equipment weighing less than ninety (90) pounds must be delivered to the service agency at the owners expense.

Merco Savory, LLC obligation under this warranty shall be to repair or replace, at its option, any part or unit which proves to be non-conforming due to quality problems in material or workmanship during the warranty period. However, we make no warranty, express or implied, of cooking effect or of exact capacity as subjective judgements and product variations may alter evaluation of equipment performance. Warranty service must be provided by an authorized service agency. Shipping damage is not covered by the manufacturer's warranty.

This warranty is limited and supersedes all other warranties, express or implied. Merco Savory, LLC neither assumes nor authorizes any person to assume for Merco Savory, LLC, any other obligation or liability in connection with Merco or Savory equipment. Neither Merco Savory, LLC nor its employees or agents shall be held liable for any claims for personal injuries or consequential damage or loss, howsoever caused.



Merco Savory, LLC 1111 North Hadley Road Fort Wayne, Indiana 46804 United States of America

Telephone: (260) 459-8200
U.S. Fax: (888) 790-8193 • Int'l Fax: (260) 436-0735
Service Hotline: (800) 678-9511

4 PDC Operations Manual