Tanaka^{*}


Parts Catalog


Backpack Brushcutter

Model: SUM-321

All Units Prior To Serial Number H 219030

FIG.1 ENGINE







REF. HER PARTER	A sk	SERIA NER REMARKS
REF. NP PARTIER	SPARK PLUG CAP ASS'Y	5 5 5 661 REP. REM.
1-001 157-01570-900	SPARK PLUG CAP ASS'Y SPARK PLUG RUBBER COVER	1 P F153662-
1-003 018-02233-200	SPARK PLUG BH-7A SPARK PLUG CJ6	1 I -F113450 1 F113451-
1-004,1 002-01365-202		1 R -E176955
	CYLINDER COMP.	1 R -F113450 1 -F153661 1 N -G195227
	CYLINDER COMP.	1 N G195228-
1-006 992-10050-012		4
1-007 017-01300-210 1-008 041-01000-201 1-009 031-01400-204		
1-010 037-01400-200		
1-012,1 046-01360-821	CRANK SHAFT COMP.	1 -F153661
1-013 999-62091-325	CRANK SHAFT COMP. NEEDLE BEARING F-910	1 N F153662-
1-017 990-11050-121		
1-018 992-10050-012 1-019 992-01050-011		
1-020 990-11050-181 1-021 992-10050-012		
1-022 992-01050-011 1-023 990-11040-121	SCREW 4X12	
1-024 992-10040-012 1-025 992-01040-011		2 2 2 2
1-026 102-01300-200 1-031 072-01370-901	INSULATOR CRANK CASE ASS'Y	1 -G025900
1-032 999-61620-200	CRANK CASE ASS'Y BALL BEARING #6202, 35MM/OD	1 G025901-
	OIL SEAL 15257 BALL BEARING #6002. 32NN/OD	
	OIL SEAL 12227 CRANK CASE GASKET	
1-037 071-02007-200	CRANK SHAFT SHIN 0.05 CRANK SHAFT SHIN 0.10	v .
	CRANK SHAFT SHIM 0.15 CRANK SHAFT SHIM 0.20	\v \ \v \ \ \v \ \ \ \ \ \ \ \ \ \ \ \
	CRANK SHAFT SHIM 0.30	
1-039 068-00300-200	WOOD-RUFF KEY 3X13X4.5 WOOD-RUFF KEY 3X10X3.7 PRIMARY CORD GROWNET	1 D F153662-
1-041 990-11050-251 1-042 992-10050-012	SCREW 5X25	4
1-043 100-00100-201	STUD BOLT 5X21	4 5153000
1-046 100-01300-201	RECOIL STARTER GASKET A STUD BOLT 6X69 STUD BOLT 6X69	1 D F153662- 2 I -G025900 2 G025901-
	STUD BOLT 6X69	2 G025901- 2 D G195228- 2 R -F113450
1-047.1 100-00100-201	STUD BOLT 5X21	2 -F153661
1-050 159-21401-872	STUD BOLT 5X26 IGNITOR COMP. TTI-1F	2 N F153662- 1 D G056541-
1-051 173-06400-800	IGNITOR LEAD WIRE COMP., B75M IGNITOR LEAD WIRE COMP., R73M IGNITOR LEAD WIRE COMP., R73M	1 -F113450 1 N F113451- 1 D G056541-
1-052 990-11040-081	SCREW 4X8	1 D G056541-
1-053 992-10040-012 1-055.1 112-01360-212		1 D G056541- 1 -F113450
- To be cont'd -		

		, , , , , , , , , , , , , , , , , , ,
REF. NER PARNER	PARTHAME	SERVATHER REMARKS
1-055 1-056 1-057 1-057 1-057 1-057 1-057 112-01360-220 990-11050-181 992-10050-012	FAN CASE SCREW 5X18	1 N F113451-
1-060 1-061 1-062,1 1-062,1 1-062 1-066,1 1-066,1 1-066,2 1-066,2	GROWMET STOP CORD COMP. STOP CORD COMP. IGNITION COIL COMP.	1
1-066 167-21951-800 1-067,1 990-11040-181	SCREW 4X22/WS S.WASHER 4	1 N -H066976 1 P H066977- 2 H F113450 2 N F113451- 2 D F113451-
1-072 1-076,1 065-00000-200 1-076 359-10112-203	WASHER 8 HAGNETO ROTOR COMP. MAGNETO ROTOR COMP. FLYWHEEL WASHER CLUTCH WASHER B STARTER PULLEY	1
1-078 993-55005-000	STARTER PAUL SPRING STARTER PAUL FLYWHEEL NUT	1 N F153682- 1 N F153662- 1 N F153662- 1 N F153662- 1 F153661 1 N F153662-
1-082 274-0136U-800	EARTH CORD COMP.	1 N H206491-


FIG.2 ENGINE COMPONENTS






REF	NER PARNER	PARTIAME	SERVANDER REMARKS
2-001 2-002 2-003 2-004 2-006 2-006	738-01365-801 990-11040-101 992-10040-012 992-01040-011	NUFFLER PROTECTOR COMP. SCREW 4X10 S. WASHER 4 WASHER 4 NUFFLER ASS'Y	1 2 2 2 1 1 -H162320 H162321-
2-007.1 2-007 2-008 2-008 2-009 2-010	990-53060-603 992-01060-061 992-01060-011	HEX. HOLE BUTTON SCREW 6X60 WASHER 6 WASHER 6 TAIL PIPE COMP.	2 G195227 2 N G195228- 2 H 1 1
2-011 2-012 2-016 2-017 2-018 2-019	403-01300-200 138-0136U-200 403-00001-200	NUFFLER GASKET INLET MANIFOLD GASKET	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
2-019 2-020 2-020 2-020 2-021 2-021	991-74050-010 991-01050-013 991-74050-010	NUT 5 U-NUT 5 SMALL VASHER 5	1 F153662- -F113450 2 N -F153661 2 N F153662- 2 F113450 N F113451-
2-022 2-023,1 2-023 2-024.1	887-33344-800 888-33340-200 888-04030-200 886-33340-800	THROTTLE VIRE B COMP. THROTTLE VIRE B COMP. CONNECTOR CASE CONNECTOR CASE THROTTLE VIRE A COMP. THROTTLE VIRE COMP.	1
2-024 2-027 2-028 2-028 2-029 2-035	992-00040-011 990-11040-121 990-11040-141 992-10040-012	SCREW 4X14	1 N H206491- 3 N G004351- -G004350 G004351- 3 2
2-036 2-037 2-038 2-039 2-041 2-041	358-10112-200 357-0136U-200 342-0136U-200 717-0136S-800	CLUTCH SHOE COMP. CLUTCH WASHER A CLUTCH STEP BOLT CLUTCH SPRING MUFFLER BODY B COMP. MUFFLER BODY B COMP.	2 2 2 1 1 1 -H162320 H162321-
2-042 2-042 2-043 2-044	740-0136G-200 739-01320-201	HUFFLER COLLAR MUFFLER COLLAR MUFFLER GASKET MUFFLER PARTITION COMP.	2 R -H162320 H162321-


FIG.3 RECOIL STARTER






		/// 6
REF NER PARNER	PARTIANE	SERVE REPARKS
3-000,1 /62-01250-900	RECOIL STARTER BODY ASS'Y RECOIL STARTER BODY ASS'Y RECOIL STARTER BODY RECOIL SPRING STARTER ROPE REEL	1 F153661 F153662 - 1 1 1 1 1 1 1 1 1 1
3-005,1 3-006,1 837-01250-200 3-007,1 990-15050-121 3-008,1 3-008,1 3-009,1 783-01250-200	FRICTION PLATE SCREW 5X12 FRICTION SPRING FRICTION SPRING	1 1 1 1 1 1 1
3-002 779-0136U-200	STARTER HANDLE	1 M 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
3-005 990-15050-126 3-006 783-0136U-200 3-007 782-06097-200 3-008 785-01820-200	ROPE	1 1 1 1 1 1 1
	!	


FIG.4 AIR CLEANER



	. NER PARTER	PARMAME	SEP SEP	IN WER REMARKS
4-000 4-001 4-002 4-003 4-004	990-11040-251 S	LEANER BODY LEANER ELEMENT LEANER FIXING BASE CREW 4X25	1 1 1 1 2	
4-005	992-10040-012 S 992-00040-011 S		2 2	


FIG.5 CARBURETOR






	JER		///
REF	NER PARTER	PARMANE	ST SERINHER REMARKS
5-000,1 5-000 5-000 5-000 5-001,1	455-22916-900 455-20444-900 455-20444-900 455-20444-901 560-22904-200	CARBURETOR ASS'Y CARBURETOR ASS'Y CARBURETOR ASS'Y CARBURETOR ASS'Y	1 N -F113450 1 N -F173300 1 R -F173300 F173301- 1
5-004.1 5-005.1 5-006.1 5-007.1	619-22912-200 592-2043K-930 593-22904-200	BODY CAP THROTTLE VALVE SPRING THROTTLE SPRING RECEIVER JET NEEDLE ASS'Y 011344 JET NEEDLE CLIP THROTTLE VALVE 1.0X1.1	
5-010.1 5-011.1 5-012.1 5-013.1	570-22903-200 561-22900-900	ADJUSTER SPRING GASKET BODY BAND ASS'Y NEEDLE VALVE COMP.	
5-016,1 5-017,1 5-018,1 5-019,1	628-22900-200 990-11040-061 607-22900-200 599-2002K-550 604-22903-200 606-22900-200	SCREV 4X6 CHAMBER GASKET MAIN JET #55 FLOAT	
5-021,1 5-022,1		DRAIN GASKET BOLT 4X6	1
5-003 5-004 5-008 5-007 5-007 5-008	619-20110-200 592-2027T-920	THROTTLE VALVE SPRING THROTTLE SPRING RECEIVE JET NEEDLE ASS'Y JET NEEDLE ASS'Y	1 1
5-009 5-009 5-010 5-011 5-012 5-013	591-2007T-200 622-20110-200 623-21700-200 602-20444-200	THROTTLE VALVE 0.5X1.5 THROTTLE VALVE 0.75X1.5 ADJUSTER SCREV ADJUST SPRING NEEDLE SEAT BODY BAND ASS'Y	-F173300 F173301-
5-014 5-015 5-016 5-017 5-018 5-019	994-34040-100 603-20444-900 607-20110-200	NEEDLE VALVE ASS'Y FLOAT CHAMBER GASKET FLOAT ARM PIN	1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
5-020 5-021 5-021 5-022 5-023	599-2001T-620 599-2001T-600 604-20110-200	MAIN JET #60	1 F173300 F173301-

FIG.6 SHOULDER FRAME




	-		7//
REF	NEP PARTIER	PARWANE	SE SERVATER REMARKS
6-001 6-002 6-003 6-003 6-004 5-005	244-33328-800 245-33331-801 746-33328-900 746-33331-900 335-33328-200	SHOULDER FRANE COMP.	1 1 1 -G025900
6-006 6-007 6-008 6-008 6-009 6-009	247-33328-201 248-33328-200		2
6-010 6-011 6-012 6-013 6-016 6-021	653-33328-804 993-50014-002		6 6 6 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
6-022 6-023 6-024 6-024 6-025 6-026	990-11050-201 990-11050-221 992-10050-012	FUEL TANK BAND SCREW 5X20 SCREW 5X22	1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
6-030 6-031 6-032 6-033 6-033 6-034	680-01004-200 680-01004-200	CLIP PET-COCK ASS'Y CLIP 8	1
6-034 6-034 6-035 6-040 6-041	700-15008-230 700-15008-250 702-33340-200 778-38100-200	FUEL PIPE 5X8X215 FUEL PIPE 5X8X230 FUEL PIPE 5X8X250 FUEL PIPE PROTECTION COIL CORD CLAMP STOP CORD COMP.	1 R -F113450 -G025900 1 G025901-
6-042,1 6-042 6-043 6-044 6-045 6-046	221-33340-800 319-33328-801	ENGINE BASE B ENGINE BASE B COMP. CUSHION RUBBER COMP. ENGINE BASE COMP. NUT 6 S. WASHER 6	1 R -E262475 E262476-
6-047 6-048 6-049 6-050 6-051 6-052	990-11060-121 992-10060-012 992-01060-011 990-11050-121 992-10050-012 992-01050-011	S. WASHER 6 WASHER 6 SCREW 5X12 S. WASHER 5	1 1 1 2 2 2 2
6-053 6-054	991-01060-011 992-10060-012	NUT 6	4 D E262476- E262476-

FIG.7 CLUTCH CASE




		······································
REF. NER PARTIER	PARTHAME	SERVANDER REMARKS
7-001 332-33340-800 7-002 993-51035-002 7-003 999-61620-204	CLUTCH DRUM COMP. STOP RING C-35 IN BALL BEARING *6202DD. 35MM/OD STOP RING C-15 EX STEP WASHER	1 1 1 1 1 1 1 -H206490
7-009.1 400-33340-200 7-009 400-33360-800	S. WASHER 6 BOLT 6X18 W/PLUS	1 N H206491- 4 1 -H206490 1 N H206491- 1 D H206491-
7-016 264-33340-200 7-016 279-11073-005	S. WASHER 4 SMALL WASHER 4 CORD PROTECTION VINYL	1 D H206491- 1 D H206491- 1 D H206491- 1 I -F066200 -G025900 1 I -H206490
7-017 903-32201-200 7-020.1 351-33340-900 7-020 351-33340-901	PROTECTION TUBE 13 WIRE CLAMP BAND FLEXIBLE SHAFT ASS'Y FLEXIBLE SHAFT ASS'Y FLEXIBLE SHAFT COMP. FLEXIBLE LINER COMP.	1 N H206491- 3 I -H206490 1 H206491- 1 I -H206490
_	FLEXIBLE LINER COMP.	H206491-

FIG.8 HANDLE




	- A		/// / .5
REF	MER PARMER	PARTAME	SERIN WER REMARKS
8-001 8-001 8-002 8-002 8-002 8-003	504-33340-200 504-33360-200 281-33340-200 281-33340-201 281-33340-202	GRIP SHAFT GRIP JOINT PIPE JOINT PIPE	1 R -H205490 1 H206491- -H066976 1 P -H206490 1 P H206491-
8-004 8-005 8-006 8-006 8-007 8-008	992-10050-012 356-33331-800	ADAPTOR COMP. ADAPTOR COMP. SPACER	1 2 1
8-010,1 8-010 8-011,1	870-33564-900 870-33564-901		1 N E163249- -E262475 -H206490 H206491-
8-013.1 8-014.1 8-015.1 8-016.1	176-33564-200 956-33564-200	STOP SWITCH STOP SWITCH SPRING EARTH TERMINAL	1 -E262475 -H206490 1 1 1 1 1 1 1 1 1
8-019,1 8-019,1 8-020,1	957-33564-200 990-11050-301 994-31050-301 994-31050-251 991-86050-000 880-37101-200	SCREW 5X30 SCREW 5X30 SCREW 5X25 SELF-LOCK NUT 5	1
8-012 8-013 8-014 8-015 8-016 8-017	162-37101-200 262-37101-200 176-37101-200 177-37101-200	RETURN SPRING STOP SWITCH STOP SWITCH SPRING EARTH TERMINAL A EARTH TERMINAL B STOP SWITCH BASE	
8-018 8-019 8-020 8-021 8-022 8-023	991-86050-000 993-55060-001 994-31050-251 853-37101-200		3 1 1 1 1 1 N H206491- 1 N H206491-
8-024 8-026 8-027 8-028 8-029 8-030	956-37101-200 500-33560-200 506-33560-200 990-21060-451 992-01060-011 992-10060-012	HANDLE HANDLE BRACKET A BOLT 6X45 WASHER 6	1 N H208491-
8-031 8-032 8-033 8-033 8-035 8-036	347-33411-912 347-33411-912 343-33331-200	DRIVE SHAFT PIPE ASS'Y BUSHING ASS'Y BUSHING ASS'Y	2 N E262476-
:			

FIG.9 GEAR CASE




_			
REF	NER PARTER	PARTIANE	SERIANER REMARKS
9-001 9-002 9-003 9-004 9-005	312-33411-200 992-29080-000 316-33410-200	CUTTER FIXING BOLT/L.H.T. TOOTHED LOCK WASHER 8 L/H BOLT PROTECTION COVER CUTTER HOLDER CAP CUTTER HOLDER	1
9-008 9-008 9-008 9-009	300-37000-911 300-37000-912 300-37000-920 993-51032-002	GEAR CASE ASS'Y STOP RING C-32 IN BALL BEARING #6002DD, 32MM/OD	1 R -E262475 1 R -G252024 -H162320 1 P H162321- 1 I -F066200
9-011 9-012 9-013 9-014	304-37000-200 301-33411-200 999-61600-000	GEAR BALL BEARING #8000, 26MM/OD BOLT 6X12 W/PLUS	F066201-
9-017 9-018 9-018 9-018	990-51050-203 991-01050-011 300-33410-210 300-33410-211 300-33410-212 300-33410-220	GEAR CASE GEAR CASE GEAR CASE	2 R -E262475 R -G252024 H162320 H162321 -
9-021 9-021	302-37000-200 999-61600-004 999-61600-003 993-50010-002	GEAR CASE WASHER PINION BALL BEARING #6000DD. 26MM/OD BALL BEARING 6000D. 26MM/OD STOP RING C-10 EX STOP RING C-26 IN	2 1 1 -F086200 F066201-
9-024 9-030 9-031 9-031 9-032 9-033	441-37003-801 441-37003-802	SAFETY GUARD BRACKET SAFETY GUARD COMP., METAL SAFETY GUARD COMP., METAL BOLT 6X15 V/PLUS	1 N H162321- 1 R -H066976 1 H066977-
8 -033			

FIG.10 TOOLS & OPTIONAL PARTS



REF	NET	PARTIAME	SERIALIER REMARKS
10-001	805-33413-200	BLADE 4 TEETH 255	1 I -G025900
	752-33900-200 813-20000-200	HEX. VRENCH 4	1 D G252025-
10-005.1	826-20000-200	BOX SPANNER 17X19	1 R -H066976
	951-20000-200 862-20000-200 801-20000-200 615-33411-900	PLUS DRIVER 4 SPANNER 8X10 CUTTER COVER ASS'Y	1 D H066977- 1 D H066977- 1 D H066977- 1 1 I -G004350
10-022 10-023 10-024 10-027	615-33680-200 615-33411-200 616-33411-200 948-39907-200	CUTTER COVER CUTTER COVER BAND	1 D G004351- 1 D G004351- 1 D G004351-

FIG.11 MARKS



REF. NEP. PARTIER	PARTAME	SERVANDER REMARKS
11-001,1 906-0136U-200 NAME PLATE 11-001 906-0136U-201 NAME PLATE 11-002 929-33802-200 SYMBOL MARK		1 R -F153661 1 F153662-