




COOKTOP PARTS

For Models: RS610PXGW3, RS610PXGN3, RS610PXGV3
(White) (Almond) (Black on Biscuit)

30" DROP-IN
ELECTRIC
STANDARD CLEAN
OVEN




Illus. No.	Part No.	DESCRIPTION
1	LIT3191799	Literature Parts Installation Instructions
	LIT3191537	Use & Care Guide
	LIT3192846	Tech Sheet
	LIT3191638	Safe Cooking Tips
2	3192459	Burner Box
4	3192575	Bracket, Mounting
5	3196537	Screw, 8-18 x 3/8
7	3192102	Trim, Extension
8		Cooktop
	3191168	White
	3191169	Almond
	8284709	Biscuit
9	3195210	Clip, Receptacle
10	3191228	Panel, Control
11	3183956	Seal, Switch (4)
12		Switch, Infinite
	3191471	Use W/ 6" Surface (Blue Shaft)
	3191472	Use W/ 8" Surface (Silver Shaft)
13	3191491	Light, Indicator
14	3195917	Clip, Element
15	3400855	Screw, 8-32 x 1/4
17	4448444	Grommet
19		Drip Bowl
	3195208	6" (2)
	3195209	8" (2)
20		Element, Coil
	8053265	6" LF-RR
	8053267	8" RF-LR
21	3400843	Screw, 8-18 x 3/8
22	3196231	Knob, Control (4)
23	3192330	Bracket, Switch Mounting

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3
(White) (Almond) (Black on Biscuit)



Illus. No.	Part No.	DESCRIPTION
-------------------	-----------------	--------------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

- | | | |
|---|---------|--|
| 1 | 4456313 | Control Panel Assy.
W/Membrane Switch |
| | 4449745 | Screw |
| | 3400832 | Screw |
| 2 | 4451034 | Gasket,
Control Panel |
| 3 | 4453193 | Microcomputer |
| | 4449745 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3
(White) (Almond) (Black on Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3
(White) (Almond) (Black on Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			14	4451740	Frame, Front	37	4451354	Fuse – Thermal
				4449040	Screw		4449809	Screw
				4450118	Nut	43	4455530	Base, Chassis
			15	4450493	Gasket, Door	49	4448933	Retainer
			19	4451478	Support, Insulation		4449154	Screw
				4449809	Screw	50	4451747	Cover, Back
1		Trim, Side					4449809	Screw
	4450844	RH Black	21		Rail, Side			
	4450847	LH Black		4450579	Right Side	51	4448477	Trim, Bottom
	4449747	Screw		4450580	Left Side	53	4449845	Support, Bracket
2	4455509	Bracket, Support		4448444	Grommet		4449154	Screw
3		Hinge Receiver		4449154	Screw	FOLLOWING PARTS NOT ILLUSTRATED		
	4455722	Left Hand	23	4450051	Deflector	INSULATION		
	4455723	Right Hand		4449154	Screw		4449316	Insulation, Wrap
4	4448520	Bumper, Door	25	4454691	Side, Chassis (R.H. & L.H.)		4450365	Insulation, Back
7	4455286	Top, Chassis		4449809	Screw			
	4449809	Screw	26	4452234	Back, Chassis			
9	4452159	Tube, Vent		4449809	Screw			
	3196176	Screw	27		Liner, Oven (Not serviceable)			
10	4451664	Fan & Bracket Assy	29	4455636	Sensor			
	4449809	Screw		4449154	Screw			
11	4452368	Oven Light Assy						
12	4452166	Bulb, Light						
13	4452165	Lens, Light						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: RS610PXGW3, RS610PXGN3, RS610PXGV3
(White) (Almond) (Black on Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

- 1 4451719 Door Liner
- 2 4449259 Glass, Inner
- 3 4455523 Hinge, Door
4449743 Screw (4)
- 4 4451671 Retainer, Glass
4449809 Screw (4)
- 5 4450813 Bracket, Handle
4451040 Screw (4)
4449743 Screw (2)
- 6 4451674 Seal, Top
- 8 4452065 Assy, Door Glass
- 9 4448854 Handle, Door
- 10 4450863 Retainer, Glass
4449743 Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3
 (White) (Almond) (Black on Biscuit)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RS610PXGW3, RS610PXGN3, RS610PXGV3
 (White) (Almond) (Black on Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw
2	4454943	Plate, Mounting
11	4449868	Block, Terminal
	3400080	Screw
	112432	Nut
13	4448549	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Compt.
	3191832	Right
	3191833	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
16	3191842	Cover, Rear
	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3
(White) (Almond) (Black on Biscuit)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828 Wire (12 Ga.
150 c Black)
242820 Wire (14 Ga.
150 c Black)
242821 Wire (14 Ga.
150 c Blue)
242822 Wire (14 Ga.
150 c Brown)
242830 Wire (14 Ga.
200 c Brown)
242823 Wire (14 Ga.
150 c Green)
242824 Wire (14 Ga.
150 c Orange)
242829 Wire (12 Ga.
150 c Red)
242825 Wire (14 Ga.
150 c Red)
242831 Wire (14 Ga.
200 c Red)
242826 Wire (14 Ga.
150 c White)
242827 Wire (14 Ga.
150 c Yellow)
242832 Wire (14 Ga.
200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

4449809 Screw
3191220 Harness, Wire
(Main)
4455745 Harness, Wire
(EDC)
4451163 Conduit
3400015 Screw, Ground
4448664 Clamp
3192236 Harness, Wire
(Infinite Switch)
4455592 Harness, Wire
(Light)
4454384 Ground, Wire
4452222 Spacer, Harness
4454835 Tie, Cable

Miscellaneous

4448950 Screw, Install.
8-14 x 1" (4)
814381 Hinge Pin Kit