



ITEM 41146 8" BOLT CUTTER ADJUSTMENT INSTRUCTIONS

1. The jaws are properly adjusted if when held in a closed position, there is a parallel gap between the cutting edges.
2. To adjust the gap, back off the jaw adjustment screw lock nut. Back off the screw until its head rests on the stopper on the opposite handle. Back off the screw 1/6th of a turn at a time and hold tool to the light, observing result of gap setting.
3. To verify the gap, place a sheet of paper between the jaws and fully close the handles. The jaws should hold the paper in place. Hold the screw in place and tighten the lock nut. **DO NOT OVER TIGHTEN** the nut.

▲WARNING

To prevent serious injury:

1. Wear ANSI-approved safety goggles during use.
2. Never use on live electrical circuits.
3. Keep fingers clear of sharp blades.
4. Keep out of children's reach.

Distributed exclusively by Harbor Freight Tools®.

3491 Mission Oaks Blvd., Camarillo, CA 93011

Visit our website at: <http://www.harborfreight.com>



**Read this material before using this product.
Failure to do so can result in serious injury.
SAVE THESE INSTRUCTIONS.**

Copyright© 2009 by Harbor Freight Tools®. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

For technical questions or replacement parts, please call 1-800-444-3353.