



**2.1 ULTRASONIX™
SPEAKER SYSTEM**

HO98012

INSTRUCTION MANUAL



www.jascoproducts.com

1. Introduction

The GE 2.1 UltraSonix™ Speaker System provides high quality stereo sound for a variety of applications: listen to CD's or MP3's from your computer or portable audio device, realistic sound for gaming, or sound for your multimedia presentations. The high-power subwoofer is made of wood for deep, rich bass resonance. Each satellite features high fidelity sound previously unavailable on computer speakers. The GE 2.1 UltraSonix™ Speaker system is acoustically balanced for high quality digital audio sound reproduction that goes beyond comprehension for your listening pleasure.

2. Package Contents

- 10-Watt (RMS) Wood Subwoofer
- Two 4 Watt (RMS) Satellite Speakers
- UL Listed AC/DC Power Adapter
- 3.5mm Stereo Cable
- Instruction Manual

3. Features

- High-power wood subwoofer
- Two full-range satellites
- Balanced acoustics to reduce harmonic distortion
- Easy Access Control Panel on Subwoofer
- Power On/Off Knob
- Main Volume Control Knob
- Bass Level Control Knob
- Power on indicator LED
- Magnetically shielded to reduce interference

4. System Requirements

- Compatible with Windows® or Mac® OS
- Standard sound card with 3.5mm output jack

5. Installation

Read all instructions carefully and follow each step in order. Shut down your computer and turn off power to speakers before installation. Failure to do so could result in injury or equipment damage.

- Connect the Left and Right satellite speaker cables to the appropriate satellite speaker connectors on the back of the subwoofer. Make sure to connect the right speaker to the right jack and the left speaker to the left jack for accurate stereo sound.
- Connect the 3.5mm stereo cable to the input jack on the back of the subwoofer and to the output jack on your computer sound card (The cable end is color coded to match the green color of the output jack on most sound cards). On portable audio devices, plug the 3.5mm jack into the headset jack.
- Connect the power adapter to the AC input jack on the subwoofer and to a standard AC electrical outlet (A GE surge protector is recommended to protect your new 2.1 UltraSonix™ Speaker System.)

- Turn the main volume control and the bass level knob to the lowest setting before switching on the power to your 2.1 UltraSonic™ Speaker System. (Turn the knobs counter- clockwise.) Turn the power knob clockwise to switch on the power. (The blue LED will illuminate when the power is switched on).
- Turn on your computer (or portable audio device). Open your media player such as Windows Media Player®, Music Match Jukebox®, etc. Click on play to start playing your music.
- Adjust the volume and bass to a comfortable listening level. Make sure the volume on your speaker system, in your music software, and the main volume control in your operating system are all at an audible level (if any one of these volume levels are at its lowest setting, you will not have sound coming from the speakers).

6. 90 DAY LIMITED WARRANTY

Jasco Products Company warrants this product to be free from manufacturing defects for a period of ninety days from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other product that may be used with this unit. This warranty is in lieu of all other warranties express or implied. Some states do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state. If unit should prove defective within the warranty period, return prepaid with dated proof of purchase to:

Jasco Products Company
311 N.W. 122nd Street
Oklahoma City, OK 73114