

Please keep this instruction sheet for future reference, as it contains important information.

Adult assembly is required.

No tools needed for assembly.

Wipe the toy with a clean damp cloth.

Play mat is surface washable.



Write to us at: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052

Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470.

For countries outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500303. www.service.mattel.com/uk


Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.

Asia: Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.




www.fisher-price.com



GEOTFE TO THE TOTAL PROPERTY OF THE PROPERTY O

Assembly



• "Snap" the coal chute frame into the holes in the coal mine building.

Hint: The coal chute frame will only fit one way. If it does not seem to fit, turn it around and try again.

- "Snap" the coal mine arch onto the coal chute frame.
- Fit the coal chute onto the coal chute frame.

Ready To Work Together



The colorful play mat guides your setup!



Drop a boulder into the coal chute and load coal into the coal car.