




TOP AND CABINET PARTS

For Models: LBR5432PQ2, LBR5432PT2
(Designer White) (Biscuit)

AUTOMATIC
WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	3958075	Installation Instructions
	3955901	Feature Sheet
	8578232	Use & Care Guide
	8557228	Wiring Diagram
	3957458	Energy Guide

Following May Be Purchased


DO-IT-YOURSELF REPAIR MANUALS

	4313896	Manual, Washer
2		Top
	8541621	White
	8541623	Biscuit
4	357213	Nut, Push-In (2)
5		Cabinet
	63128	White
	3954777	Biscuit
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	3357011	Screw, 10-16 x 1/2
8	3351614	Screw, Ground
11	8318084	Switch, Lid
13	3351355	Screw, Lid Hinge Mounting (4)
15	8318088	Hinge, Lid (L.H.)
16	54583	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid Hinge (2)
19		Lid
	8542383	White
	8542385	Biscuit
20	9724509	Bumper, Lid (2)
21	3390631	Screw, 10-16 x 3/8 (4)

CONTROLS AND REAR PANEL PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)






Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3976300	Washer, Water Inlet Hose (4)	16		Cap, End (L.H.)	36	3400818	Screw, Timer Mounting
2	3400073	Screw, Ground		8271365	White			
3		Hose, Water Inlet		8271368	Biscuit	37	8541669	Bucket, Drain Hose (Left Half)
	8571377	Cold	17	9740848	Screw, 8-18 x 1/2	38	8541658	Bucket, Drain Hose (Right Half)
	8571378	Hot	18	3955673	Valve, Water Mixing	39		Panel, Console
4	8541672	U-Bend, Drain Hose	19	8541668	Clamp, Hose		3956558	White
5	8568314	Strap, Console (2)	20	3351614	Screw, Ground		3956578	Biscuit
6	8541686	Panel, Rear	21	301958	Clamp, Hose	44		Knob, Timer
7	62747	Pad, Rear Panel	22	8541607	Hose, Vacuum Break		8544943	White
8	8559373	Drain Hose Assembly (Includes Items 19 & 27)	23	370450	Clamp, Hose		8544944	Biscuit
9	8557226	Timer, Control (60 Hz.) (Motor Not A Service Part)	24	3347034	Break, Vacuum	45		Dial, Timer
10	388326	Screw, 8-18 x 1.25	25	303294	Edge Protector		8544947	White
11	90767	Screw, 8-18 x 3/8	26	8519200	Support, Rear Panel		8544948	Biscuit
12	3366849	Switch, Water Level	27	8541667	Clamp, Hose	46	8536939	Clip, Knob
13	3948814	Bracket, Control	28	8572717	Capacitor, Motor Start	47		Knob, Control
14	661661	Cord, Power (Includes Item 15)	29	8318046	Clip, Capacitor		8544935	White
15	3952821	Strain Relief, Power Cord	30	3363366	Clamp, Hose		8544936	Biscuit
			31	8317496	Clamp, Hose	50	62863	Screw, 10-16 x 3/8
			32	3951449	Hose, Pump To Tub (Includes Item 30)	51		Cap, End (R.H.)
			33	3349557	Retainer, Harness		8271359	White
			34	8559320	Restraint, Hose		8271362	Biscuit
			35	661612	Switch, Water Temperature	52	3347868	Cable Tie
						54	3957021	Harness, Wiring (For Detail See Page 9 & 10)
						FOLLOWING PARTS NOT ILLUSTRATED		
						3957361 Miscellaneous Parts Bag		

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)


Illus. No.	Part No.	DESCRIPTION
1	3352483	Cap, Agitator
2	358237	Screw & Washer (5/16-24 x 1)
4	63377	Agitator
5	3360611	Tub Ring & Gasket Assembly
6	3359586	Gasket, Tub Ring
7	8519815	Clip, Balance Ring (8)
8	3956205	Balance Ring
10	3949550	Washer
11	2219077	Clip, Pressure Switch Hose
12	21366	Nut, Spanner
13	3956206	Basket & Balance Ring
14	63125	Tub
15	389140	Block, Basket Drive
16	383727	Gasket, Centerpost
17	3363657	Hose, Pressure Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS


For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	388951	Brake & Drive Tube (Complete) (Refer to Page 11 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951311	Clutch (Complete)
6	3951308	Band & Lining, Clutch (Includes Illus. 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3946792	Spring, Clutch
9	3360630	Gearcase (Complete) (Refer To Page 12 For Further Breakdown.)

Illus. No.	Part No.	DESCRIPTION
10	3357334	Screw, Gearcase To Base (3)
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	285753	Coupling, Motor And Isolation Coupling
14	3946532	Shield, Motor
15	8577374	Seal
16	3400516	Screw
17	3349637	Retainer, Motor (2)
18	3362089	Shield, Tub To Motor
19	8528157	Motor, Main Drive
20	3952056	Switch, Main Drive Motor
21	8546127	Retainer, Pump (2)
22	3363394	Pump (Complete)
23	3387485	Screw, 10-16 x 5/8
24	3355454	Clip, Anti-Rattle




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)



WH2I

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness	10	353424	Plug, Terminal (3-Way)	17	3347730	Receptacle (6-Way)
2	388498	Clip, Harness			(Power Cord)			(Use Term. 94613)
3	3347812	Clip, Harness			(Use Term.94613)	18	3349494	Connector, Etc
4	3352501	Clip, Harness	11	62505	Block, Disconnect (Motor 2 Speed)	19	3407125	E.T.C. Control
5	90016	Clip, Harness			(Use Term.352088)	20	3948617	Connector (T.P.A.) (3-Circuit)
6	3390496	Clip, Harness	12	3347243	Block, Disconnect (Use Term. 352088)	21	3360056	Connector (T.P.A.) (3-Circuit)
7	389379	Retainer, (Suds Models)	13	63523	Protector			(Pressure Switch)
8		Timer, Block Disconnect	14	717252	Connector (2-Way)	22		Block, Connector
	3948614	White			(Use Term.94614)		3354925	Cold Valve
	352089	Black	15	3352944	Clip, Harness		3354926	Hot Valve
9	62889	Receptacle, Terminal (3-Way) (Lid Switch) (Use Term.94613) Or 94614.)	16	3390423	Block, Disconnect (12-Way) (Timer) (Use Term. 94613)			

**FOR COMPLETE WIRING HARNESS REFER TO
CONTROL AND REAR PANEL PARTS PAGE**


WH2I

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	388951	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	356427	Seal, Drive Tube
4	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
5	64035	Ring, Retaining
6	64232	Shoe, Brake (2)
7	62703	"T" Bearing, Spin Tube
8	3353956	Cap, Brake Spring (2)
9	62647	Spring, Brake
10	3355360	Sleeve, Brake Spring
11	661516	Cam, Brake Release
12	63022	Sleeve, Cam
13	64194	Driver, Brake Cam
14	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED


285208 Lubricant
(Use Only In Brake Shoe Assembly On Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate




GC-215-C

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WATER SYSTEM PARTS

For Models: LBR5432PQ2, LBR5432PT2

(Designer White) (Biscuit)



WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: LBR5432PQ2, LBR5432PT2
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
-------------------	-----------------	--------------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350938 Primer, Gray
350930 White
4392901 Biscuit

PAINT, BULK (1 qt.)

799344 White (Uncut)
4392900 Biscuit (Uncut)

OIL

350572 Oil, Gearcase
(16 Oz.)

LUBRICANT

285208 Lubricant (Use
Only in Brake
Shoe Assembly
On Roller and
Pin)

SEALER

285195 Sealer, Gasket
(.20 Fl. Oz.) (6 ml)

ACCESSORY PARTS

367031 Drain Protector
285320 Siphon Break Kit