


KitchenAid®

COOKTOP PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02
(Black) (White) (Stainless)

30" FREESTANDING
GAS OVEN
CONVECTION



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	7	3400843	Screw	19		Cap, Burner
	W10118262	Installation	9	9763445	Bracket, Burner			6K (RF, LR)
		Instructions	10	9756821	Support, Wiring		8284669CB	Coal Black
	W10162198	Use & Care Guide	12		Grate, Burner		9761562SD	Satin Cumberland
		Tech Sheet			Right			12.5K (RR)
	W10112145	English		9761555CB	Coal Black		9761563CB	Coal Black
	W10112146	French		9761555SD	Satin Cumberland		9761563SD	Satin Cumberland
	9757680	Anti-Tip	13		Grate, Burner	20	4449809	Screw
		Instructions			Left	21	3196160	Screw
	9762761	Safe Cooking Tips		9761556CB	Coal Black	23	9759627	Cover, Cooktop
	9763467	Guide Easy Set		9761556SD	Satin Cumberland			Rear
2	W10153103	Burner Box	16	9759944	Thermostat (60c)	24	9763436	Cover, Top Rear
3	9761784	Bracket, Mounting	17		Vent, Center	25		Head, Burner
4		Cooktop		9760225BL	Black		8286181	LR, RF
	W10175850	Black/Stainless		9760225WH	White		8286182	RR
	W10175851	White	18		Grate, Insert	26	W10109920	Gasket (Tape)
5	3196537	Screw		9761557CB	Coal Black			
				9761557SD	Satin Cumberland			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


OVEN PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02

(Black)

(White)

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right
	W10109540	Black
	W10109570	White
	W10140548	Stainless
		Left
	W10109490	Black
	W10109520	White
	W10140547	Stainless
2	8053971	Brace, Main Back
3		Hinge Receiver
	4455606	Right
	4455605	Left
4	W10105790	Bumper, Door
5	4448444	Grommet
6	3400832	Screw
7	8303099	Top Chassis
8	9759722	Insulation, Body Side Trim
9	9761666	Tube, Vent
10	W10067870	Lens, Light
11	W10009930	Assembly, Oven Light
12	4452166	Bulb, Light

Illus. No.	Part No.	DESCRIPTION
13	9757732	Shield, Heat
14	W10115831	Frame, Front
15	W10074200	Gasket, Door
17	4452152	Bracket, Mounting
18	9757685	Guide, Side Panel
19	9757461	Bracket, Side Panel
20		Oven, Side Panel
	9760723PB	Black
	9760723PW	White
21	9757811	Brace, Side Panel
22	W10195934	Latch, Motorized
23	9757807	Thermostat
24	9759890	Clip, Side Panel
25	4455641	Side, Chassis
26	9759762	Back, Chassis
27		Liner, Oven (Not serviceable)
28	9759945	Standoff, Rear
29	W10131825	Sensor
30	9756454	Bracket, GOC
31	9760223	Slide, DSI
32	W10083460	Slide, GOC
33	9762774	Central, Appliance
34	3196537	Screw
35	9760481	Washer, Insulation Body Side Trim

Illus. No.	Part No.	DESCRIPTION
37	9759242	Thermostat (TOD)
41	4449743	Screw
43	W10110534	Base, Chassis
49	4448933	Retainer, Gasket
50	9758583	Cover, Back
51	4449809	Screw
54		Vent, Bottom Upper
	9756481BL	Black
	9756481WH	White
	9756481SS	Stainless
55		Trim, Bottom Vent
	W10153486	Black
	W10153488	White
	W10154789	Stainless

**FOLLOWING PARTS
NOT ILLUSTRATED**


INSULATION

9756817	Insulation, Wrap
9756470	Insulation, Back
W10095410	Insulation Cover, Back Top
W10095400	Insulation Cover, Back Side

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02
(Black) (White) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02

(Black)

(White)


(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760580	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457104	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	9763497	Right
	9763496	Left
13	8522415	Seal, Window
14		Assembly, Door Kit
	W10131888	Black
	W10131889	White
15		Handle, Door
	8303774BL	Black
	8303774WH	White
	8303774SS	Stainless
16	3196184	Screw
17	4448520	Bumper, Door (3)
18		Badge
	8304603BL	Black
	8304603WH	White
	8304603SS	Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02
(Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	9763501BL	Support, Front & Rear	10	W10164163	Drawer	15	3196537	Screw
3	4453720	Brace, Drawer Right	12	W10164169	Panel, Drawer	16	8274149	Thermistor
	4453721	Left	13	W10203760	Black	17	9760775	Element, Warming
5	9759953	Side, Base Right		W10203762	White	18	4449809	Screw
	9759954	Left		W10203763	Stainless	19	9758676	Support, Element
6	W10058460	Foot	14	9761573BL	Black	23	9761796	Enclosure, Warming Drawer
8	3196037	Foot Assembly		9761573WH	White	24	W10153099	Cover, Access
				9761573SS	Stainless	25	3400805	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10203758	Front, Air Duct
2		Top, Air Duct
	W10068590	Right
	W10068600	Left
3	9759320	Blower
4	4451758	Block, Foam
7	9757829	Bracket, Transformer
8	W10111628	Transformer
9	3196537	Screw
10	4449040	Screw
11	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


INTERNAL OVEN PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02

(Black)

(White)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9752980	Shield, Flame
2	W10196895	Motor, Convection
5	9757779	Fitting, Broiler
6	W10179152	Rack, Oven
7	9760776	Element, Broil
8	4453957	Pan Support, Bake
9	9760229	Electrode, Bake
10	9760228	Burner, Bake Log
11	9752737	Shield, Oven
12	4453984	Shield, Bake Flame
	3196176	Screw


Illus. No.	Part No.	DESCRIPTION
13	9763716	Valve, Assemble
14	9756831	Tube, Broil
15	W10111219	Burner, Broil
16	8054129	Ignitor, Broil
17	4454009	Cover, Ignitor
18	4453920	Pan, Oven Bottom
19	9760777	Element, Convect
20	W10104790	Cover, Fan
21	9755542	Probe, Meat

Illus. No.	Part No.	DESCRIPTION
23		Shield, Element
	W10153093	Right
	W10153094	Left
24	W10153101	Diverter, Air
25	W10116351	Blade, Fan
26	W10116349	Nut
27	9755543	Jack, Meat Probe
28	9755547	Washer, Lock External
29	9755546	Hex Nut
30	3196176	Screw
31	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP BURNER PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10128446 LR, RF W10128455 RR	Burner Base
2	9761069	Tubing, Burner(RF)
3	9761070	Tubing, Burner(RR)
4	W10110378	Ingitor, Orifice Holder
5	9761068	Tubing, Burner(LR)


Illus. No.	Part No.	DESCRIPTION
6	9762937 LR, RF 9762938 RR	Orifice
7	4456816	Valve, Burner Small (2)
8	4456817	Valve, Burner Large
10	9761648	Tube, Manifold

Illus. No.	Part No.	DESCRIPTION
11	9761641	Manifold TCB
12	9761642	Cooktop
12	3196537	Screw
13	8273062	Screw
14	8523704	Bolt, Valve (4)
18	4453754	Tubing GDS to Manifold


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TRIPLE CROWN BURNER

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02
 (Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9761639	Burner Assembly Triple Crown Burner
2	8285250	Plate, Closure
3	8285255	Internal Head, Triple Crown
4	8285256	External Head, Triple Crown Burner
5		Cap, Burner External
6	8285258	Matte Black
	8285258SD	Satin Cumberland
		Cap, Burner Internal
	9758829CB	Matte Black
	9758829SD	Satin Cumberland
7	3400702	Screw
8	3400843	Screw
9	9760519	Valve, T.C.B.
10		Tube, T.C.B. Gas
	9761072	Outer
	9761071	Inner
11		Orifice
	9762443	Internal
	9762442	External
12	9763494	Igniter



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10117036	Control Panel Black
	W10117038	White
	W10156273	Stainless
2	9761566	Switch, Membrane
3	9762794	Control, Interface
4	W10105370	Shield, Console
5	3196537	Screw

Illus. No.	Part No.	DESCRIPTION
6	9757409	Support, Gas Valve
7	9761745	Bracket, Touchsensor
9		Knob, Burner RF, RR, LR
	W10193275	Black
	W10193273	White
	W10156265	Stainless

Illus. No.	Part No.	DESCRIPTION
10	9758080	Module, Spark
11		Knob, TCB LF
	W10193263	Black
	W10193261	White
	W10156262	Stainless
12	9780271	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: KGSS907SBL02, KGSS907SWH02, KGSS907SSS02

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	261869	Cord Brown
	72032	Black
<u>PAINT, SPRAY</u>		
	350930	White
	261900	Citrine White
	830864	Black
<u>ADHESIVE</u>		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
<u>WIRING HARNESS PARTS</u>		
	W10157936	Harness, Main
	9762904	Harness, Bake/ Broil Ingiter
	9756824	Harness, Spark Switches
	W10110533	Harness, Warming Drawer
	9756921	Harness, Triple Crown Burner
	9762921	Harness, Communication
	9763481	Harness, Ground Strap
	W10155291	Connector, Flex
	4449809	Screw
	4454842	Tie, Cable
	4450800	Screw, Ground
	4452222	Spacer, Harness

Illus. No.	Part No.	DESCRIPTION
<u>Miscellaneous</u>		
	4455352	Bracket, Blower
	9757426	LP Orifice Kit
	9758677	Power Cord
	9782676	Anti-Tip, Assembly Filler, Countertop
	W10113902A	Black
	W10113903A	White
	W10113901A	Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST