DENON

FRANÇAIS

ENGLISH

ESPAÑOL

AVR-E400

INTEGRATED NETWORK AV RECEIVER

Getting Started

Mise en route / Antes de empezar

Welcome

Thank you for choosing a Denon receiver. This guide provides step-by-step instructions for setting up your receiver.

If you have setup problems:


If you need additional help in solving problems, contact Denon customer service in your area.

1-855-MY.Denon

1-855-693-3666 Call for Assistance: 9:00AM to 8:00PM M-F E.S.T. For frequency asked questions please visit www.usa.denon.com/FAQ

For US and Canada only

Before You Begin



Setup

There are three steps to the setup process.




Connect the receiver to your TV

3 Follow the On-Screen Setup Assistant









2 Connecting the receiver to your TV

□ Place the receiver near your TV.




ΤV




Receiver

□ Connect the receiver to your TV with an HDMI cable.











TV remote control unit


□ Select the appropriate HDMI input on your TV.






TV remote control unit

□ Turn on receiver.




• Turn on receiver as shown below.




3 Follow the On-Screen Setup Assistant

The Setup Assistant will walk you through connecting and configuring your speakers and components to your Denon receiver. Please use the remote control and follow the on-screen instructions.








Owner's Manual

The included CD-ROM contains an Adobe PDF version of the full owner's manual for the AV receiver.

Please reference this manual for more details about the setup and operation of the receiver and it's features.





DENON

www.denon.com

D&M Holdings Inc. Printed in China 5411 11014 00AD