




VENTILATION PARTS

For Model: GZ7730XGS0

(Brushed Aluminum)

30" RANGE HOOD
(Use with Gas or Electric Range)




VENTILATION PARTS

For Model: GZ7730XGS0
(Brushed Aluminum)

Illus. No.	Part No.	DESCRIPTION
1	4360001	Damper, Canopy
2		Hood, Canopy Non-serviceable
3	4360002	Support, Canopy (2)
4		Bracket, Blower
	4360003	Left Side
	4360054	Right Side
5		Support, Housing Housing
	4360004	Left Side
	4360039	Right Side
6	4360005	Washer
7	4360006	Screw, 5 x 12 (3)
8		Endcap, Blower
	4360007	Left
	4360053	Right
9	4360008	Housing, Blower
10	4360075	Support, Housing
11	4360063	Bushing (4)
12	4360062	Strain Relief
13	4360357	Plate, Mounting
14		Cover, Terminal
	4360060	Left Side
	4360056	Right Side
15	4360057	Terminal
16	4360058	Capacitor
17	4360059	Bracket, Capacitor
18		Wheel, Blower
	4360049	Left Side
	4360055	Right Side
19	4360040	Motor
20	4360052	Plate, Motor
21	4360050	Screw 4 x 8 (3)
22	4360051	Washer (3)
23	4360064	Grille, Blower (2)
24	4360067	Screw 6 x 10 (2)
25	4360074	Clip (2)
26	4360048	Pin, Filter (2)
27	4360071	Bracket, Filter
28	4360072	Spring, Filter (2)
29	4360120	Bracket (6)

DOOR AND CONTROL PARTS

For Model: GZ7730XGS0
(Brushed Aluminum)



DOOR AND CONTROL PARTS

For Model: GZ7730XGS0
(Brushed Aluminum)

Illus. No.	Part No.	DESCRIPTION
1	4360010	Guide, Door (2)
2		Guide, Housing
	4360011	Left Side
	4360037	Right Side
3	4360012	Support, Guide
4	4360013	Socket, Lamp (2)
5	4360014	Lamp
6	4360015	Filter
7	4360076	Glass, Door
8	4360017	Brace, Glass (2)
9		Frame, Door
	4360018	Left Side
	4360024	Right Side
10		End Cap, Door
	4360069	Left Side
	4360070	Right Side
11		End Cap Handle
	4360020	Left Side
	4360022	Right Side
12	4360358	Handle
13	4360112	Bracket, Handle
14	4360077	Baffle, Door
15	4360080	Support, Light
16	4360066	End Plate
17	4360043	Bracket, Light
18	4360044	Clamp, Wiring
19	4360045	Ballast, Lamp
20	4360047	Receptacle
21	4360046	Starter
22	4360041	Brace, Glass (2)
23	4360042	Lens, Light
24	4360081	Frame, Lens
25	4360033	Base, Switch
26	4360034	Cover, Base
27	4360035	Switch (2)
28	4360036	Cover, Switch
29	4360073	Screw
30	4360025	Switch, Light (2)
31	4360359	Light, Indicator
32	4360027	Switch, Fan (2)
33	4360028	Lens, Ind. Light
34	4360029	Cover, Switch
35	4360030	Knob, Control
36	4360031	Knob, Fan
37	4360032	Knob, Light

LITERATURE PARTS

LIT883141 Installation
Instructions
LIT4360082 Wiring Diagram

ACCESSORY PARTS

883140 Non-Vent Kit
883142 Front Kit (Black)
883144 Front Kit (White)