# INSIGNIA

# Quick Setup Guide NS-PAH5101/NS-PAH5101-C/NS-PAH5201/ NS-PAH5205/NS-PAH5201-C/NS-PAH5205-C


# **PC Headset/Stereo PC Headset**

### **PACKAGE CONTENTS**

- Mono PC Headset, Stereo PC Headset, or Deluxe Stereo PC Headset
- Y adapter
- · Quick Setup Guide

#### **INSTALLING YOUR HEADSET**

 Plug the connectors into the corresponding ports on your computer, laptop, smartphone, or tablet.



## **TROUBLESHOOTING**

If your headset does not function correctly, try the following:

- Make sure that your headset is plugged all the way into the correct ports.
- Make sure that the volume on your device is set to a medium level and is not muted.
- Slowly adjust the volume control on the headset cable.

#### **ONE-YEAR LIMITED WARRANTY**

Visit www.insigniaproducts.com for details.

### **CONTACT INSIGNIA:**

For customer service, call 877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico) www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies. Registered in some countries.
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2014 Best Buy. All rights reserved.
Made in China

### ADJUSTING THE VOLUME

You can adjust the volume by:

• Turning the volume knob on the headset.



#### OR

 Using your computer's volume controls to adjust operating system volume levels.