

PACKAGE CONTENTS

- Light stand
- Carry bag
- Quick Start Guide

FEATURES

- 3-section design extends up to 6 ft
- Cushioned main pole dampens motion
- Compact design folds to 28.5" for easy portability
- Stand holds your studio lights, flashes, umbrellas and reflectors such as:




#	ITEM	DESCRIPTION
1	1/4" mounting screw	Use this screw to mount a device such as a studio light, flash, or umbrella bracket. NOTE: Some studio flash heads or umbrella brackets slide all the way over this mount area and fasten in place with a locking clamp.
2	Upper screw knob	Lock or loosen the first section tube of the light stand
3	Lower screw knob	Lock or loosen the second section tube of the light stand
4	Leg locking knob	Lock the light stand legs in place to provide maximum stability & strength

USING YOUR LIGHT STAND


- 1 Loosen the leg locking knob.



- 2 Pull outward on the legs. Set upright, then push down on the legs and tighten the leg locking knob.



- 3** Loosen the lower screw knob. Then extend the center column to the length you want.



- 4** Tighten the lower screw knob.



- 5** Loosen the upper screw knob. Then extend the center column to the length you want.



- 6** Tighten the upper screw knob for the second section lock.



- 7** Attach your studio light, flash, umbrella or other item for use.

SPECIFICATIONS

- **Warranty:** 12 months parts & labor
- **Maximum operating height:** 74.8 in. (190cm)
- **Minimum operating height:** 28.3 in. (72cm)
- **Folded height:** 28.5in (72.4cm)
- **Net weight:** 3.4 lbs (1.54 kg)
- **Max operating load:** 8.8 lbs (4 kg)
- **Number of leg sections:** 3
- **Material:** Aluminum & Iron

IMPORTANT SAFETY INSTRUCTIONS

To prevent damage to your lighting equipment or injury to you or others, read the following safety precautions in the entirety before using the stand.

- 1 Read and understand all instructions before using.
- 2 Keep these instructions.
- 3 Close supervision is necessary when any appliance is used by or near children. Do not leave the appliance unattended while in use.
- 4 Do not place the light stand on an uneven surface. Your stand may tip over and cause property damage or personal injury.

NOTE: Do not exceed the 8.8 lb maximum load capacity of this light stand. Avoid mounting heavier or unbalanced loads on the stand to prevent an accidental fall, bodily injury or damage to your equipment.

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)
www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies. Registered in some countries.
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2015 Best Buy. All rights reserved.
Made in China