

Koss Operating Instructions for the TC/45 Tele-Headset System

Congratulations on your choice of the Koss TC/45 Tele-Headset. Now you can enjoy the Sound of Koss anytime you use your cellular or mobile cellular telephone. The TC/45 is compatible with most cellular and mobile cellular telephones that have a 2.5mm jack. Some of the cellular phones include:

- Motorola Flip, GSM, Micro Tac Elite
- Fujitsu ST, XL
- AT&T 3625, 3760, 3770
- OKI 1145, 1150, 1325, 1335, 1375
- Panasonic EB-H10, EB-H20, EB-H40, EB-H41, EB-H105
- Ericsson/GE AH97, GT700, MicroFlip, TK01, TK03, DH-388
- Audio Vox MVX-425, MVX-450, MVX-525, MVX-550
- Toshiba TCP-900, TCP-1000
- General Electric CT-500, CT-700
- ETE Communicator
- Prestige PR-140, PR-150

If your cellular or mobile telephone is not listed, please check for a 2.5mm jack. If your cellular or mobile cellular telephone requires a different adapter, call 1-800-USA-KOSS.

To Connect the TC/45 to your Cellular Telephone

1. Insert the 2.5mm plug of the TC/45 Headset into the jack located on your cellular phone.
2. To Make a phone call using the TC/45
 - A. Slip the TC/45 ear piece around your ear so the fit is snug and comfortable.
 - B. Adjust the microphone to a comfortable position in front of your mouth.
 - C. To complete or take a call, follow cellular or mobile cellular telephone manufacturer's instructions.

Trouble Shooting Guide

No Sound

1. Check volume control on cellular or mobile cellular phone.
2. Check all connections.

For additional service problems, call 1-800-USA-KOSS