



IMPORTANT — To assure product **SAFETY** and **RELIABILITY**, repairs, maintenance or adjustments should be performed by **MAKITA** Service Centers or other qualified service organizations. Always use **MAKITA** replacement parts.

Fig.	Part No.	Qty. Used	Description	Fig.	Part No.	Qty. Used	Description
1	265837-4	7	TAPPING SCREWM3x20	15	415250-8	1	HOUSING SET (Incl. Fig. 3)
3	415250-8	1	HOUSING SET (Incl. Fig. 15)	16	651889-5	1	SWITCH, FWD/REV.
4	265998-0	1	HEX SCREW 5x21	17	214019-5	1	PLANE BEARING 4
6	153175-5	1	GEAR Cpl.	18	226077-9	1	GEAR Cpl., 11-65
7	214017-9	1	PLANE BEARING 5	19	214019-5	1	PLANE BEARING 4
8	629649-3	1	DC MOTOR 4.8V (with Gear, 221851-0)	20	411640-3	1	HOLDER 6
9	414113-5	1	SWITCH LEVER	ACCESSORIES			
10	231311-4	1	COMPRESSION SPRING 7	400	763110-1	1	KEYLESS CHUCK
11	651852-8	1	SWITCH, ON/OFF	401	784202-3	1	PHILLIPS BIT No.2
12	631161-1	1	CIRCUIT BOARD	402	150087-3	1	3-HOUR CHARGER DC4100
13	678102-6	1	BATTERY	403	824417-1	1	PLASTIC TOOL CASE
14	415231-2	1	COVER				