


Vextra

AM/FM FLASHLIGHT RADIO

MODEL: VX0050

1. LIGHT
2. PRESS BUTTON
3. LIGHT ON/OFF
4. VOLUME CONTROL
5. TUNING CONTROL
6. BAND SELECTOR SWITCH



POWER OPERATION

This unit is designed to operate with DC 3V (two "AA" size batteries). Batteries not included.

Open the battery cover and install two "AA" size batteries, observing the battery polarity (+ and -).

NOTE: WEAK OR DEAD BATTERIES MAY SWELL AND LEAK. TO AVOID DAMAGE TO THE UNIT, REMOVE THE BATTERIES WHEN THE UNIT IS TO BE STORED FOR A LONG PERIOD OF TIME OR IF THE BATTERIES BECOME WEAK.

RADIO OPERATION

1. Turn ON-OFF volume control to ON position.
2. Set the selector to either AM or FM BAND. Rotate the tuning knob until the desired station is selected.
3. Adjust the volume control to the desired listening level.

LIGHT

This unit can be used as a flash light by setting the light on/off switch to ON position. Set the switch to OFF position to switch off the light.

CLEANING

Clean the casing with a soft cloth slightly moistened with water or a mild detergent solution. Do not use solvents such as alcohol, benzine or gasoline as they may mar the finish of the casing.

Never immerse unit in water. This will damage the electronic components.

BULB FOR REPLACEMENT: BULB TYPE NO. 222 (2.2V/2.5V)

FOR ADDITIONAL SET UP OR OPERATING ASSISTANCE, PLEASE CONTACT CUSTOMER SERVICE AT (954) 660-7100. PLEASE KEEP ALL PACKAGING MATERIAL FOR AT LEAST 90 DAYS IN CASE YOU NEED TO RETURN THIS PRODUCT TO PLACE OF PURCHASE. FOR PARTS AND ACCESSORIES, CONTACT FOX INTERNATIONAL AT 1-800-321-6993

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.