KDL-V26A12U

### Quick Start Guide

Follow steps 1 through 6 to quickly set up the TV for use.

For more information, see the Operating Instructions supplied with this manual.

© 2005 Sony Corporation Printed in Spain

## Checking the accessories









(2) Size AA batteries (R6 type)




D












(1) Mains lead (Type BF)


(1) Cable holder

Support belt (1) and screws (2)


### Inserting batteries into the remote



# Connecting an aerial/VCR




2



Λ

#### **Preventing the TV from toppling over**



5

#### Switching on the TV

