



**PROSERIES**

## Air Compressor Illustrated Parts List

Questions? Help is just a moment away!

Vous avez des questions? Vous n'avez pas besoin d'aller  
loin pour trouver de l'aide!

Preguntas? La ayuda es justa un momento lejos!

Call: **Helpline**

Appelez: **Ligne d'assistance**

Llame: **Línea Directa**

**1-800-743-4115** M-F 8-5 CT

**BRIGGSandSTRATTON.COM**


**074010**



**BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC**  
**JEFFERSON, WISCONSIN, U.S.A.**

Manual No. 203721A Revision - (01/21/2008)

# EXPLODED VIEW



Copyright © 2008 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.

## PARTS LIST

Item	Part #	Description	Item	Part #	Description
1	199175GS	DECAL, Hot Surface	41	*	WASHER
2	*	SCREW, M8 x 45	42	*	HHCS, 5/16 x 25
3	200699GS	CONVEYOR, Air	43	*	WASHER
4	*	PPHMS, 5 x 12	44	*	SCREW
5	201389GS	PLATE, Filter	45	201063GS	INFEED TUBE
6	200697GS	ELEMENT, Filtering	46	199173GS	DECAL, Warning
7	201390GS	FILTER, Intake	47	201413GS	ASSY, Pressure Reducer
8	*	PPHMS, 4 x 18	48	200535GS	DECAL, Warning
9	200698GS	GASKET	49	199739GS	DECAL, Tank Drain
10	201382GS	KIT, Valve Plate Set	50	200775GS	DECAL, Starting Instructions
11	201400GS	ASSY, Pump	51	200536GS	DECAL, Warning, Moving Parts
12	*	HHCS, M8 x 25	52	201409GS	CLAMP, Belt Guard
13	*	WASHER, M8, Shakeproof, Int	53	192310GS	KIT, Vibration Mount (Includes Qty of 2)
14	*	WASHER	54	201419GS	CONNECTOR, Elbow
15	200702GS	FLYWHEEL	55	*	WASHER, M6
16	200686GS	OIL LEVEL SIGHT GLASS	56	*	WASHER, M10
17	200538GS	DECAL, Warning, Hot Muffler	57	*	NUT, M10
18	201398GS	PLUG, Breather Pipe	58	200675GS	TAP, Discharge
19	200537GS	DECAL, Warning, Fuel Vapors	59	201411GS	HANDLE, Rubber
20	201061GS	WHEEL	60	201408GS	FITTING, Hose Tail
21	201062GS	PIN, Wheel	61	*	NUT, M8 with Washer
22	*	NUT Lock M6	62	*	CLAMP, Hose
23	200696GS	GUARD, Belt	63	201418GS	HOSE
24	201401GS	PLATE	64	201417GS	FITTING, Hose Tail
25	*	WASHER, M5	65	201414GS	VALVE, Safety
26	*	SCREW, Self Threading, M5 x 14	66	201416GS	ADAPTER
27	201402GS	SPACER	67	201415GS	GUAGE, Pressure
28	201405GS	SPACER	900	§	ENGINE
29	201404GS	CONNECTOR, Elbow			
30	*	HHCS, M10 x 45			
31	201060GS	ACCELERATOR, Pneumatic			
32	201064GS	VALVE, Auto Unloading			
33	*	HHCS, M8 x 45			
34	200677GS	COUPLER, Quick Connect			
35	201420GS	GUAGE, Pressure			
36	201403GS	PLATE			
37	*	HHCS, M8 x 16			
38	*	SHCS, M6 x 16			
39	200695GS	PULLEY			
40	200693GS	BELT			

Parts Not Illustrated	
203721GS	MANUAL, Operator's
200774GS	DECAL, Unloader Valve
201770GS	OIL, Compressor
203245GS	KIT, Decal, Srv
BB3061BGS	OIL BOTTLE, 18oz Engine

§ - Contact Engine Manufacturer  
 \* - Items without part numbers are common fasteners and can be found at your local hardware store.