IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

DANGER - Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. Always unplug appliance immediately after using.

2. Do not use while bathing or in a shower. Do not place or store appliance where it can fall or be pulled into a tub or sink. 4. Do not place in, or drop into water or other liquid.

5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

WARNING - To reduce the risk of burns. electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.

2. Do not pull, twist, or wrap line cord around appliance, even during storage.

3. This appliance should not be used by, on or near children or individuals with certain disabilities.

4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer.

5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.

6. Keep the cord away from heated surfaces. 7. Never use while sleeping.

8. Never drop or insert any object into any opening or hose.

9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

10. Unit is hot when in use. Do not let heated surfaces touch eves or bare skin.

11. Do not place the heated unit directly on any surface while it is hot or plugged in.

12. Never block the air openings of the appliance or place on a soft surface such as a bed or couch, where the air openings may be blocked. Keep the air opening free of lint and other debris. 13. Do not use an extension cord with this appliance.

14. Do not touch hot surfaces of the appliance. Use handles or knobs.

15. Before plugging in, read the information about dual voltage contained in the instruction section of this manual.

16. Do not attemp to touch the housing of your appliance near the straightening plates, as it is hot when in use.



OPERATING INSTRUCTIONS

This straightening iron appliance is intended for household use. This unit is designed to operate at 120/240 volts AC. Use on Alternating Current (50/60 hertz) only. This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

DUAL VOLTAGE

This straightening iron will automatically adjust to the proper voltage. Use an adapter plug with correct configuration, prior to use in outlet.

STRAIGHTENING BASICS

Plug the straightening iron cord into any household outlet (120/240V). Press ON/OFF button. Red light will blink until it reaches desired temperature setting and then becomes soild. To activate Turbo, press button and green light will go on and increase plate temperatures up to 15-20 degrees C. To turn off, press ON/OFF button again until red light goes out. Never leave your straightening iron on and unattended. However, should you fail to turn the unit off, it will shut itself off automatically within 60 minutes.

WARNING: The straightening iron's ceramiccoated plates will get very hot within a few seconds and should not be placed in contact with the skin after the straightening iron has been turned on.

Start with a hair section that is 2" (5 cm) wide and no more than 1/2" (1.25 cm) thick. Open the iron and place a hair section between the two hot plates, close to the scalp. Trap hair between the plates by firmly squeezing the handles together. While maintaining the tension, slowly pull the unit down along the hair section toward the end of hair. At the end of hair section, release the pressure on the handle and allow the hair section to slide out Repeat process on additional sections of hair until you achieve the hair style you desire. It may be necessary to repeat process on certain areas, depending on the texture of your hair. Some experience is necessary when learning to use this straightening iron. After using iron several times, you will learn the ideal way to straighten and style your hair easily.

For faster styling results, we have added a unique optional Turbo Heat on/off feature. Press the Turbo button to deliver up to 20°C/36°F more heat in the highest setting, for maximum styling performance.

NOTE: Please refer to the temperature setting guide for heat settings.

STYLING WITH THE NEW EASY-GLIDE FLOATING CERAMIC-COATED PLATES

The plates of your new straightening iron are designed with a little give, to "float" in your iron This provides better contact with hair, eliminating gaps for straighter results. The easy-glide ceramic surface is the one of the latest - and best-technological advances in hair appliances The ceramic even heat distribution produces the ultimate in healthy, shiny, silky looking hair. You'll find that hair glides easily over the surface of the plates as you're straightening, and that it is

easier to clean styling products residue, etc. off the plates after each use. The ceramic surface also helps smooth down flyways and frizzies. As you smooth your hair, heat is evenly distributed so that the style you create has a salon-perfect, silky smooth, shiny finish. Hair also glides right through the plates after it's straightened And that's not all. Conair's professional salon standards of engineering provide you with a Uniform Heat Recovery System to maintain the straightening iron at a constant temperature. A constant surge of power ensures that heat is

continuously delivered for optimal styling results, unlike other units that lose heat during use. It provides consistent styling power so that every strand of hair is set with the same level of heat for uniform results and a perfect finish. Ceramic technology is a pleasure to work with.

makes styling your hair easier and provides professional results.

USING INSTANT HEAT. THE 25 VARIABLE TEMPERATURE SETTINGS AND UNIFORM HEAT RECOVERY SYSTEM

This straightening iron features Conair's Instant Heat technology. It quickly heats up to the temperature you've selected for your hair type and is then ready to use.

Within this Instant Heat technology there are 25 temperature settings for every type of hair, from the finest to the curliest and most resistant.

Temperature Setting Guide

TEMP. CONTROL	HAIR TYPE
Low I-8	Delicate, thin, easy-to-straighten hair
Medium 9-14	Average to thick or treated hair
Med-High 15-20	Thick or wavy hair
High 21-25	Hard-to-straighten hair
Turbo Heat™	Up to 20°C/36°F burst of heat for difficult styling spots

TURNS CURLS INTO SMOOTH HAIR IN SECONDS



Before

After

GET TO KNOW YOUR CERAMIC STRAIGHTENING IRON



USER MAINTENANCE

Your straightening iron is virtually maintenancefree. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION


NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections.



KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unpluaaed.

> **ALWAYS UNPLUG** SMALL APPLIANCES

LIMITED TWO-YEAR WARRANTY

Conair will repair or replace, at our option, your appliance free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below, together with your sales slip and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES. OBLIGATIONS. OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SHALL BE LIMITED IN DURATION TO THE 24-MONTH DURATION **OF THIS WARRANTY.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to vou.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY. EXPRESS OR IMPLIED. WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

SERVICE CENTER

CONAIR CORPORATION Service Department 7475 N. Glen Harbor Blvd Glendale, AZ 85307 ©2010 Conair Corporation

For info on any Conair or Infiniti by Conair product, call: 1-800-3-CONAIR or visit us on the web at: www.conair.com

For your safety and continued eniovment of this product, always read the instruction book carefully before using.



Instruction & Styling Guide Model CS19VCS





