MARGARITA MANIA™

MMA-600 Series



FOR HOUSEHOLD USE ONLY **READ THESE INSTRUCTIONS BEFORE USING THIS** UNIT! SAVE THESE INSTRUCTIONS!

IMPORTANT PRECAUTIONS

Appliance Specifications:

. 350 Watts 120V / 60HZ

Important Precautions to Remember:

- A. NEVER immerse the MARGARITA MANIA[™] base or cord in water.
- B. NEVER use near water.
- C. NEVER leave unit unattended if used near children.
- D. NEVER use a scouring pad on the MARGARITA MANIA. ™
- E. NEVER use an abrasive sponge or harsh cleaning products on the MARGARITA MANIA. $^{\rm TM}$
- F. NEVER use for anything other than what this item was intended.
- G. Avoid contact with moving parts.
- H. DO NOT operate this appliance with a damaged cord or plug or in the event the appliance ever malfunctions.
- I. DO NOT place motor base in dishwasher.
- J. Keep out of reach of children.
- K. Unplug MARGARITA MANIA[™] from electrical outlet when not in use and before cleaning. Remove plug by gripping the plug body and pulling out of the outlet. Never yank or twist cord to unplug the unit.
- L. This appliance is NOT A TOY
- M. This appliance is not intended for use by young children or infirm persons without supervision.

IMPORTANT SAFE GUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS before operating this MARGARITA MANIA™

- Do not use outdoors, FOR HOUSEHOLD USE ONLY.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the Risk of electrical shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.
- To protect against electrical shock, do not immerse cord, plugs or unit in water.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug. Should the appliance malfunction or become damaged, return the appliance to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment or send back to company as stated in this booklet in the warranty.
- Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the Margarita Mania[™]. A scraper may be used but must be used only when the Margarita Mania[™] is not running.

IMPORTANT SAFE GUARDS (Continued)

- Blades are sharp. Handle carefully.
- Install the blender pitcher onto blender base (do not reach hands inside of blender as the blades are sharp).
- To reduce the risk of injury, never place blending blades on base without pitcher properly attached.
- Clean all parts of the Margarita Mania[™] prior to use.
- Always operate Margarita Mania[™] with ice compartment lid in place.
- Check the ice shaving chamber for presence of foreign objects before using.
- The appliance manufacturer does not recommend the use of accessory attachments. This will risk injuries.
- Never place fingers or other utensils into feed or discharge areas.
- The cord should be arranged so that it will not drape over the table or counter top in such a way where it can be pulled on by children. This should also reduce the risk resulting from becoming entangled or tripping.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Before plugging your unit into the main electrical supply, make sure the voltage corresponds to that indicated on the maker's nameplate.
- DO NOT attempt to move the MARGARITA MANIA[™] while the unit is in operation.
- Do not use this appliance for other than intended use.
- A unit that is plugged into an outlet should not be left unattended.
- Check the Ice shaving chamber for presence of foreign objects prior to use.
- This is not a commercial unit. Do not leave unit running for more than 3 minutes at a time.
- Make sure the glass pitcher with blender base is properly attached before inserting into MARGARITA MANIA[™] base unit.

PRE-USE PREPARATION AND ASSEMBLY

Prepare for first use by thoroughly washing the clear glass pitcher and lid, blending blade, and base, ice tray, clear ice cover and water reservoir in warm sudsy water and thoroughly dry.

DO NOT put the motor base in water. To clean motor base when needed, using a damp cloth to wipe exterior should be sufficient, followed by drying with a clean dry towel. (See Parts Breakdown on page 3).

- 1. Check the blending base of the glass pitcher to confirm the mixing blade and rubber washer are in place and the base has been properly attached.
- 2. Set the pitcher lid on the mouth of the pitcher. NOTE: The ice shaving chute goes up and down to allow for the insertion of the pitcher. Tip the pitcher slightly as you insert the mouth of the pitcher under the ice shaving chute, pushing upward and simultaneously set the pitcher base onto the blending gear. (See Breakdown illustration on page 3)
- 3. To remove the clear ice cover, push in the two large tabs located on one side of the clear lid while you lift the cover out. This allows the two extruding tabs to back out of their receptor holes in the ice tray. (See photo illustration C, on page 4)


PRE-USE PREPARATION AND ASSEMBLY (Continued)

- To remove the ice tray located on top of the motor base, push in the tab located at the top rear of the MARGARITA MANIA[™] motor base while lifting up. (See photo illustration C, on page 4)
- 5. The water reservoir is located at the rear side of the motor base. It is removable and snaps in and out for easy cleaning. (See illustration A, below)

A

PARTS BREAKDOWN

- A. Ice Shaving Chamber
- B. Ice Shaving Chute
- C. Ice Compartment Lid
- D. Ice tray
- E. Blending blade and base
- F. Blending gear
- G. Pitcher and lid
- H. Power and function selection Buttons



Н

SPECIAL FEATURES

Your MARGARITA MANIA[™] is a frozen drink machine that will make perfect frozen drinks such as margaritas, daiquiri or smoothies every time!

- Your MARGARITA MANIA[™] has a generous 56 ounce glass pitcher with liquid measurements on the side, and is ideal for small groups or parties.
- Choice of ice shaving alone, blending alone or both ice shaving and blending combined functions as well as a power on/off button.
- Uses ice cubes.
- The MARGARITA MANIA[™] is an ideal addition for your home.
- Sturdy and attractive thin upright design will Take a limited amount of space on the counter.
- Motor base has a rear water reservoir. Melting ice is channeled into reservoir to prevent watered-down margaritas and other frozen drinks.
- Cord storage is also located at the back.






OPERATING YOUR MARGARITA MANIA™

Now that you have pre-cleaned and reassembled your MARGARITA MANIA $^{\rm IM},$ making perfect frozen drinks is both easy and fun!

Follow the steps 2 through 4 in Pre Use Preparation and Assembly, on pages 2 and 3, to prepare the MARGARATOR MANIA $^{\rm M}$ for use.

- A. Fill the pitcher with your favorite liquor, mix or fruit (or you may choose to select to follow one of the recipes included in this booklet). Put the lid on the pitcher, and set the pitcher in place (refer to page 3 pre-use preparation and assembly if needed, for proper placement and insertion).
- B. Open the ice compartment, and remove any foreign objects. Add enough cubed ice to fill but not exceed the max fill line.
- C. Close the ice compartment by lining up the lid hinges with the hinge acceptor on the motor base as instructed on page 2 (Pre Use Preparation and Assembly). Your lid should close and snap shut with the lid fitting smoothly into place.
- D. Select the desired blending and ice button you desire and push in. The buttons are located on the front of your MARGARATOR MANIA. ™
 - Reading buttons left to right
 - Power On/Off
 *2. Ice Shaver
 - 3 Blender
 - *4. Ice Shaver and Blender
 - Location of locking tabs on clear ice cover
 - Location of locking tab for removing ice tray



В

- * Allow ice to shave to desired consistency.
- E. Wait until all moving parts have stopped and the unit is un-plugged from the socket before moving or cleaning the unit.

IMPORTANT INFORMATION and TIPS

- This unit is not a commercial unit. DO NOT leave unit running for more than 3 minutes at a time.
- After each use, please allow 5 minutes for unit to cool before using again, to prolong the life of the Margarita Mania™.
- Should the unit operate slowly, please turn off unit and wait 10 minutes for unit to cool down before operating. Also, at this time, make sure the shaving area is free of debris.
- DO NOT use the blending pitcher to blend ice. The hopper on top is for ice shaving.

CLEANING

1. After using your MARGARITA MANIA[™], disconnect from electrical outlet. Remove plug by gripping the plug body and pulling out of the outlet. Never yank or twist cord to unplug the unit.

CLEANING (Continued)

- 2. Thoroughly wash the clear pitcher and lid, blending blade with washer ring and base, clear ice cover and ice tray, in warm sudsy water and thoroughly dry. DO NOT put the motor-base in water. When needed, using a damp cloth to wipe exterior should be sufficient.
- 3. Once washing and thorough drying is complete, reassemble your MARGARITA MANIA[™]. Wind the cord and return to the convenient storage location at the rear of motor base. Now your MARGARITA MANIA[™] is ready to use again.

Easy as 1 -2 -3, easy to use, easy to clean, easy to store!

RECIPE IDEAS

Use your imagination to create many different drinks with your MARGARITA MANIA[™]. We have provided a few recipes below. You can adjust the ingredients to your particular taste, or create your own. Keep in mind, that if you have a recipe for a drink made for 'one' – your MARGARITA MANIA[™] has the capacity for ten – 8 oz. drinks – so adjust your recipes accordingly.

Basic Margarita (Serves 1)

2 shots tequila 1 shot Triple Sec 1 1/2 Cups Margarita Mix 1 Shot freshly squeezed Lime Juice Salt & Lime wedge for glass

LEGEND 1 Shot = 1 1/2 ounces (45 ml) 1 Cup (275 ml) = 5 Shots

Strawberry Mango Margarita (Serves approx. 15)

1 1/2 cups tequila 7 cups mango juice *8 - 16 oz fresh strawberries (cut / quartered) Salt rim of glasses (if desired) *frozen strawberries can be substituted for fresh strawberries.

Strawberry Daiquiri Slush with Honeydew Melon (Serves 4)

1 (12 oz) pkg. frozen unsweetened Strawberries 1 1/3 cup light corn syrup 2/3 cup white rum 3 Tbs fresh lime juice 1/2 ripe Honeydew Melon, seeded and fresh, cut into 1/2 inch cubes Lime slices for garnish

Orange Julius Slush (Serves 2)

2 1/2 oz. Malibu Rum 12 oz. Orange Juice 2 1/4 oz. Vodka

Apricot Smoothie (Serves 2)

2 oz. White Rum 1 oz. Triple Sec 6 oz. Apricot Juice 1/2 oz. Cream

Kahlua Colada (Serves 1)

1 1/2 oz. Kahlua 1/2 oz. Rum 2 1/4 oz. Cocoanut Crème 2 1/4 os. Pineapple Juice 1/2 oz. Crème

RETURNS & WARRANTY

SHOULD YOUR UNIT NOT WORK OR IS DAMAGED WHEN YOU FIRST TAKE IT OUT OF THE BOX, PLEASE RETURN IT TO THE PLACE OF PURCHASE IMMEDIATELY.

Should you have any questions, please contact us via email or at the customer service number listed below between the hours of 8:00 AM and 5:00 PM, Monday through Friday, Central Standard Time.

Distributed by:

Nostalgia Products Group LLC 1471 Partnership Dr. Green Bay, WI 54304-5685

Customer Service

Phone: (920) 347-9122 Web: www.nostalgiaelectrics.com

Customer Service Inquiry

To submit a Customer Service inquiry, go to <u>www.nostalgiaelectrics.com</u> and fill out the <u>Customer Service Inquiry</u> form and click the Submit button. A representative will contact you as soon as possible.

MARGARITA MANIA™

MMA-600 Series Limited Warranty

This appliance is designed and built to provide many years of satisfactory performance under normal household use. The distributor pledges to the original owner that should there be any defects in material or workmanship during the first 90 days of purchase, we will repair or replace the unit at our option. Our pledge does not apply to damages caused by shipping, mishandling or unit being dropped. A product deemed defective either from manufacturing or being mishandled is up to the distributor's discretion. To obtain service under this warranty, return this unit to Nostalgia Products Group, LLC at the address above, shipping prepaid. You must also include a copy of the original receipt along with your name, address and phone number. Include a description of the defect along with the date you purchased the product.

This warranty does not apply to re-manufactured merchandise.

Please read these instructions carefully. Failure to comply with these instructions, damages caused by improper replacement parts, abuse or misuse will void this pledge to you and is being made in place of all other expressed warranties.



Nostalgia Products Group LLC 1471 Partnership Dr. Green Bay, WI 54304-5685

Visit Us Online at www.nostalgiaelectrics.com

©2009 Nostalgia Products Group LLC

Rev.6/16/09