







# Slideshow fun on your TV

# in High Definition quality

See, share and relive your memories with the Philips PhotoViewer. The easiest way to view your digital photos in High Definition quality on your TV - without a PC.

# Top quality photo viewing on your TV

- Enjoy crisp photos in brilliant High Definition
- Add MP3 soundtracks to your photo slideshows
- Designed to match your television

# Easy to set up and use

- Connect directly to your TV with the cable supplied
- Accepts 19 memory card formats, USB sticks and hard disks
- No PC required and no software to install
- Operate your PhotoViewer from across the room

# **Customize your slideshows**


- Create a slideshow with the on-screen slideshow manager
- · Play slideshows or browse single photos or thumbnails











# **Specifications**

# Connectivity

- Universal Card Reader
- USB: 2 x USB 2.0 (host)
- Audio Output Analog: Stereo (Red/White cinch)
   Video Output Analog: Component X Ph Pr
- Video Output Analog: Component Y Pb Pr (cinch), Composite video out, S-video, Support HDMI -adapter not incl
- Video resolution: SD quality, HD quality (720p, 1080i), PAL/NTSC

#### **Multimedia Applications**

- Multimedia connections: 19-in-1 card reader, USB memory class device
- Memory Card Types: Compact Flash type I, Compact Flash type II, Memory Stick, Memory Stick Duo, Memory Stick Pro, Memory Stick Pro Duo, Msmicro (M2), MS-ROM, Microdrive, MultiMedia Card (MMC), Micro MMC, RS-MMC, Mobile MMC, MMC Plus, Secure Digital Card (SD), Micro SD (T-Flash), Mini-SD, SDHC, Xd
- (SD), Micro SD (T-Flash), Mini-SD, SDHC, Xd
   Supported USB devices: USB flash drive, External USB hard disk, Epson photo printers, See www.philips.com/welcome
- Playback Formats: JPEG Still pictures, MP3

#### Convenience

- Remote control: included
- Photo format supported: JPEG photo, Up to 65
- Megapixels

  Multiple viewing options: Thumbnail browse, Full screen browse, Slideshow
- Slideshow management: Create slideshow
- Slideshow setting: Random, Sequential, Transition effect, Timing, Add MP3 soundtracks
- Language available: UI: English, French, German, Dutch
- Firmware upgradeable: Firmware upgradeable via

## USB

#### Accessories

• Included Accessories: AC-DC Adapter, Component Video cable, Audio/Video cable, Remote Control, Batteries for remote control, User Manual, Quick start guide, Stand

#### Power

Power supply: 100-240VAC, 50/60Hz

#### Miscellaneous

- Color product: High gloss piano black
- Color stand: Brilliant pearl

#### **Product dimensions**

- Product dimensions (W x H x D): 20 x 3 x 12 cm
- Weight: 0.3 kg

#### Packaging dimensions

- Packaging dimensions (W x H x D): 23 x 15.3 x 12.3 cm
- Nett weight: 1.143 kg
- Gross weight: 1.3 kg
- Tare weight: 0.157 kg
- EAN: 87 12581 35148 9
- Type of shelf placement: Laying
- Number of products included: I
- Packaging type: Carton

#### **Outer Carton**

- Outer carton (L x W x H): 32.4 x 26.5 x 25.1 cm
- Nett weight: 4.572 kg
- Gross weight: 5.8 kg
- Tare weight: 1.228 kg
- EAN: 87 12581 37809 7
- Number of consumer packagings: 4

# SPV3000/05

# **Product highlights**

# Direct connection to TV

The PhotoViewer is easily connected to your TV using the cables supplied. Once it is plugged in, you are ready to go. Now you can use your TV as a large photo frame or as a slideshow to share your memories.

#### **High Definition quality**

By using a TV with a high-definition TV input to display your digital photos, you'll enjoy crisp and sharp High Definition quality (up to 1080i). This product requires component video connection for high-definition playback, as this produces higher picture quality more than traditional connection. Of course, you can also use the composite video or s-video connection on your TV to view your photos in standard definition.

#### Universal card slots and USB

You can use memory cards from digital cameras, mobile phones and PDAs. The memory card slots accept 19 card types, including Compact Flash I/II (CF), SD card, Multi Media Card (MMC), Memory Stick (MS), Memory Stick Pro (MS Pro), Micro Drive and xD. The USB connectors allows you to connect USB mass storage devices like memory sticks and hard disks.

### No PC required

The Philips PhotoViewer enables you to view and enjoy your photos conveniently and easily on the TV screen without the need for a computer. You simply remove the storage card from your camera, insert in the viewer and instantly view your photos directly on your TV in impressive full-screen size. It's very straightforward; you plug it in and it works!

#### Add music to slideshows

To make sharing photos with family and friends more fun you can run a photo slideshow with music playing in the background. This Philips product supports simultaneous playback of JPG/JPEG pictures and MP3 music. It is not even necessary to store the music and image files on the same card or USB mass storage device. You simply select suitable MP3 music to accompany your slideshow of JPG/ JPEG pictures.

#### Designed for TV

The simple, elegant styling of the PhotoViewer complement today's new TVs. If you prefer, you can place the PhotoViewer vertically in the stand supplied for an alternative space-saving solution.

#### **Create slideshows**

The slideshow manager is a quick and easy-to-use tool that helps you to create your own personalized slideshows. You can set up and adjust the frequency, select transition effects, opt to shuffle your photos and add music for personalized slideshows.

#### **Multiple viewing options**

The multiple viewing options give you the freedom to display your photos one image at a time, in thumbnail mode for quick easy searches, or a slideshow of your most treasured photos. You can zoom, rotate or mark the photos by using the remote control.



Issue date 2008-02-22

© 2008 Koninklijke Philips Electronics N.V. All Rights reserved.

Electronics N.V. or their respective owners.

Version: 2.10.9

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips

12 NC: 8670 000 32388 EAN: 87 12581 35148 9

www.philips.com