


For Model: KBC024LSBX02

(Black Cabinet)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: KBC024LSBX02

(Black Cabinet)


Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	2300277	Use & Care Guide
	4344901	Wiring Diagram
2		Cabinet (Not A Service Part)
3	4344739	Lens, Light
4	4344740	Bulb, Light
5	4344746	Heater, Defrost
6	4344747	Heat Shield
7	4344761	Grille
8	4344762	Plate, Bottom
9	4344763	Foot, Leveling
10	W10204638	Brace, Support
11	4344898	Control Box
12		Frame, Side
	4344789	Left Side
	4344790	Right Side
13	4344771	Bracket, Grille
14	W10239395	Evaporator Fan Assembly
15	4344860	Thermostat
16	4344768	Knob, Thermostat
17	4344767	Switch, Plunger
18	4344826	Screw
19	W10243104	Screw
20	4344819	Clip, Grille
21	4344825	Screw
22	4344823	Seal
23		Frame, Support
	4344821	Right
	4344820	Left
24	4344824	Clip, Harness
25	4344857	Harness, Wire
26	4344826	Screw
27	4344792	Thermal Fuse
28	4344793	Screw
29	4344791	Screw
30	4344783	Fan Blade
31	4344878	Screw
32	4344865	Evaporator Fan Motor
33	4344877	Harness, Wire
34	4344832	Screw, Ground
35	4344778	Grommet, Fan Motor
36	4344899	Bracket, Motor
37		Evaporator (Not Serviced)
38	4344858	Switch, Light
39	4344917	Transformer Cable
40	W10238027	Temperature Sensor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Model: KBC024LSBX02

(Black Cabinet)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Model: KBC024LSBX02
(Black Cabinet)

Illus. No.	Part No.	DESCRIPTION
1	W10238032	Wine Rack Top & Middle
2	4344866	Rubber Support
3	W10238029	Rail Assembly
4	W10187313	Wine Rack, Lower Ladder, Shelf
5	4344842	Left Side
	4344843	Right Side
6	4344794	Screw
7	4344795	Washer
8	W10239367	Shelf Support
9	4344851	Screw
10	4344882	Trim, Top And Middle Racks
11	4344867	Rubber Support
12	W10163279	Trim, Lower Rack Support, Bumper
13	4344886	Left
	4344885	Right
14		Screw
	4344915	Left
	4344914	Right
15	W10238033	Shelf, Large
16	4344871	Glass, Shelf
17	4344868	Shelf, Small
18	4344869	Glass, Shelf
19	4344872	Trim, Shelf
20	4344873	Seal, Rear
21	4344874	Seal, Side (2)
22	4344875	Seal, Front
23	W10239364	Shelf Support
24	W10239371	Shelf Support
25	W10239368	Shelf Support
26	W10162986	Screw W/Washer
27	W10238187	Top Cover
28	W10238184	Bottom Cover
29	W10238024	Transformer Cable
30	W10238026	Sensor Assy
31	W10238025	Sensor Assy, Top
32	W10238028	Extension Cable
33	W10238180	PCB Display Board


Following Parts Not Illustrated

W10204809 Screw, Cover
W10238031 LED Spacer
W10238384 Seal
W10238189 Support
W10239385 Support Spacer
W10243273 Screw, Support
W10243310 Screw, Support
W10243312 Screw, LED

DOOR PARTS

For Model: KBC024LSBX02

(Black Cabinet)



Illus. No.	Part No.	DESCRIPTION
1	4344891	Door Assembly (Includes Gasket)
2	W10162992	Washer/Bottom
3	W10163191	Gasket-Push Plate
4	4344787	Hinge Bottom
5	4344754	Hinge, Top
6	4344804	Spacer, Top Trim
7	4344798	Spacer Bottom Hinge

Illus. No.	Part No.	DESCRIPTION
8	4344757	Actuator, Switch
9	4344802	Door Stop
10	4344852	Door Gasket
11	4344760	Washer
12	4344803	Spacer, Door
13	4344796	Screw
14		Screw, Lower Hinge
	4344906	Quantity 3
	W10243104	Quantity 3


Illus. No.	Part No.	DESCRIPTION
15	W10204865	Screw
16	4344800	Screw
17	W10243123	Screw
Following Parts Not Illustrated		
	4344818	Installation Kit, Door Panel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Model: KBC024LSBX02

(Black Cabinet)



Illus. No.	Part No.	DESCRIPTION
1	W10163193	Drain Pan
2	4344773	Bracket, Defrost Timer
3	4344774	Defrost Timer
4	4344797	Screw
5	4344776	Start Device
6	W10238066	Mounting Plate, Compressor
7	4344778	Grommet, Fan Motor
8	4344779	Grommet, Compressor
9	4344780	Bolt, Compressor
10	4344781	Fan Motor, Condenser

Illus. No.	Part No.	DESCRIPTION
11	4344782	Baffle, Air
12	4344783	Fan Blade
13	4344784	Bracket, Motor
14	4344785	Bracket, Motor
15	4344786	Cover, Rear
16	4344837	Capacitor
17	4344836	Clip
18	W10163276	Trap, Drain
19	4344861	Power Cord
20	4344829	Cable Tie
21	W10163273	Drier
22	4344907	Trim Edge
23	W10238022	Clip
24	W10163274	Pad-Rubber
25	4344826	Screw

Illus. No.	Part No.	DESCRIPTION
26	4344825	Screw
27	4344832	Screw
28	4344775	Compressor (Includes Items 5, 8, 16, 17 & 21)
29	4344834	Screw
30	4344833	Screw
31	W10238070	Transformer
32	W10163278	Thermostat
33	4344864	Bracket, Thermostat

REFRIGERANT CHARGE

3.5 Ounces
(R-134A)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST