



Illustrated Parts List

Model Series

12S900

TYPE NUMBERS
0100 through 2732.

TABLE OF CONTENTS

Air Cleaner	8
Alternator	11
Blower Housing	5
Camshaft	2
Carburetor	9
Carburetor Overhaul Kit	9
Controls	10
Covers/Guards	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	11
Exhaust System	7
Flywheel	5
Fuel Supply	6
Gasket Set - Engine	4
Gasket Set - Valve	3
Governor Spring	10
Ignition	11
Lubrication	6
Operator's Manual	2
Piston/Rings/Connecting Rod	2
Rewind Starter	5
Sump	4
Thermostat	10
Valves	3
Warning Label	2

Not for reproduction

PRINTED IN U.S.A.



COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.








1319 WARNING LABEL

REQUIRED when replacing parts with warning labels affixed.


1036 EMISSIONS LABEL

1058 OPERATOR'S MANUAL

1330 REPAIR MANUAL




Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.






Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.

12S900



718 




718 








358 ENGINE GASKET SET




Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.




Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.




Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.








Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.




Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.



Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.



Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.



Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.

12S900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	798947	Cylinder Assembly	16	796467	Crankshaft	23	796619	Flywheel
3	299819S	Seal-Oil (Magneto Side)			Used on Type No(s). 0123, 0139, 0142, 0143, 0145, 0148, 1411, 1463, 1473, 2139, 2411, 2463.			(Aluminum) Used on Type No(s). 0100, 0124, 0126, 0127, 0129, 0132, 0134, 0135, 0136, 0137, 0140, 0141, 0144, 0146, 0149, 0150, 0152, 0153, 0154, 0156, 0161, 0162, 0707, 0732, 1257, 1368, 1369, 1563, 1564, 1567, 2127, 2129, 2141, 2144, 2145, 2732.
4	493279	Sump-Engine Used on Type No(s). 0100, 0124, 0126, 0127, 0128, 0129, 0130, 0135, 0139, 0140, 0141, 0142, 0143, 0145, 0148, 0150, 0155, 0158, 0159, 0160, 0163, 0707, 0732, 1257, 1368, 1369, 1411, 1463, 1473, 1563, 1564, 1567, 2127, 2128, 2129, 2139, 2141, 2411, 2463, 2732.			----- Note ----- 796468 Crankshaft Used on Type No(s). 0124, 0126, 0127, 0129, 0132, 0134, 0136, 0137, 0140, 0141, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 1257, 1368, 1369, 1563, 1564, 1567, 2127, 2129, 2141, 2144, 2145.			----- Note ----- 797386 Flywheel (Zinc) Used on Type No(s). 0130, 1411, 1463, 1473, 2411, 2463.
		----- Note ----- 498983 Sump-Engine Used on Type No(s). 0121, 0122, 0123, 0151.			796469 Crankshaft Used on Type No(s). 0100, 0121, 0122, 0128, 0150, 0160, 0707, 0732, 2128, 2732.	23B	796623	Flywheel (Cast Iron) Used on Type No(s). 0121, 0122, 0123, 0128, 0139, 0142, 0143, 0145, 0148, 0151, 0155, 0158, 0159, 0160, 0163, 2128, 2139.
4B	692509	Sump-Engine Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.			796924 Crankshaft Used on Type No(s). 0151.			24 222698S Key-Flywheel
5	796471	Head-Cylinder			797107 Crankshaft Used on Type No(s). 0130.			25 797302 Piston Assembly (Standard)
7	796475	Gasket-Cylinder Head			797909 Crankshaft Used on Type No(s). 0135.			----- Note ----- 797303 Piston Assembly (.020" Oversize)
11	796478	Tube-Breather			799337 Crankshaft Used on Type No(s). 0155, 0158, 0159, 0163.			
12	692232	Gasket-Crankcase						
13	793451	Screw (Cylinder Head)						
15	691680	Plug-Oil Drain (Square Socket)	17	692517	Bearing-Ball Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.			
			20	399781S	Seal-Oil (PTO Side)			
			22	691092	Screw (Crankcase Cover/Sump)			

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
26	797304	Ring Set (Standard) (Used After Code Date 09041900). ----- Note ----- 796641 Ring Set (Standard) (Used Before Code Date 09042000). 797305 Ring Set (.020" Oversize) (Used After Code Date 09041900). 796642 Ring Set (.020" Oversize) (Used Before Code Date 09042000).	37A	796534	Guard-Flywheel Used on Type No(s). 0100, 0121, 0122, 0123, 0124, 0126, 0128, 0129, 0135, 0137, 0139, 0140, 0141, 0142, 0143, 0145, 0148, 0150, 0151, 1368. ----- Note ----- 796535 Guard- Flywheel Used on Type No(s). 0127, 0130, 0132, 0134, 0136, 0144, 0146, 0149, 0707, 0732, 1257, 1369, 1411, 1463, 1473.	40	692194	Retainer-Valve
27	691588	Lock-Piston Pin	37B	799155	Guard-Flywheel Used on Type No(s). 0152, 0154, 0155, 0158, 0159, 0160, 0163, 1563, 1567, 2128, 2129, 2139.	43	796650	Slinger-Governor/Oil Used on Type No(s). 0100, 0121, 0122, 0123, 0124, 0126, 0127, 0128, 0129, 0130, 0135, 0139, 0140, 0141, 0142, 0143, 0145, 0148, 0150, 0151, 0155, 0158, 0159, 0160, 0163, 0707, 0732, 1257, 1368, 1369, 1411, 1463, 1473, 1563, 1564, 1567, 2127, 2128, 2129, 2139, 2141, 2411, 2463, 2732.
28	298909	Pin-Piston			----- Note ----- 796525 Slinger- Governor/Oil Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.			
29	796470	Rod-Connecting						
32	691664	Screw (Connecting Rod)						
32A	695759	Screw (Connecting Rod)						
33	499642	Valve-Exhaust						
34	795443	Valve-Intake						
35	691304	Spring-Valve (Intake)						
36	691304	Spring-Valve (Exhaust)						
37	796536	Guard-Flywheel Used on Type No(s). 0100, 0121, 0122, 0123, 0124, 0126, 0127, 0128, 0129, 0130, 0132, 0134, 0135, 0136, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0148, 0149, 0150, 0151, 0152, 0153, 0154, 0155, 0156, 0158, 0159, 0160, 0161, 0162, 0163, 0707, 0732, 1257, 1368, 1369, 1411, 1463, 1473, 1563, 1564, 1567, 2127, 2128, 2129, 2139, 2141, 2144, 2145, 2411, 2463, 2732.						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12S900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
45	690977	Tappet-Valve	81	691740	Lock-Muffler Screw	118	494870	Jet-Main
46	694039	Camshaft	104	797622	Pin-Float Hinge			(High Altitude)
		Used on Type No(s).	117	697355	Jet-Main			Used on Type No(s).
		0100, 0121, 0122,			(Standard)			0100, 0121, 0122,
		0123, 0124, 0126,			Used on Type No(s).			0123, 0124, 0126,
		0127, 0128, 0129,			0100, 0121, 0122,			0127, 0128, 0129,
		0130, 0135, 0139,			0123, 0124, 0126,			0130, 0132, 0134,
		0140, 0141, 0142,			0127, 0128, 0129,			0135, 0136, 0137,
		0143, 0145, 0148,			0130, 0132, 0134,			0139, 0140, 0141,
		0150, 0151, 0155,			0135, 0136, 0137,			0142, 0143, 0144,
		0158, 0159, 0160,			0139, 0140, 0141,			0145, 0146, 0148,
		0163, 0707, 0732,			0142, 0143, 0144,			0149, 0150, 0151,
		1257, 1368, 1369,			0145, 0146, 0148,			0152, 0153, 0154,
		1411, 1463, 1473,			0149, 0150, 0151,			0156, 0161, 0162,
		1563, 1564, 1567,			0152, 0153, 0154,			0707, 0732, 1257,
		2127, 2128, 2129,			0156, 0161, 0162,			1368, 1369, 1411,
		2139, 2141, 2411,			0707, 0732, 1257,			1463, 1473, 1563,
		2463, 2732.			1368, 1369, 1411,			1564, 1567, 2127,
		----- Note -----			1463, 1473, 1563,			2128, 2129, 2139,
		694040 Camshaft			1564, 1567, 2127,			2141, 2144, 2145,
		Used on Type No(s).			2128, 2129, 2139,			2411, 2463, 2732.
		0132, 0134, 0136,			2141, 2144, 2145,			----- Note -----
		0137, 0144, 0146,			2411, 2463, 2732.			799604 Jet-Main
		0149, 0152, 0153,			----- Note -----			(High Altitude)
		0154, 0156, 0161,			799178 Jet-Main			Used on Type No(s).
		0162, 2144, 2145.			(Standard)			0155, 0158, 0159,
51	796596	Gasket-Intake			Used on Type No(s).			0160, 0163.
58	697316	Rope-Starter			0155, 0158, 0159,	121	796612	Kit-Carburetor
		(Cut to Required			0160, 0163.			Overhaul
		Length)						----- Note -----
60	281434S	Grip-Starter Rope						799235 Kit-Carburetor
73	798337	Screen-Rotating						Overhaul
		Used on Type No(s).						Used on Type No(s).
		0141, 2141.						0155, 0158, 0159,
75	691736	Washer						0160, 0163.
		(Flywheel)						
		Used on Type No(s).						
		0100, 0124, 0126,						
		0127, 0129, 0130,						
		0132, 0134, 0135,						
		0136, 0137, 0140,						
		0141, 0144, 0146,						
		0149, 0150, 0152,						
		0153, 0154, 0156,						
		0161, 0162, 0707,						
		0732, 1257, 1368,						
		1369, 1411, 1463,						
		1473, 1563, 1564,						
		1567, 2127, 2129,						
		2141, 2144, 2145,						
		2411, 2463, 2732.						
78	793480	Screw						
		(Flywheel Guard)						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 10054-14 Assemblies include all parts shown in frames. 02/01/2011

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
122	796595	Spacer-Carburetor	192	796631	Adjuster-Rocker Arm	216A	798944	Link-Choke
125	796608	Carburetor	202	796657	Link-Mechanical			Used on Type No(s).
		Used on Type No(s).			Governor			0155, 0158, 0159,
		0100, 0121, 0122,	209	793604	Spring-Governor	217	798900	0160, 0163.
		0123, 0124, 0126,			Used on Type No(s).			Spring-Choke Return
		0127, 0128, 0129,			0121, 0122, 0123,			----- Note -----
		0130, 0132, 0134,			0142, 0143, 0145,			799179 Spring-Choke
		0135, 0136, 0137,			0148, 0150, 0151,			Return
		0140, 0141, 0142,			0155, 0158, 0159,			Used on Type No(s).
		0143, 0144, 0145,			0163.			0155, 0158, 0159,
		0146, 0148, 0149,			----- Note -----			0160, 0163.
		0152, 0153, 0154,			796483 Spring-	222	796482	Bracket-Control
		0156, 0161, 0162,			Governor			(Manual Friction,
		0150, 0151, 0707,			Used on Type No(s).			Remote, & Fixed
		0732, 1257, 1368,			0124, 0130, 0135,			Speed Control)
		1369, 1411, 1463,			0136, 0146, 0161.	227	796487	Lever-Governor
		1473, 1563, 1564,			796484 Spring-			Control
		1567, 2127, 2128,			Governor	238	691300	Cap-Valve
		2129, 2139, 2141,			Used on Type No(s).	240	298090S	Filter-Fuel
		2144, 2145, 2411,			0100, 0128, 0132,			Used on Type No(s).
		2463, 2732.			0134, 0141, 0144,			0130, 1567.
		----- Note -----			0149, 0156, 0162,	265	690798	Clamp-Casing
		797736 Carburetor			0707, 0732, 1257,			----- Note -----
		Used on Type No(s).			1368, 1369, 1411,			691024 Clamp-Casing
		0139, 2139.			1463, 1473, 1563,			Used on Type No(s).
		799027 Carburetor			1564, 1567, 2128,			0130.
		Used on Type No(s).			2141, 2144, 2145,	267	691044	Screw
		0155, 0158, 0159,			2411, 2463, 2732.			(Casing Clamp)
		0160, 0163.			796926 Spring-	268	691025	Casing-Control Wire
133	398187	Float-Carburetor			Governor			(Cut To Required
		----- Note -----			Used on Type No(s).			Length)
		797626 Float-			0126, 0127, 0129,	269	691026	Wire-Control
		Carburetor			0137, 0139, 0140,			(Cut To Required
		Used on Type No(s).			0152, 0153, 0154,			Length)
		0155, 0158, 0159,			0160, 2127, 2129,	270	691027	Nut
		0160, 0163.			2139.			(Control Wire Casing)
134	398188	Kit-Needle/Seat	216	796485	Link-Choke	271	691028	Lever-Control
		----- Note -----			Used on Type No(s).	276	271716	Washer-Sealing
		799177 Kit-			0100, 0121, 0122,			----- Note -----
		Needle/Seat			0123, 0124, 0126,			797632 Washer-
		Used on Type No(s).			0127, 0128, 0129,			Sealing
		0155, 0158, 0159,			0130, 0132, 0134,			Used on Type No(s).
		0160, 0163.			0135, 0136, 0137,			0155, 0158, 0159,
137	796610	Gasket-Float Bowl			0140, 0141, 0142,			0160, 0163.
		----- Note -----			0143, 0144, 0145,			
		797625 Gasket-Float			0146, 0148, 0149,			
		Bowl			0150, 0151, 0152,			
		Used on Type No(s).			0153, 0154, 0156,			
		0155, 0158, 0159,			0161, 0162, 0707,			
		0160, 0163.			0732, 1257, 1368,			
163	691894	Gasket-Air Cleaner			1369, 1411, 1463,			
187	791766	Line-Fuel			1473, 1563, 1564,			
		(Cut To Required			1567, 2127, 2128,			
		Length)			2129, 2141, 2144,			
187A	796491	Line-Fuel			2145, 2411, 2463,			
		(Formed Hose)			2732.			

12S900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
291	796486	Thermostat Used on Type No(s). 0100, 0121, 0122, 0123, 0124, 0126, 0127, 0128, 0129, 0130, 0132, 0134, 0135, 0136, 0137, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0148, 0149, 0150, 0151, 0707, 0732, 1257, 1368, 1369, 1411, 1463, 1473.	304	796692	Housing-Blower (Rewind Start) Used on Type No(s). 0100, 0121, 0122, 0123, 0124, 0126, 0128, 0129, 0135, 0137, 0139, 0140, 0142, 0143, 0145, 0148, 0150, 0151, 0152, 0154, 0155, 0158, 0159, 0160, 0163, 1368, 1563, 1567, 2128, 2129, 2139.	304A	798333	Housing- Blower (Electric Start) Used on Type No(s). 0141, 1411, 1463, 1473. ----- Note ----- 799249 Housing- Blower (Electric Start) Used on Type No(s). 2141, 2411, 2463. 799249 Housing- Blower (Electric Start) (Required for use with replacement Starter Motor Ref# 309 799241) Used on Type No(s). 0141, 1411, 1463, 1473.
291A	798938	Thermostat Used on Type No(s). 0152, 0153, 0154, 0155, 0156, 0158, 0159, 0160, 0161, 0162, 0163, 1563, 1564, 1567, 2127, 2128, 2129, 2141, 2144, 2145, 2411, 2463, 2732.			----- Note ----- 796693 Housing- Blower (Electric Start) Used on Type No(s). 0127, 0132, 0134, 0136, 0144, 0146, 0149, 0707, 0732, 1257, 1369. 797384 Housing- Blower (Electric Start) Used on Type No(s). 0130. 798945 Housing- Blower (Electric Start) Used on Type No(s). 0153, 0156, 0161, 0162, 1564, 2127, 2144, 2145, 2732. 798945 Housing- Blower (Electric Start) (Required for use with replacement Starter Motor Ref# 309 799241) Used on Type No(s). 0127, 0132, 0134, 0136, 0144, 0146, 0149, 0707, 0732, 1257, 1369. 798946 Housing- Blower (Required for use with replacement Starter Motor Ref# 309 799241) (Electric Start) Used on Type No(s). 0130.			
300	796495	Muffler-Exhaust Used on Type No(s). 0100, 0121, 0122, 0123, 0124, 0126, 0127, 0128, 0129, 0130, 0132, 0134, 0135, 0136, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0148, 0149, 0150, 0151, 0707, 0732, 1257, 1368, 1369, 1411, 1463, 1473.						
300A	798940	Muffler-Exhaust Used on Type No(s). 0152, 0153, 0154, 0155, 0156, 0158, 0159, 0160, 0161, 0162, 0163, 1563, 1564, 1567, 2127, 2128, 2129, 2139, 2141, 2144, 2145, 2411, 2463, 2732.						

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	799241	Motor-Starter Used on Type No(s). 0153, 0156, 0161, 0162, 1564, 2127, 2141, 2144, 2145, 2411, 2463, 2732. ----- Note ----- 799241 Motor-Starter (Requires Blower Housing Ref# 304 798945 and Flywheel Guard Ref# 37B 799242) Used on Type No(s). 0127, 0132, 0134, 0136, 0144, 0146, 0149, 0707, 0732, 1257, 1369. 799241 Motor-Starter (Requires Blower Housing Ref# 304 798946 and Flywheel Guard Ref# 37B 799242) Used on Type No(s). 0130. 799241 Motor-Starter (Requires Blower Housing Ref# 304A 799249 and Flywheel Guard Ref# 37B 799242) Used on Type No(s). 0141, 1411, 1463, 1473.	333	796499	Armature-Magneto Used on Type No(s). 0100, 0124, 0126, 0127, 0129, 0132, 0134, 0135, 0136, 0137, 0140, 0141, 0144, 0146, 0149, 0150, 0152, 0153, 0154, 0156, 0161, 0162, 0707, 0732, 1257, 1368, 1369, 2127, 2129, 2141, 2144, 2145, 2411, 2732. ----- Note ----- 796500 Armature- Magneto Used on Type No(s). 0121, 0122, 0123, 0128, 0130, 0139, 0142, 0143, 0145, 0148, 0151, 0155, 0158, 0159, 0160, 0163, 1411, 1463, 1473, 2128, 2139, 2463.	337	692051	Plug-Spark Used on Type No(s). 0100, 0121, 0122, 0123, 0126, 0127, 0129, 0132, 0139, 0141, 0142, 0143, 0144, 0145, 0150, 0151, 0152, 0153, 0153, 0155, 0158, 0159, 0707, 0732, 1257, 1411, 1563, 1564, 1567, 2127, 2129, 2139, 2141, 2144, 2145, 2411, 2732. ----- Note ----- 692720 Plug-Spark Used on Type No(s). 0124, 0128, 0130, 0134, 0135, 0136, 0137, 0140, 0146, 0148, 0149, 0154, 0156, 0160, 0161, 0162, 0163, 1368, 1369, 1463, 1473, 2128, 2463.
332	690662	Nut (Flywheel)	333A	799645	Armature-Magneto Used on Type No(s). 1563, 1564, 1567.	347	795333	Switch-Rocker Used on Type No(s). 0121, 0122, 0123, 0142, 0143, 0145, 0148, 0151.
			334	793454	Screw (Magneto Armature)	347A	798939	Switch-Rocker Used on Type No(s). 0155, 0158, 0159, 0160, 0163.

12S900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
356	692390	Wire-Stop Used on Type No(s). 0100, 0124, 0126, 0127, 0128, 0129, 0132, 0134, 0135, 0136, 0137, 0139, 0140, 0141, 0144, 0146, 0149, 0150, 0152, 0153, 0154, 0156, 0161, 0162, 0707, 0732, 1257, 1368, 1369, 1563, 1564, 1567, 2127, 2128, 2129, 2139, 2141, 2144, 2145, 2732.	445	795066	Filter-Air Cleaner Cartridge	564A	799026	Screw (Control Cover) Used on Type No(s). 0155, 0158, 0159, 0160, 0163.
356A	797743	Wire-Stop Used on Type No(s). 0130.	455	796615	Cup-Flywheel Used on Type No(s). 0121, 0122, 0123, 0128, 0139, 0142, 0143, 0145, 0148, 0151, 0155, 0158, 0159, 0160, 0163, 2128, 2139.	601	791850	Clamp-Hose
356B	692602	Wire-Stop Used on Type No(s). 0121, 0122, 0123, 0142, 0143, 0145, 0148, 0151.	474	794103	Alternator Used on Type No(s). 0127, 0130, 0141, 0153, 1411, 1463, 1473, 2127, 2141, 2411, 2463.	604	799024	Cover-Control Used on Type No(s). 0155, 0158, 0159, 0160, 0163.
356C	695630	Wire-Stop Used on Type No(s). 0121, 0122, 0123, 0142, 0143, 0145, 0148, 0151.	497	691044	Screw (Stopswitch Bracket) Used on Type No(s). 0121, 0122, 0123, 0142, 0143, 0145, 0148, 0151.	608	796497	Starter-Rewind
356F	798332	Wire-Stop Used on Type No(s). 0130, 1411, 1463, 1473, 2411, 2463.	505	793515	Nut (Governor Control Lever)	613	796496	Screw (Muffler)
356G	798942	Wire-Stop Used on Type No(s). 0155, 0158, 0159, 0160, 0163.	523	796503	Dipstick	615	796674	Retainer-Governor Shaft
356H	798943	Wire-Stop Used on Type No(s). 0155, 0158, 0159, 0160, 0163.	524	692296	Seal-Dipstick Tube	616	798327	Crank-Governor
358	799495	Gasket Set-Engine	525	796502	Tube-Dipstick	621	692310	Switch-Stop
363	19069	Puller-Flywheel	535	797301	Filter-Air Cleaner Foam Used on Type No(s). 0155, 0158, 0159, 0160, 0163.	623	793628	Seal-O Ring (Carburetor Spacer)
365	793458	Screw (Carburetor)	536	799025	Cleaner-Air Used on Type No(s). 0155, 0158, 0159, 0160, 0163.	627	796702	Bracket-Stopswitch Used on Type No(s). 0121, 0122, 0123, 0142, 0143, 0145, 0148, 0151.
383	19576S	Wrench-Spark Plug	562	793514	Bolt (Governor-Control Lever)	635	66538S	Boot-Spark Plug
404	690272	Washer (Governor Crank)	564	690351	Screw (Control Cover) Used on Type No(s). 0155, 0158, 0159, 0160, 0163.	635A	799646	Boot-Spark Plug Used on Type No(s). 1563, 1564, 1567.
						668	797373	Spacer Used on Type No(s). 0130.
						668A	797383	Spacer Used on Type No(s). 0130.
						670	793485	Spacer-Fuel Tank
						676	692010	Deflector-Muffler
						676A	799187	Deflector-Muffler Used on Type No(s). 0160, 2128.
						677	690661	Screw (Muffler Deflector)

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
10054-18 Assemblies include all parts shown in frames. 02/01/2011

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
697	691127	Screw (Drive Cap) Used on Type No(s). 0127, 0130, 0132, 0134, 0136, 0141, 0144, 0146, 0149, 0153, 0156, 0161, 0162, 0707, 0732, 1257, 1369, 1411, 1463, 1473, 1564, 2127, 2141, 2144, 2145, 2411, 2463, 2732.	750	691147	Screw (Oil Pump Cover) Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.	847	796501	Dipstick/Tube Assembly
718	690959	Pin-Locating	789	792685	Harness-Wiring Used on Type No(s). 0127, 0132, 0134, 0136, 0141, 0144, 0146, 0149, 0153, 0156, 0161, 0162, 0707, 0732, 1257, 1369, 1564, 2127, 2141, 2144, 2145, 2732.	851	493880S	Terminal-Spark Plug
737	692511	Screw (Oil Filter Adapter) Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.	789A	696546	Harness-Wiring Used on Type No(s). 0130, 1411, 1473, 2411.	851A	692424	Terminal-Spark Plug
741	795755	Gear-Timing ----- Note ----- 797521 Gear-Timing Used on Type No(s). 0155, 0158, 0159, 0163.	830	796472	Stud-Rocker Arm	868	795440	Seal-Valve
742	93941	Retainer-E Ring Used on Type No(s). 0127, 0130, 0132, 0134, 0136, 0141, 0144, 0146, 0149, 0153, 0156, 0161, 0162, 0707, 0732, 1257, 1369, 1411, 1463, 1473, 1564, 2127, 2141, 2144, 2145, 2411, 2463, 2732.	832	796494	Guard-Muffler Used on Type No(s). 0121, 0122, 0123, 0124, 0126, 0127, 0129, 0132, 0134, 0135, 0136, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0148, 0149, 0150, 0151, 1368, 1369, 1411, 1463, 1473.	875	796492	Base-Air Cleaner
745	698557	Screw (Brake) Used on Type No(s). 0100, 0124, 0126, 0127, 0129, 0132, 0134, 0135, 0136, 0137, 0140, 0141, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 0707, 0732, 1257, 1368, 1369, 1563, 1564, 1567, 2127, 2129, 2141, 2144, 2145, 2732.	832A	798951	Guard-Muffler Used on Type No(s). 0152, 0153, 0154, 0155, 0156, 0158, 0159, 0161, 0162, 0163, 1563, 1564, 2127, 2129, 2139, 2141, 2144, 2145, 2411, 2463.	883	793497	Gasket-Exhaust
			836	793500	Screw (Muffler Guard)	883A	796677	Gasket-Exhaust
			837	797735	Spacer-Muffler Used on Type No(s). 0139, 2139.	886	799492	Gasket Kit-Cylinder Head Plate
			842	691031	Seal-O Ring (Dipstick Tube)	910	796498	Stud (Alternator) Used on Type No(s). 0127, 0130, 0141, 0153, 1411, 1463, 1473, 2127, 2141, 2411, 2463.
			843	691884	Sleeve-Lever Used on Type No(s). 0128, 0139, 2128, 2139.	914	794451	Screw (Rocker Arm Cover)
						921	798356	Cover-Blower Housing Used on Type No(s). 0141, 2141.
						922	692135	Spring-Brake Used on Type No(s). 0100, 0124, 0126, 0127, 0129, 0132, 0134, 0135, 0136, 0137, 0140, 0141, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 0707, 0732, 1257, 1368, 1369, 1563, 1564, 1567, 2127, 2129, 2141, 2144, 2145, 2732.
						923	796635	Brake Used on Type No(s). 0100, 0124, 0126, 0127, 0129, 0132, 0134, 0135, 0136, 0137, 0140, 0141, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 0707, 0732, 1257, 1368, 1369, 1563, 1564, 1567, 2127, 2129, 2141, 2144, 2145, 2732.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12S900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
925	796531	Cover-Linkage Used on Type No(s). 0121, 0122, 0123, 0128, 0130, 0139, 0142, 0143, 0145, 0148, 0150, 0151, 0155, 0158, 0159, 0160, 0163, 1411, 2128, 2139, 2411, 2463.	972	796489	Tank-Fuel (EVAP) ----- Note ----- 798336 Tank-Fuel (EVAP) (With Gage) Used on Type No(s). 0141, 2141.	1028	796522	Adapter-Oil Filter Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.
937	799427	Spline-Starter Used on Type No(s). 0127, 0130, 0132, 0134, 0136, 0141, 0144, 0146, 0149, 0707, 0732, 1257, 1369, 1411, 1463, 1473. ----- Note ----- 799420 Spline-Starter Used on Type No(s). 0153, 0156, 0161, 0162, 1564, 2127, 2141, 2144, 2145, 2411, 2463, 2732.	975	796611	Bowl-Float ----- Note ----- 797631 Bowl-Float Used on Type No(s). 0155, 0158, 0159, 0160, 0163.	1029	691230	Arm-Rocker
943	692514	Seal-O Ring (Oil Pump Cover) Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.	988	692515	Gasket-Oil Adapter Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.	1034	691343	Guide-Push Rod
957	796577	Cap-Fuel Tank (EVAP)	993	796473	Gasket-Cylinder Head Plate	1036		Label-Emissions (Available From A Briggs & Statton Authorized Dealer)
965	692507	Cover-Oil Pump Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.	1005	796614	Fan-Flywheel Used on Type No(s). 0121, 0122, 0123, 0128, 0139, 0142, 0143, 0145, 0148, 0151, 0155, 0158, 0159, 0160, 0163, 2128, 2139.	1055	796524	Tube-Oil Pump Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.
967	796254	Filter-Pre Cleaner	1022	796480	Gasket-Rocker Cover	1058	279946	Manual-Operator's
968	796493	Cover-Air Cleaner	1023	796479	Cover-Rocker Arm	1059	793471	Kit-Screw/Washer
969	690700	Screw (Blower Housing Cover) Used on Type No(s). 0141, 2141.	1024	692508	Pump-Oil Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154, 0156, 0161, 0162, 2144, 2145.	1095	799496	Gasket Set-Valve
			1026	796481	Rod-Push	1119	794100	Screw (Alternator) Used on Type No(s). 0127, 0130, 0141, 0153, 1411, 1463, 1473, 2127, 2141, 2411, 2463.
			1027	795990	Filter-Oil Used on Type No(s). 0132, 0134, 0136, 0137, 0144, 0146, 0149, 0152, 0153, 0154.	1212	796537	Stud (Blower Housing)
					----- Note ----- 798319 Filter-Oil Used on Type No(s). 0156, 0161, 0162, 2144, 2145.	1212A	793479	Stud (Blower Housing)
						1212B	797002	Stud (Blower Housing) (Used With Alternator Only)
						1263	697124	Reed-Breather
						1264	793453	Screw (Breather Reed)
						1319	794467	Label-Warning
						1330	276781	Manual-Repair
						1335	793481	Nut (Blower Housing)
						1375	796476	Cover-Breather/Reed
						1376	794451	Screw (Breather/Reed Cover)

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
10054-20 Assemblies include all parts shown in frames. 02/01/2011

12S900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1395	690349	Screw (Air Cleaner Base to Carburetor) Used on Type No(s). 0100, 0121, 0122, 0123, 0124, 0126, 0127, 0128, 0129, 0130, 0132, 0134, 0135, 0136, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0148, 0149, 0150, 0151, 0152, 0153, 0154, 0156, 0161, 0162, 0707, 0732, 1257, 1368, 1369, 1411, 1463, 1473, 1563, 1564, 1567, 2127, 2128, 2129, 2139, 2141, 2144, 2145, 2411, 2463, 2732.	1395A	798294	Screw (Air Cleaner Base to Carburetor) Used on Type No(s). 0155, 0158, 0159, 0160, 0163.			
			1430	796477	Gasket-Breather/Reed			

Not for
Reproduction

Not for
Reproduction

Not for
Reproduction

Not for
Reproduction

