



DO NOT RETURN THIS PRODUCT TO THE PLACE OF PURCHASE

For product questions:  
Jarden Consumer Services U.S.A.  
1-877-689-2737

[www.margaritavillecargo.com](http://www.margaritavillecargo.com)

©2010 Sunbeam Products, Inc., doing business as Jarden Consumer Solutions.  
All rights reserved. Distributed by Sunbeam Products, Inc., doing business as  
Jarden Consumer Solutions, Boca Raton, Florida 33431

Margaritaville® is a registered trademark of Margaritaville®.

Printed in China

P. N. 143640



**Model NBMGDC1XXX Series** User Manual

# IMPORTANT SAFEGUARDS

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

1. **READ ALL INSTRUCTIONS BEFORE USING.**
2. To protect against electric shock, do not immerse appliance, cord or plug in water or other liquids.
3. Close supervision is necessary when any appliance is used near children. This appliance should not be used by children.
4. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
5. Do not operate any appliance with damaged cord or plug, after the appliance malfunctions, or is dropped or damaged in any manner. Contact 1-877-689-2737 for customer service.
6. This product is not intended for outdoor placement and/or usage.
7. Do not let cord hang over the edge of a table or counter or touch hot surfaces, including the stove.
8. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
9. Extreme caution must be used when moving an appliance containing liquids.
10. Do not place on or near a hot gas, or electric burner, or in a heated oven.
11. Do not use appliance for other than intended use.
12. Please drink responsibly and obey legal drinking age laws.

## SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

### Polarized Plug

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature. Do not attempt to modify the plug in any way. Do not use an extension cord.



## WELCOME


*Congratulations on your purchase of the Margaritaville® Chillin' Pour Liquor Chiller!*

To learn more about Margaritaville® products, please visit us at [www.margaritavillecargo.com](http://www.margaritavillecargo.com).

## LIQUOR CHILLER

### PARTS LIST

- |  |   |
|--|---|
| 1 Reservoir Lid – Covers the Reservoir | 7 Power Cord Connection Port  |
| 2 Reservoir – Holds Liquids (internal) | 8 Bottle Platform – Retractable to accommodate any size bottle          |
| 3 Lever Handle – Dispenses Liquids     | 9 “Ultra-Cold” Indicator Projection Light                               |
| 4 Blue Power Indicator Light           | 10 AC Adapter – Converts AC power to DC power required by the appliance |
| 5 Dispenser – Place Glass Underneath   |   |
| 6 Removable Drip Tray – Landing Pad    |   |





## START UP

### Follow cleaning instructions before first use.

1. Place the unit on a clean dry flat surface.
2. Remove the Reservoir Lid.
3. Fill the Reservoir with up to 750ml (25 oz) of liquor or potion\*.  
To Avoid Freezing: The alcohol content should be at least 70% alcohol to 30% mixer (that's about 2 parts alcohol to 1 part non-alcoholic mixer).
4. Replace the Reservoir Lid.
5. Plug unit into standard 120volt outlet. Blue light at base of Handle indicates unit is chilling.

**NOTE:** Unit will begin chilling immediately when plugged in.

#### Room temperature potions\* will require:

2 hours to reach colder than ice temperature of 32°F (0°C).  
4 hours to get to a minimum temperature of 15°F (-9°C).

Potions\* from the freezer take minutes to achieve minimum temperature.

\*Potion – Any cocktail mixture with a minimum of 70% alcohol.

## COOL NOTE

*Compass light projects down onto landing pad when your potion is below freezing.*

## HOW TO USE


### To Dispense:

1. Place glass in center of drip tray under the Dispensing Spout.
2. Pull Handle down to dispense liquor.
3. Release Handle when glass has been filled to desired level.

### To Refill:

1. Remove Reservoir Lid.
2. Fill Reservoir with up to 750ml (25oz) of liquor or potion.
3. Replace Reservoir Lid.

**NOTE:** The 750ml (25 oz) fill line can be seen about 1 inch from the top of the reservoir as a slight indent around the reservoir.



# CLEANING AND MAINTENANCE

## Clean Up:

- Unplug unit and dispense all liquor from the reservoir.
- Run warm water through reservoir draining through dispenser nozzle.
- Drain completely for storage through dispensing nozzle. Do not invert to empty contents of reservoir.
- Do not immerse unit or electrical parts in liquid.
- Use paper towel to absorb remaining liquids inside reservoir.

## Do's & Don'ts:

- DO** follow the clean up instructions prior to your first use and after subsequent uses.
- DO** unplug the unit when not in use.
- DO NOT** place ice, frozen food, fruits, or juice with pulp into liquid reservoir.
- DO NOT** fill with non-alcoholic drinks as they will freeze. If this occurs just unplug the unit to thaw and rinse. Then refill with your favorite liquor or potion\*!

## Troubleshooting:

- Power Indicator Light not on:**  
Check that the AC Adapter plug is firmly seated into the Power Cord Connection.
- “Ultra-Cold” Projection Light is not on:**  
The “Ultra-Cold” Projection Light will only turn on when the entire Reservoir is below freezing temperature. When the “Ultra-Cold” Projection Light appears varies depending on the original temperature of the liquor or recipe.

# SPIRITS POTIONS (RECIPES)



## TIP

*Keep refill batches (or bottle of liquor) in the freezer for mid-party refills! That way your party never skips a beat and ice cold shots or drinks are continuously flowing!*

## Lemon Drops

- Ingredients** 18 oz (530ml) Citrus Vodka  
7.4 oz (220ml) Sour Mix

## Fuzzy Navel

- Ingredients** 18 oz (530ml) Peach Schnapps  
7 oz (210ml) Orange Juice

## Mud Slide

- Ingredients** 9.5 oz (280ml) Kahlua  
9.5 oz (280ml) Bailey's Irish Cream  
6.4 oz (190ml) Vodka

## Kamikaze

- Ingredients** 11 oz (325ml) Vodka  
7 oz (210ml) Triple Sec  
4 oz (120ml) Sour Mix  
3 oz (90ml) Cranberry Juice

## B-52

- Ingredients** 9.5 oz (280ml) Kahlua  
9.5 oz (280ml) Bailey's Irish Cream  
6.4 oz (190ml) Grand Marnier

## ATTENTION

*Always keep the recipes at least 2 parts alcohol to 1 part non-alcoholic mixer to avoid freezing.*



## FAQS

### How fast does it get cold?

If the liquid is at room temperature:

- a) Approximately 2 hours to get below freezing (32°F or 0°C)
- b) Approximately 3-4 hours to reach 10°-15°F (-12°C to -9°C).

If the liquid comes from the freezer it will chill to Ultra-Cold (15°F or -9°C) in minutes!

### Are there any liquors that won't work with this product?

No, anything from tequila to thicker creamy liqueurs work well in the Liquor Chiller.

### Can I put non-alcoholic liquids in the Reservoir?

Yes, but not without alcohol, the non-alcoholic liquids must equal less than 30% of the whole batch.

NOTE: No juices with fruit pulp. Solids of any kind may clog the dispensing element.

### What mixed drinks can I put in the product?

Any mixed drink with an alcohol content of 70% or more and has no fruit pulp. (That's about 2 parts alcohol to 1 part mixer.)

For example: Lemon Drops = 18 oz. (530ml) Citrus Vodka (71%), 7.4 oz (220ml) sour mix (29%)

### How do I clean the product?

Dispense all liquor or mixed cocktail then run warm water through machine. Drain completely for storing.

### Can you leave it plugged in?

Yes if there is still liquid inside. Do not leave plugged in if empty.

### Does the product dispense out a measured amount?

No, a user can pour as little or as much as they want!

### How do I keep the party going if I use up an entire Reservoir?

Keep refill batches in the freezer. (It only takes minutes to get to Ultra-Cold when taken from the freezer.)

### Are the Drip Tray and Reservoir Lid dishwasher safe?

No, Reservoir Lid and Drip Tray should be hand washed with soap and hot water.

### Can I use the product before the projection light comes on?

Yes! The projection light just lets you know when your potion is Ultra-Cold.

### 1 Year Limited Warranty

Sunbeam Products, Inc., doing business as Jarden Consumer Solutions or if in Canada, Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions (collectively "Jarden Consumer Solutions") warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. Jarden Consumer Solutions, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Jarden Consumer Solutions dealers, service centers, or retail stores selling Jarden Consumer Solutions products do not have the right to alter, modify or in any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than Jarden Consumer Solutions or an authorized Jarden Consumer Solutions service center. Further, the warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

### What are the Limits on Jarden Consumer Solutions' Liability?

Jarden Consumer Solutions shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty.

Jarden Consumer Solutions disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise.

Jarden Consumer Solutions shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

### How to Obtain Warranty Service

If you have any question regarding this warranty or would like to obtain warranty service, please call 1- 877-689-2737 and a convenient service center address will be provided to you.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc., doing business as Jarden Consumer Solutions, located in Boca Raton, Florida 33431.

**PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.**

# NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

# NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---