

COOKTOP, BURNER AND GRATE PARTS

For Model: KDRU763VSS00

(Stainless)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts Tech Sheet	10	W10116151	Indicator, Housing	20	W10116103	Keypad
	W10284341	English	11	W10261512	Bezel, Rear	21	W10250477	Bracket User Interface
	W10284345	French	12	W10137323	Bracket, Spark Module	22	W10115953	Nut, Burner
	W10285549	Use & Care Guide			Cap, Burner	23	W10284666	Assembly, Console
	W10284348	Installation Instructions Safer Cooking Tips	13			24	W10250389	Knob, Control (Dual – LF)
	9762761	English		8286816	LF	25	7431P038-60	Module, Spark
	W10065852	French		W10160229	LR & RF	26	8286930	Gasket, Orifice Holder
				W10115952	RR	27	7103P166-60	Nut, Hex
2		Orifice	14		Base, Burner	28	W10250391	Knob, Control
	W10160179	LF – High		W10189082	LR & RF	29	W10078270	Screw
	W10160185	LF – Low		W10250405	RR	30	3196160	Screw
	W10160232	LR & RF	15		Spring, Electrode	31	W10116115	Len, Indicator Light
	W10282663	RR		W10160826	LF, LR & RF	32	W10271525	Trim
3	W10160187	Orifice Holder (Dual – LF)		8286863	RR	33	7101P338-60	Screw
4		Orifice Holder	16		Electrode	34	4448520	Bumper (12) Bracket, Moving Console
	W10160234	LR & RF		W10250406	LF (Dual)	35		
	W10282659	RR		W10160235	LR & RF		W10130759	Right
5	W10115928	Grate, Burner	17	W10145991	RR		W10130760	Left
6	W10269217	Trim, Island	18		Module, User Interface		W10276498	Griddle, Module
7	W10160825	Clip, Electrode		W10282192	Cooktop	36	W10276498	Griddle, Module
8	8286695	Rubber, Foot		W10189104	Right	37	W10261515	Bezel, Griddle
9	W10261510	Bezel, Front	19		Left Burner Head	38	W10250390	Knob, Griddle
				W10250459	LF	39	W10116113	Control, Griddle
				W10250458	LR & RF			
				W10282515	RR			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Model: KDRU763VSS00

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Model: KDRU763VSS00

(Stainless)


Illus. No.	Part No.	DESCRIPTION
1	W10284547	Valve, Gas (RR)
2	7101P426-60	Screw
3	W10145622	Insulation, Burner Box
4	W10189107	Bracket, Valve
5	W10115850	Bracket, Pressure Regulator
6	4453115	Adapter, 1/2" Female
7	W10115985	Manifold
8	W10250407	Valve, Single (LR & RF)
9	W10189097	Bushing, Burner Box
10	W10189140	Screw, Valve Mtg
11	W10293267	Regulator, Pressure
12	W10250425	Burner Box
13	W10115929	Bracket, Burner LF, LR & RF
	W10280796	RR
14	W10250410	Valve, Gas (LF)
15	W10115843	Cover, Ignition
16	4453116	Adapter, 1/2" Male
17	W10189177	Seal, Switch Cover
18	W10269191	Tube, Pressure Regulator
19	W10269214	Drip, Tray
20	W10145620	Tray, Element Griddle
21	W10246074	Tray, Insulation Griddle
22	W10145621	Insulation, Griddle
23	W10138296	Element, Griddle
24	W10276497	Drip Tray, Griddle

Following Parts Not Illustrated

W10115908	Tubing, Gas (LR)
W10115910	Tubing, Gas (RF & LF)
W10115911	Tubing, Gas (LF - Simmer)
W10280797	Tubing, Gas (RR)

OVEN PARTS

For Model: KDRU763VSS00
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Model: KDRU763VSS00

(Stainless)

Illus.	Part	
No.	No.	DESCRIPTION
1	4449743	Screw
2	4449748	Screw
3	W10105790	Assembly, Bumper
4	W10267896	Top, Chassis
5	W10288061	Tube, Vent
6	W10169756	Lens, Light
7	W10009940	Oven Light Assy
8	W10169757	Bulb, Light
9		Hinge Receiver
	4455605	Left
	4455606	Right
10	W10160867	Frame, Front
11	W10145398	Panel, Back Bottom
12		Side, Chassis
	W10269205	Right
	W10269206	Left
13	W10273153	Back, Chassis
14		Liner, Oven (Not Serviced)
15	W10131825	Sensor
16	4449154	Screw
17	4449040	Screw
18	3196176	Screw
19	4449751	Thermostat (TOD)
20	W10235536	Base, Chassis
21	W10157511	Retainer, Gasket
22	W10269208	Panel, Back Top
23	7101P426-60	Screw
24	W10153096	Orifice, Boiler
25	9758597	Orifice, Boiler Slip Fit
26	W10269193	Support, Channel
27	W10116188	Appliance, Manager
28	W10194453	Switch, Pressure
29	W10076930	Hose, Transfer
30	W10160877	Enclosure, Steam Valve
31	W10111418	Valve, Solenoid
32	W10076760	Sensor, Conductivity
33	W10116067	Hose, Silicone
34	W10160828	Tube, Copper Steam
35	9758598	Assembly, Boiler

FOLLOWING PARTS NOT ILLUSTRATED


INSULATION

	Steam Valve
8300158	Insulation, Wrap
W10145746	Insulation, Back

CHASSIS PARTS

For Model: KDRU763VSS00

(Stainless)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


1	W10225970	Kickplate
3	W10138054	Roller, Assembly
5	3196537	Screw
6	9760860	Foot
7	W10249333	Base, Leveling Leg
8	3196537	Screw
9		Panel, Side
	W10250464	Right
	W10250465	Left
10	W10115869	Shaft, Long
11	W10115793	Shaft, Short
12	489504	E-Ring
13	4449743	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Model: KDRU763VSS00

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10246075	Slope, Exhaust Vent
2	W10160896	Vent, Cooling Top
3	W10245511	Blower
4	W10246078	Vent-Bottom
5	W10160875	Plate, Cooling Latch
6	9762885	Transformer, Control

Illus. No.	Part No.	DESCRIPTION
7	7101P426-60	Screw
8	W10160844	Bracket, Blower
9	W10160858	Cover, Latch
10	W10270396	Chimney Seal
11	9761958	Block, Terminal
13	W10115858	Box, Terminal


Illus. No.	Part No.	DESCRIPTION
14	9759721	Insulator, Terminal Box
15	W10269198	Cover, Channel
16	3196163	Screw
17	7101P460-60	Screw
18	W10249337	Support, Control
19	W10270397	Seal, Foam
20	W10239444	Seal, Control

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Model: KDRU763VSS00

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10225960	Door Liner
2	W10269203	Hinge, Door Right
	W10269204	Left
3	W10188327	Glass, Inner
4	W10115765	Insulation, Door
5	W10188324	Retainer, Glass
6	W10115876	Cover, Hinge Left
	W10115877	Right
7	W10226005	Glass, Inner

Illus. No.	Part No.	DESCRIPTION
8	W10292297	Screw
9	W10113961	Nameplate
10	W10188330	Panel, Door
11	W10115712	Glass, Outer
12	W10217130	Screw, End Cap (2)
13	W10115718	Door Handle
14	W10115713	Handle, End Caps Right
	W10115714	Left
15	9759229	Bracket(2nd Glass)
16	W10212184	Screw, End Cap
17	W10145810	Bracket, Bottom


Illus. No.	Part No.	DESCRIPTION
18	W10145806	Bracket, Top
19	W10296908	Shield, Heat Top
20	3196537	Screw
21	7101P426-60	Screw
22	W10226024	Shield, Heat Bottom
23	W10296907	Bracket, Door Top
24	9759230	Bracket(3rd Glass)
25	W10145811	Bracket, Side (2)
26	W10225964	Support, Handle
27	W10061760	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Model: KDRU763VSS00

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10160857	Shield, Element Broil
2	W10115991	Element, Broil
3	W10212435	Oven, Rack Sliding Hefty
4	W10277392	Rack, Heftier
5	W10115992	Element, Hidden Bake

Illus. No.	Part No.	DESCRIPTION
6	W10160879	Baffle, Convection
7	W10116228	Motor, Convection
8	W10116351	Blade, Fan
9	W10261523	Cover, Fan
10	W10116349	Nut
11	W10116434	Element, Convection

Illus. No.	Part No.	DESCRIPTION
12	W10160872	Tray, Hidden Bake
13	9755542	Probe, Temperature
14	7101P500-60	Screw
15	W10150011	Jack, Meat Probe
16	9755546	Nut
17	9755547	Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Model: KDRU763VSS00

(Stainless)

Illus. No.	Part No.	DESCRIPTION
-------------------	-----------------	--------------------

ADHESIVE

591014	Adhesive Loctite (1/3 oz.)
482338	Sealer, Silastic (3 oz.)
4453192	Seal, Ribbon Cable
4453191	Seal, Access Panel

WIRING HARNESS PARTS

W10116189	Main Harness
W10231531	Harness, Wire Door Latch
W10116183	Harness, Wire Communication
W10116172	Harness, Wire (Switch, F/S)
W10116174	Harness, Wire (Switch, CT)
W10145992	Harness, Wire (Ignitor, 3 Wire)
W10116182	Harness, Griddle
112432	Nut
4450800	Screw, Ground
W10051680	Reducer, Stem
W10076960	Elbow, Plug In

Miscellaneous

W10221288	LP Conversion Kit
4396920	Stainless Steel Cleaner and Polish
31464	Cooktop Cleaner
W10123240	Broil Pan and Roasting Rack
W10231702	Stainless Steel Knob Kit
W10188342	30" Handle Kit
W10253333	Bracket, Anti-Tip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST