INTRODUCTION:

Thank you for purchasing the newest addition to the DIGIPOWER line of Universal Power Products. Now, you no longer need to purchase many adapters for your different products. Whether you have Fuji®, Nikon®, Olympus or any other digital cameras, this one simple Universal Adapter is easy to use and specifically designed for use with your camera. Unlike other AC Adapters, the ACD-100 changes voltage and amperage with each voltage setting, making this a truly dedicated adapter. It comes with four pin connectors to fit almost any digital camera.

Please carefully read the instructions below.

PACKAGE INCLUDES:

 Universal AC Adapter
Pin connectors, labeled: D, E, F and G.
compatibility chart for Pin and Voltage settings One Year Manufacturer Warranty

If you have any questions regarding this product or any other DIGIPOWER* product, please email digipowersolutions@mizco.com, or call toll free: (866) DG-POWER.

INSTRUCTIONS:

1. Before you power up your digital camera with the ACD-100, refer to our camera compatibility chart included with this package for the correct Pin connector to use and the correct Voltage setting.

Select the appropriate Pin connector (D, E, F or G) and attach it to the output socket at the end of the output cord.
Now, to set the Voltage dial on your ACD-100 to your camera's setting, turn the dial until the arrow is pointed directly at the Voltage listed next to your camera model on the chart. (Figure 1)

4. Once you have attached the correct Pin Connector and set the correct voltage, you may plug in the adaptor to your wall outlet.

5. Now you may plug the Pin connector to your camera's DC in jack and power up your Digital Camera.

ACD-100 Voltage dial. ACD-100 Electrical Specifications

Voltage Amperage 3.0 Volts 1.5 Amp 3.4 Volts 2.5 Amp 4.5 Volts 1.5 Amp 5.0 Volts 2.0 Amp 6.0 Volts 2.0 Amp Figure 1. 6.5 Volts 2.0 Amp (2.5 peak) 7.0 Volts 2.0 Amp 8.4 Volts 1.3 Amp 9.0 Volts 1.2 Amp

PRECAUTION:

1. <u>If your unsure if you camera is compatible this ac adapter, or have questions on how to set it up, then</u> please contact DIGIPOWER to see if your camera will work with this unit. Ph: (866) DG-POWER or email:

digipowersolutions@mizco.com

2. Do not expose this product to water, rain or moisture.

3. The ACD-100 Universal AC power supply is multi voltage (110V-240V) and may be used in any country. Do not attach any voltage converter to this adapter.

ONE YEAR WARRANTY:

Mizco International, Inc. warrants this product to be free from defects in materials and workmanship to the original purchaser for a period of One Year from the original purchase date. Mizco's responsibility with regard to this limited warranty shall be limited solely to the repair or replacement, at it's own option, of any product which fails during normal use. This warranty does not extend to damage or failure, which results from misuse, neglect, accident, alteration, abuse, improper installation, or improper maintenance. To exercise this limited warranty, send your name and address with proof of purchase and the UPC from the package. Product sent for warranty must be mailed to the address below, freight prepaid. Include \$5.00 for return shipping and handling.

DIGIPOWER* 140 58th Street Building B, Unit 4G Brooklyn, NY 11220

DIGIPOWER® Customer Support:

If at any time you need technical assistance using your DIGIPOWER* product or simply have comments regarding the product, please call the number below or e-mail us and we will be sure to answer you as quickly as possible. Telephone Support: (866) DG-POWER Email Support: digipowersolutions@mizco.com Fax Support: (718) 567-0630

WARRANTY REGISTRATION

You may EMAIL or FAX your product registration to the above address or telephone number. You may also register online at www.mizco.com http://www.mizco.com

First Name		_ Last Name _		
Company (if purchased for company use)				
Address				
City	State		_ZIP	
Item No. Purchased				
Where did you purchase this item?				
How did you hear about this item?				
-				