B1266 Instructions






Please keep this instruction sheet for future reference, as it contains important information. Adult assembly is required. Tool required for assembly: Phillips Screwdriver (not included).


Www.fisher-price.com Www.fisher-price.com Noah's Ark

Parts


This product contains small parts in its unassembled state. Adult assembly is required.



Assembly




- Fit the cabin to the deck as shown.
- While holding the cabin in place, turn the deck over and insert an M3 x 16mm screw into each hole in the deck and tighten the screws with a Phillips screwdriver. Do not over-tighten.



- Fit the groove on the top of the door onto the peg at the top of the doorframe.
- Press the bottom of the door to fit it onto the peg at the bottom of the doorframe.

Assembly



- Fit the flag into any hole on top of the cabin.
- Press the button under the front of the deck and lift to remove the deck.
- Press the button on top of the hull to open.

Care

- Wipe the toy with a clean cloth dampened with a mild soap and water solution.
- Do not immerse the toy.

Questions? We'd like to hear from you!

Call Fisher-Price[®] Consumer Relations, toll-free at **1-800-432-5437**, 8 AM- 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price[®] Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

For countries outside the United States:

CANADA: Questions? 1-800-567-7724. Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

GREAT BRITAIN: <u>Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500302.</u> AUSTRALIA: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

NEW ZEALAND: 16-18 William Pickering Drive, Albany 1331, Auckland.

ASIA: Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A. ©2003 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc. PRINTED IN CHINA B1266a-0920