## **User Instructions**

# Multi-Star

#### HALOGEN LAMP WARNING!

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

**Caution!** Always disconnect from main power before replacing lamps or servicing unit. Remember to always replace with same lamps and fuses.

## **Model:** Multi-Star™

### **SPECIFICATIONS:**

Lamp: 5 x ZB-FCS 24V 150W Dimensions: 21" x 21" x 18.5"

Weight: 20 lbs.

Supply Voltage: 120V

Fuse: 10A

Working Position: Any Safe position Duty Cycle: 10 min. ON, 10 min. OFF

Colors: Multiple Colored Lens.



Thank you for purchasing this American DJ® product. For your convenience this lighting effect has been lamped and is ready to be used, there is no assembly required. Please read the following instructions before installing or using your new unit.

#### Operating Instructions:

Unit is ready to be hung or set on flat surface. Be sure not to obstruct cooling vents. Place in a well ventilated area. For best results, fog or special effects smoke must be used in order to see the beams of light.

Caution! Never open unit when in use. Always disconnect main power before servicing or replacing lamp. Remember always replace with the same type of lamps and fuses.

Lamp replacement: Remove thumb screws on each ball and pull off ball cap. Pull out old lamps from their sockets. Replace with new lamps and reassemble. When replacing lamps, it is recommended to change all five lamps at the same time.

For service, contact your American DJ® dealer.