Brookstone°

e5

Wood & Aluminum Earphones with Mic



TABLE OF CONTENTS

Warnings and Cautions	. 2
Location of Parts and Controls	. 3
Using your Earphones	. 3
Features	. 4
Specifications	. 4
Warranty	. 5

WARNING

THIS PRODUCT MAY CONTAIN SMALL PARTS WHICH MAY POSE A CHOKING HAZARD TO CHILDREN.


THIS PRODUCT MAY INCLUDE COMPONENTS WHICH MAY POSE A STRANGULATION HAZARD TO CHILDREN.

- 1. Keep away from children. This is not a toy.
- Listening to audio at excessive volumes can cause permanent hearing damage. Use at as low a volume as possible.
- 3. Use this unit only for its intended use as described in this manual.
- Do not use when failure to hear your surroundings could be dangerous, such as while driving, or when biking, walking or jogging where traffic is present.
- 5. Prior to inserting the earphones, always recheck the earlips to make sure that they are firmly attached to the nozzles.
- 6. Turn up the volume control only far enough to hear properly.
- Ringing in your ears may indicate that the level of the volume is too high. Try lowering the volume.
- 8. Stop using the earphones if they are causing you great discomfort or irritation.

SAVE THESE INSTRUCTIONS

LOCATION OF PARTS AND CONTROLS

- Earphones (shown with Medium Eartips)
- 2. Microphone
- 3. Multi-Function Button Controller
- 2 Additional Pairs of Eartips (Large & Small)




USING YOUR EARPHONES

1. Connect the Earphones to your music player.

Note: When your phone is ringing, click the Center button once to pick up the call. Click once to disconnect the call.

- 2. Click the Volume Up button to increase the volume.
- 3. Click the Volume Down button to decrease the volume.
- 4. Click the Center button once to pause the music.
- 5. Double click the Center button to go to the next track.
- 6. Triple click the Center button to go to the previous track.
- Double click and hold the Center button to fast-forward within a track.
- Triple click and hold the Center button to rewind within a track.



FEATURES

- · Comfortable in-ear design.
- Built-in MICROPHONE for recording voice memos and talking on the phone.
- Convenient MULTI-FUNCTION buttons to control music or video playback and volume level.
- · Soft silicone EARTIPS in three different sizes for ultimate comfort.
- Storage Case

SPECIFICATIONS

Design	. In-ear
Driver Dimension	. 9.2 mm speaker
Impedance	. 16 ohms
Sensitivity	. 105 dB/126 mv
Maximum Input Power	. 5 mw
Frequency Range	. 20 Hz~20 kHz
Plug	. 3.5 mm gold plated
Cord Length	. 53" 12.6" (earphone to remote) 37.4" (remote to plug)
Unit Weight	. Approximately .50 oz.

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may provide their own warranties to the purchaser,

but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Find thousands more great ideas online

Brookstone[®]

737226